OCT 24, 2020

🌐 Microplate reader operating procedure V.2

Zhujun Wei¹

¹2020 iGEM NEFU China

2020 iGEM NEFU China

Zhujun Wei

OPEN ACCESS

DOI:

dx.doi.org/10.17504/protocols.io.bnwymffw

Protocol Citation: Zhujun Wei 2020. Microplate reader operating procedure V.2. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.bnwymffw>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Oct 24, 2020

Last Modified: Oct 24, 2020

PROTOCOL integer ID:
43704

ABSTRACT

We use Tecan Spark® multimode microplate reader to measure absorbance.

MATERIALS

Tecan Spark® multimode microplate reader
96-well plate

SAFETY WARNINGS

Please read the instructions carefully before use.
Please turn off the power after use.

BEFORE START INSTRUCTIONS

1. Click on "instrument" on the left, click on "temperature", and check "temperature control" to control the real-time temperature.
2. In the "Action" bar of the left column, you can drag it to the process list under the 96-well plate, drag up and down to sort, click the trash can to delete the option. You can design your own processes that meet your needs.

1

10m

Turn on the power and warm up for 10 minutes.

- 2 Open the program and select "New" to create a new process.
- 3 Select "Absorbance" in the left column. There is a schematic of a 96-well plate in the middle of the screen.
- 4 You can select the hole to be used according to the spotting hole, and the selected hole will turn blue.
- 5 Put in the 96-well plate, set the parameters, click "start" to measure the absorbance, and then remove the 96-well plate.
- 6 Wait a moment, it will generate an Excel file with results and various parameters. Save and copy the file to the u disk and process the data.