



Jul 27, 2019

Infant formula sample preparation for element analysis using PIXE/RBS

 [PLOS One](#)

DOI

<https://dx.doi.org/10.17504/protocols.io.5qyg5xn>

Seth H. Frisbie¹, Erika J. Mitchell², Stéphane oudeau³, Florelle Domart³, Asuncion Carmona³, Richard Orterga³

¹Department of Chemistry and Biochemistry, Norwich University, Northfield, VT, USA;

²Better Life Laboratories, Inc., East Calais, VT, USA;

³University of Bordeaux, Centre d'Etudes Nucléaires de Bordeaux Gradignan (CENBG), CNRS, Gradignan, France



Richard Orterga

Create & collaborate more with a free account

Edit and publish protocols, collaborate in communities, share insights through comments, and track progress with run records.

Create free account

OPEN  ACCESS



DOI: <https://dx.doi.org/10.17504/protocols.io.5qyg5xn>

External link: <https://doi.org/10.1371/journal.pone.0223636>

Protocol Citation: Seth H. Frisbie, Erika J. Mitchell, Stéphane oudeau, Florelle Domart, Asuncion Carmona, Richard Orterga 2019. Infant formula sample preparation for element analysis using PIXE/RBS. **protocols.io**

<https://dx.doi.org/10.17504/protocols.io.5qyg5xn>

Manuscript citation:

Frisbie SH, Mitchell EJ, Roudeau S, Domart F, Carmona A, Ortega R (2019) Manganese levels in infant formula and young child nutritional beverages in the United States and France: Comparison to breast milk and regulations. PLoS ONE 14(11): e0223636. doi: [10.1371/journal.pone.0223636](https://doi.org/10.1371/journal.pone.0223636)

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](https://creativecommons.org/licenses/by/4.0/), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working

We use this protocol and it's working

Created: July 23, 2019

Last Modified: July 27, 2019

Protocol Integer ID: 26103

Keywords: Infant formula, trace element, manganese, PIXE, RBS, infant formula sample preparation for element analysis, chemical elements from infant formula sample, infant formula sample preparation, infant formula sample, powdered sample, rutherford backscattering spectrometry, liquid sample, chemical element, element analysis, using pix, sample, pix

Abstract

This protocol was developed to quantify chemical elements from infant formula samples by PIXE/RBS (Particle Induced X-ray Emission / Rutherford Backscattering Spectrometry). This protocol aims to analyze powdered samples. Liquid samples can also be prepared beginning from step 6.

Materials

MATERIALS

 Water Optima™ LC/MS Grade Fisher Scientific **Catalog #10728098**

- 1 Work under a clean atmosphere to avoid dust contamination.
- 2 Use a disposable plastic spatula to deliver between 1.0000 grams (g) and 1.0099 g of powdered product to a laboratory-grade plastic centrifuge tube.
- 3 Add 10.00 milliliters (mL) of ultra-trace elemental analysis grade water (Water Optima™).
- 4 Vortex until the complete dissolution or uniform suspension of powder.
- 5 Store the solution or suspension at 4°C for a maximum of 24 hours.
- 6 Immediately before using, vortex the solution again.
- 7 Deliver 1.0 microliter (μL) of the solution or suspension with an air displacement pipet onto a labeled PIXE/RBS sample holder.
- 8 Repeat step 7 until a total of three different drops from the same sample are placed in three different locations of the same sample holder.

Note

Use a different pipette tip to deliver each drop. Always vortex immediately before filling the pipette tip.

- 9 After delivering the three 1.0 μL drops onto the three different locations on the sample holder, store the sample solution or suspension at 4 °C.
- 10 DDry the drops at room temperature in a laminar flow hood for 24h.
- 11 Vortex the solution.



- 12 Superimpose onto each dried drop another 1.0 μL of solution or suspension to increase the quantity of matter in order to be more sensitive for analysis by PIXE/RBS.

Note

Use a different pipette tip to deliver each drop. Always vortex immediately before filling the pipette tip.

- 13 Dry samples at room temperature in a laminar flow hood for 24h and store the solution or suspension at 4°C.
- 14 Repeat steps 11, 12 and 13 until each spot on the sample holder is comprised of three superimposed drops of 1.0 μL .
- 15 Store the sample holders with the dried spots in a desiccator and protect from dust until PIXE/RBS analyses.