FEB 05, 2019

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.xr2fm8e

Protocol Citation: Mattia Pegoraro 2019. 0.5 M EDTA (0.5 L). **protocols.io**
<https://dx.doi.org/10.17504/protocols.io.xr2fm8e>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Feb 05, 2019

Last Modified: Feb 05, 2019

PROTOCOL integer ID:
 19994

Keywords: EDTA, TBE

0.5 M EDTA (0.5 L)
 Forked from [0.5 M EDTA \(0.5 L\)](#)

Mattia Pegoraro¹

¹C.N.R.

Mattia Pegoraro
 C.N.R.

ABSTRACT

Is used in a multitude of experiments, but is often used as an ingredient in 10x TBE buffer

MATERIALS

MATERIALS

Ethylenediamine Tetraacetic Acid Disodium Salt Dihydrate **Fisher Scientific Catalog #S311-500**

Sodium Hydroxide **Fisher Scientific Catalog #BP359-500**

SAFETY WARNINGS

Will be using NaOH pellets, make sure to wear gloves.

BEFORE START INSTRUCTIONS

Make sure you are able to use the pH machine and an autoclave machine

1 Fill 0.5 L beaker with 300 mL of deionized water.

- 2 Add 73.06 g of Ethylenediamine Tetraacetic Acid Disodium Salt (292,24 g/mol) to the water and mix.
- 3 Put the electrode pH meter into the solution (with continuous mixing) and measure the pH (don't worry if the solution isn't clear). The pH will be about 3 at this point. The pH needs to be at 8.
- 4 Add NaOH pellets until the pH is near 7.8 (the solution will be clear around pH 7.5). Complete to arrive at pH 8 with NaOH 5 M solution (also NaOH 10 M is good).
- 5 Once at pH 8, fill to 500 mL .
- 6 Autoclave at 121 °C for 00:15:00 or filter it with 0,22 u filter.