VERSION 2

DEC 28, 2020

OPEN ACCESS

DOI:

[dx.doi.org/10.17504/protocols.io.bq27myhn](https://doi.org/10.17504/protocols.io.bq27myhn)

External link:

<https://research.unimelb.edu.au/centre-for-cancer-research/our-research/single-cell-innovation-lab>

Protocol Citation: Luciano G Martelotto 2020.

'Frankenstein' protocol for nuclei isolation from FRESH and FROZEN tissue for snRNA-Seq (10x Genomics Platform). **protocols.io** <https://dx.doi.org/10.17504/protocols.io.bq27myhn> Version created by Luciano G Martelotto

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Dec 28, 2020

Last Modified: Dec 28, 2020

PROTOCOL integer ID:
45887

Keywords: snRNAseq, 10x, nuclei, isolation, FACS

'Frankenstein' protocol for nuclei isolation from FRESH and FROZEN tissue for snRNA-Seq (10x Genomics Platform) V.2

Luciano G Martelotto¹

¹University of Adelaide

Human Cell Atlas Method Development Community

Single Cell Core, Harvard Medical School

[1 more workspace](#) ↓

Luciano G Martelotto

University of Adelaide

DISCLAIMER

DISCLAIMER – FOR INFORMATIONAL PURPOSES ONLY; USE AT YOUR OWN RISK

The protocol content here is for informational purposes only and does not constitute legal, medical, clinical, or safety advice, or otherwise; content added to [protocols.io](#) is not peer reviewed and may not have undergone a formal approval of any kind. Information presented in this protocol should not substitute for independent professional judgment, advice, diagnosis, or treatment. Any action you take or refrain from taking using or relying upon the information presented here is strictly at your own risk. You agree that neither the Company nor any of the authors, contributors, administrators, or anyone else associated with [protocols.io](#), can be held responsible for your use of the information contained in or linked to this protocol or any of our Sites/Apps and Services.

ABSTRACT

This protocol is the result of the combination of various nuclei isolation protocols for single cell RNA-seq experiments using droplet-based methods, hence the name Frankenstein. Developed to prepare nuclei isolates from small sample sizes (as little as a grain of rice), this protocol uses FACS to identify cell subpopulations based on ploidy (e.g. tumor versus stroma), to ensure that nuclei suspensions are not clumped, and to remove any debris, especially ambient RNA, to help reduce background. The reference protocols can be found in the following papers: Hu, et al., Habib, et al. (2016), Habib, et al. (2017), Lake, et al., and Lacar, et al.

This protocol has been validated in the Single-Cell Innovation Lab (UMCCR) and other labs worldwide for single nuclei experiments using 10x Genomics technologies.

The protocol has been demonstrated to work successfully with fresh, snap/flash frozen, cryopreserved cells, and cell lines, as well as various solid cancers: pancreas, pheochromocytomas, paragangliomas, breast cancer, lymphoma, xenografts and other samples types.

Cardiomyocytes can be really difficult to prepare but we have successfully prepare this. Get in touch for some tips.

ATTACHMENTS

[___Frankenstein___protocol_for_nuclei_isolation_from_fresh_and_frozen_tissue_FINAL.pdf](#)

Note

This protocol requires access to a cell sorter and familiarity with sorting cells/nuclei into 96-well plates.

1. Use a plastic pestle to mechanically homogenize tissue and release nuclei
2. Separate the nuclei from debris using a cell sorter
3. Collect a specific number of nuclei in a 96-well plate containing 10x RT Buffer*
4. Immediately load the sample into a Single Cell Chip for processing according 3' v3.x or 5' v1/2 user guides.
5. FACS sorting **critical** for for a full Frankentein protocol experience, however, it is not absolutely needed.
6. **For a protocol using Iodixanol gradient please contact me.**

*Assume that nuclei recovery is 62%, and use this to determine the number of nuclei to collect for each of your samples. This value was derived from the Cell Suspension Volume Calculator Table in the respective kits' user guides.

10x Genomics Products

Chromium Single Cell Immune Profiling Solution - <https://www.10xgenomics.com/solutions/vdj/>

Chromium Single Cell Gene Expression Solution - <https://www.10xgenomics.com/single-cell/>

New 10x kits and user guidelines have been made available, so follow the same instructions accounting for buffer volume changes.

MATERIALS

MATERIALS

Nuclei EZ lysis buffer **Sigma Catalog #EZ PREP NUC-101**

Nuclei wash and resuspension buffer (prepare chilled, 4°C)

- 1x PBS
- 1.0% BSA
- 0.2 U/μl RNase Inhibitor

Nuclei wash and resuspension buffer with DAPI (prepare chilled, 4°C)

- 1x PBS
- 1.0% BSA
- 0.2 U/μl RNase Inhibitor
- 10 μg/mL DAPI

10x RT Buffer¹ for Single Cell Gene Expression 3' reagents (DO NOT add RT enzyme)

RT Reagent Mix	50 μL
RT primer	3.8 μL
Additive A	2.4 μL
H2O	(31.7 - X - Y) μL

10x RT Buffer¹ for Single Cell Immune Profiling 5' reagents (DO NOT add RT enzyme)

RT Reagent Mix	50 μL
RT primer	5.9 μL

Additive A	2.4 µL
H2O	(31.7 - X - Y) µL

¹RT Buffer Notes

- X ('sorting volume'): In the cytometric analysis setup described in this protocol, each droplet is 1 nL. Example: 10,000 nuclei = 10,000 nL = 10 µL 'sorting volume'.
- Y ('additional volume'): This accounts for any additional volume deposited by the flow cytometer nozzle. In the cytometric analysis setup described in this protocol (i.e. 75 µm nozzle) there is no additional volume deposited by the nozzle, so Y = 0. If in doubt, or to be on the safe side, just make Y = 5-10 µL.
- The 1 nuclei/nL assumption was corroborated empirically by sorting 10,000 nuclei in ten wells containing 70 µL PBS and then measuring the final volume post sorting. It is highly recommended to determine X empirically as value may vary depending on different sorters/nozzle combinations. It is recommended to determine it at least once.
- Always measure the volume after sorting and top up to 90 µL with PBS or H₂O if required.
- After adding the RT Enzyme Mix the final volume will be 100 µL.
- It is crucial to work as fast as possible. Do not leave nuclei sitting on ice for too long (e.g. 30' is too long).
- Reduce as much as possible the time from sorting-to-controller run, ideally keep it under 40 minutes. The longer the time the higher the background will be.

SAFETY WARNINGS

- ⚠ See SDS (Safety Data Sheet) for safety warnings and hazards.

BEFORE START INSTRUCTIONS

All samples and reagents are kept on ice or at 4 °C (wet ice).

Prepare all buffers and reagents as described in the "Materials" section.

Tissue Homogenization

- 1 Mince/chop tissue with a razor blade to small pieces. The tissue may be as small as a grain of rice.

Note

For mincing the tissue, you may take the tube out of ice, however, be quick and return to ice.

- 2 Add 500 µL chilled Nuclei EZ Lysis Buffer to the tissue in 1.5 mL tube.

- 3 Homogenize the sample using a douncer (stroking 10-20 times).

- 4 Transfer the homogenate (~ 500 µL) into a 2 mL tube.

Nuclei Isolation and Staining

- 5 Add 1 mL of chilled Nuclei EZ Lysis Buffer, mix gently and incubate on ice for 00:05:00 . Gently mix with a wide bore tip. Repeat 1-2 times during the incubation.
- 6 Filter homogenate using a 70 µm-strainer mesh. Collect flow through in a polystyrene round-bottom FACS tube and transfer volume back into a new 2 mL tube.
- 7 Centrifuge the nuclei at 500 x g for 00:05:00 at 4 °C and remove supernatant leaving behind ~ 50 µL .
- 8 Gently resuspend nuclei in another 1.5 mL of EZ Lysis buffer, incubate for 00:05:00 on ice.
- 9 Centrifuge the nuclei at 500 x g for 00:05:00 at 4 °C , remove supernatant as much as possible without disturbing pellet (if pellet looks loose leave ~ 50 µL behind).
- 10 Add 500 µL Nuclei Wash and Resuspension Buffer and incubate 00:05:00 **without resuspending** to allow buffer interchange.
- 11 After incubation, add 1 mL of Nuclei Wash and Resuspension Buffer and resuspend the nuclei.
- 12 Centrifuge the nuclei at 500 x g for 00:05:00 at 4 °C , remove supernatant leaving behind ~ 50 µL .
- 13 Gently resuspend nuclei in 1.4 mL Nuclei Wash and Resuspension Buffer and transfer to a 1.5 mL tube (easier to see small pellets).
- 14 Repeat Step 13 and resuspend in 500 µL **Nuclei Wash and Resuspension Buffer supplemented with DAPI**. Collect all nuclei by washing off nuclei from the wall of centrifuge tube.

Note

IMPORTANT: Protect from light from here forward.

Cytometry and 10x

- 15 Filter nuclei (at least once) with a 35- μ m cell strainer. Visually inspect nuclei integrity under a microscope.
- Note
- Count the number of nuclei with a cell counter or hemacytometer if required.
- 16 Perform cytometric analysis. Identify single nuclei and sub-populations based on DNA content, gate and sort directly into 10x RT Buffer prepared **without the RT Enzyme Mix**.
- 17 Proceed immediately with the 10x Genomics Single Cell Protocol and minimize the time between nuclei preparation/sorting and chip loading.
- 18 Add 10 μ L RT Enzyme Mix to the sorted nuclei in RT buffer, mix well but gently and load chip as per the respective user guides.
- 19