SEP 17, 2020

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.bjj8kkrrw

Protocol Citation: Peter Szabo, Steven Wells, Peter A. Sims, Donna Farber 2020. COVID Airway Processing for scRNAseq. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.bjj8kkrrw>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Aug 11, 2020

Last Modified: Sep 17, 2020

PROTOCOL integer ID:
 40288

Keywords: SARS-CoV-2, COVID-19, lymphocytes, isolation, pan-mononuclear cells

COVID Airway Processing for scRNAseq

Peter Szabo¹, Steven Wells¹, Peter A. Sims¹, Farber¹ Donna

¹Columbia University

Human Cell Atlas Method Development Community

Coronavirus Method Development Community

Peter Sims

ABSTRACT

This protocol describes the isolation of lymphocytes and pan-mononuclear cells from airway samples.

ATTACHMENTS

[Columbia_Wells_COVID_Airway_Ficoll_Processing_for_scRNAseq.pdf](#)

MATERIALS

MATERIALS

- ✕ Gibco™ DPBS no calcium no magnesium Thermo Fisher Scientific Catalog #14190144
- ✕ Penicillin-Streptomycin-Glutamine (100X) Thermo Fisher Catalog #10378016
- ✕ UltraPure™ 0.5 M EDTA pH 8.0 Thermo Fisher Scientific Catalog #15575020
- ✕ Thermo Scientific™ Nunc™ 50mL Conical Sterile Polypropylene Centrifuge Tubes Fisher Scientific Catalog #12-565-271
- ✕ 5mL Falcon™ Round-Bottom Polypropylene Test Tubes Fisher Scientific Catalog #14-959-11A
- ✕ Biotin anti-human CD235ab Antibody BioLegend Catalog #306618
- ✕ Biotin anti-human CD66b Antibody BioLegend Catalog #305120
- ✕ BioMag® Plus Streptavidin Bangs Laboratories Catalog #BP628
- ✕ Corning™ Externally Threaded Cryogenic Vials Fisher Scientific Catalog #09-761-71
- ✕ CryoStor CS10 100ML Fisher Scientific Catalog #NC9930384
- ✕ Gibco™ Fetal Bovine Serum qualified Australia Fisher Scientific Catalog #10-099-141
- ✕ Ficoll-Paque™ PLUS Media Fisher Scientific Catalog #45-001-749
- ✕ Human TruStain FcX™ BioLegend Catalog #422302
- ✕ Gibco™ IMDM (Iscoves Modified Dulbeccos Medium) Fisher Scientific Catalog #12-440-053
- ✕ NC-Slide A8™ box with 25 Slides Chemometec Catalog #942-0003
- ✕ Solution 13 AO – DAPI Chemometec Catalog #910-3013
- ✕ Dead Cell Removal Kit Miltenyi Biotec Catalog #130-090-101

Equipment

- Centrifuge
- Cell Counter - NC-3000
- EasyEights™ EasySep™ Magnet (Stemcell Technologies, Cat. No.: 18103)

Equipment

EasyEights™ EasySep™ Magnet

NAME

Magnet for column-free immunomagnetic separation

TYPE

EasySep

BRAND

18103

SKU

<https://www.stemcell.com/easyeights-easysep-magnet.html>

LINK

- MACS Multistand (Miltenyi, Cat. No.: 130-108-934)

Equipment

MACS MultiStand

NAME

Separator for magnetic cell separation

TYPE

MACS

BRAND

130-108-934

SKU

<https://www.miltenyibiotec.com/DE-en/products/macs-multistand.html#130-108-934>

LINK

SAFETY WARNINGS

For hazard information and safety warnings, please refer to the SDS (Safety Data Sheet).

Biosafety Notes

- All materials required for sample processing are to be prepared in the biosafety cabinet before handling of Airway samples.
- All Airway sample manipulation takes place in a biosafety cabinet unless specifically stated.
- All centrifugation steps must take place in capped containers. Upon completion of a centrifugation step, return the capped container to the biosafety cabinet, remove all tubes, and spray and wipe them with >70% ethanol before continuing to the next step.

Preparing Buffer and Media

1

Create the following **DPBS Solution-EDTA** in a bottle of DPBS by using the table below:

Component	Volume (mL)	Starting Conc.	Final Conc.
DPBS	474	-	
FBS	25	100%	5%
EDTA	1	0.5 M	1 mM

Table 1.

2 Create **IMDM Layering Media** in a bottle of IMDM.

Component	Volume (mL)	Starting Conc.	Final Conc.
IMDM	470	-	
FBS	25	100%	5%
EDTA	5	100%	1%

Table 2.

Preparation of Sample

3 Place sample box into biosafety cabinet.

4 Remove samples from box and from the containment bags, discard bags, spray sample containers with >70% ethanol and wipe down.

Note

NOTE: If sputum traps come with tubing attached flush tubing with 1 mL 2 mL (or more) before proceeding to optimize yield.

5 Record the total volume of Airway sample to be processed in mL.

6 Transfer the Airway Sample to a 50 mL tube, add 4 mL DPBS to the airway sample.

7 Spin the Airway for , remove and save four aliquots of the supernatant in cryovials. **Add the same volume to all cryovials.**

Record number of vials: _____ and the volume per vial _____ mL.

Note

NOTE: Ensure that cryovials are decontaminated prior to removal from the biosafety cabinet.

- 8 Add **IMDM Layering Media** to the Airway sample to bring the *total volume* to **25 mL**.

- 9 Add **40 µL Benzonase** to the sample, pipette up and down vigorously to mix and dissociate airway pellet, incubate at **Room temperature** for **00:30:00**.

- 10 Add **750 µL 0.5M EDTA**, and filter sample through a **100 µM** filter.

Ficoll-Paque

- 11 Aliquot **15 mL Ficoll-Paque Media PLUS** to a 50 mL tube.

- 12 Using the **slow** setting on the pipette gun, **gently** layer the airway/IMDM mixture on top of the

15 mL Ficoll-Paque Media PLUS

Take extra care not to disturb the interface while layering. Disturbing the interface excessively prevents the mononuclear cells from becoming a clean layer.

- 13 Spin for **1200 x g, 20°C, 00:20:00** with **no brake**, 4 acceleration.

Note

NOTE: Centrifuge should be pre-warmed to **20 °C**.

- 14 Remove the mononuclear cell layer from each tube and transfer to a new 50 mL tube. **Take extra care to avoid pulling cells from the ficoll layer (underneath the mononuclear cell layer) as this typically contains a lot of granulocytes.** Pulling from the plasma layer is not an issue.

- 15 Top MNC with **cold DPBS Solution-EDTA** to **40 mL** (ensure at least 2-3 volumes are added) and centrifuge the cell suspension(s) for **400 x g, 4°C, 00:10:00**.

16 (Platelet Spin) Discard the supernatant, top tube to 40 mL with cold DPBS Solution-EDTA, and centrifuge the cell suspension for 120 x g, 4°C, 00:10:00.

17 Remove the supernatant (**caution: pellet may be loose**), and re-suspend the cell pellet in 4.5 mL Dulbecco's Phosphate Buffered Saline (DPBS) (final volume should be about 5 mL).

Cell Counting of COVID Samples

18 Add 0.05 mL sample, 0.05 mL DPBS, and 0.005 mL Solution 13 to a 1.5 mL centrifuge tube, incubate for 00:02:00 at Room temperature.

19 Add 0.1 mL BD Cytofix Fixation Buffer to the samples and incubate 00:30:00, Room temperature, and protect from light.

20 Aliquot 0.01 mL sample to the well of a NC-Slide A8 and count on the NC-3000.

Record number and viability below, calculate total cells:

cell number: _____ cells/mL, _____ % viable

Division of Sample for scRNAseq Analysis and Freeze-down

21 Aliquot up to 2×10^7 cells to a 5 mL Falcon Round-Bottom tube and place On ice for subsequent sample clean-up (next section).

22 Freeze down up to 1×10^8 cells in approximately 1×10^7 aliquots (1 mL each) using Cryostor CS10 Medium, a Mr. Frosty, and a -80 °C freezer.

Record the number of vials frozen: _____ and the cells per cryovial frozen: _____.

Sample Clean Up for scRNAseq - CD66b and CD235ab removal

23

Centrifuge the single cell suspension for

 400 x g, 4°C,
00:05:00

24

Discard the supernatant and resuspend the cell pellet in

50 µL DPBS Solution-EDTA

25

Add

 10 µL Human TruStain
FcX

to the single cell suspension and incubate for

00:10:00

4 °C

26

Add

 10 µL biotinylated anti-CD66b and biotinylated anti-
CD235ab

to the sample and incubate for

00:30:00

4 °C

27

While the single cell suspension is incubating add
tube.
 0.2 mL BioMag Plus Streptavidin
Beads

to a 5 mL Falcon Round-Bottom

28

Add

 2 mL DPBS Solution-
EDTA

to the BioMag Plus Streptavidin Beads and place on a magnet for

00:05:00

29

Remove all the supernatant from the BioMag Plus Streptavidin Beads, remove from the magnet and resuspend the beads in

 0.1 mL DPBS Solution-
EDTA

30

Once step 26 ([⇒ go to step #26](#)) is complete, add
 3 mL DPBS Solution-
EDTA

to the single cell suspension and centrifuge

for

 400 x g, 4°C,
00:05:00

31

Resuspend the single cell suspension in the BioMag Plus Streptavidin Beads from step 29 ([⇒ go to step #29](#)), and incubate
at

Room temperature

for

00:05:00

32

Add 3 mL DPBS to the tube and place on a magnet for 00:05:00.

33

Remove supernatant from tube and transfer to a separate 5 mL Falcon Round Bottom tube.

Sample Clean Up for scRNAseq - Dead Cell Removal

34

Centrifuge the single cell suspension for 400 x g, 4°C, 00:05:00, and discard supernatant.

35

Resuspend cell pellet in 0.1 mL Dead Cell Removal Microbeads, mix well, incubate, Room temperature, 00:15:00.

36

While the cell suspension is incubating, place an MS Column onto the MACS Multistand and rinse with 0.5 mL 1x Binding Buffer Solution.

37

Post incubation, apply cell suspension to the MS Column and capture the flow through in a 5 mL Falcon Round Bottom tube.

38

Rinse with 1.5 mL 1x Binding Buffer and capture in the same tube.

39

Centrifuge the single cell suspension for 400 x g, 4°C, 00:05:00, and discard supernatant.

40

Resuspend cell pellet in 0.5 mL DPBS, and count cells.

Cell Counting of COVID Samples (10x)

41

Add 0.05 mL sample, 0.05 mL DPBS, and 0.005 mL Solution 13 to a 1.5 mL centrifuge tube, incubate for 00:02:00 at Room temperature.

42

Add 0.1 mL BD Cytofix Fixation Buffer to the samples and incubate 00:30:00, Room temperature, and protect from light.

43

Aliquot 0.01 mL sample to the well of a NC-Slide A8 and count on the NC-3000.

44

Record number and viability below, calculate total cells:

cell number: _____ cells/mL, _____ % viable

10X Encapsulation

45

Follow the appropriate 10X protocol (Chromium Next GEM Single Cell 3' Reagent Kits v3.1 User Guide – Rev D) for encapsulation of cells from the airway sample.