OCT 15, 2019

DNA Concentration Measurement (Protocol for Thermo Scientific NanoDrop™ 1000 Spectrophotometer)

Alba Balletbó¹

¹Wageningen University

iGEM Wageningen 2019

Alba Balletbó

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.79khr4w

Protocol Citation: Alba Balletbó 2019. DNA Concentration Measurement (Protocol for Thermo Scientific NanoDrop™ 1000 Spectrophotometer). **protocols.io**
<https://dx.doi.org/10.17504/protocols.io.79khr4w>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Oct 15, 2019

Last Modified: Oct 15, 2019

PROTOCOL integer ID:
28684

ABSTRACT

Protocol adapted from the NanoDrop 1000 Spectrophotometer V3.8 User's Manual.

MATERIALS

TE Buffer or MQ Water
DNA Sample

- 1 Open the ND-1000 V3.8.1 Program using the computer (the computer should be connected to the Nanodrop apparatus).

- 2 Click on the corresponding application module (e.g., Nucleic acid to determine the concentration and purity of nucleic acid).
- 3 Open the sampling arm and load a blank sample (e.g., TE Buffer, MQ Water, etc.).
1.5 µL
- 4 Close the sampling arm on the machine to cover the blank sample.
- 5 Click "OK" to read the blank.
- 6 Open the sampling arm and clean the blank off the upper and lower pedestals using a Kim Wipe.
- 7 Load your DNA or RNA sample and close the sampling arm.
1.5 µL
- 8 Select the sample type in the program (e.g., DNA or RNA).
- 9 Click "Measure".

- 10 When finalized, read the 260/280, 260/230 and concentration (ng/μL) measurements.
- 11 Clean the nucleic acid sample off of the upper and lower pedestals using a Kim Wipe.
- 12 Repeat for all samples.
- 13 Close program.