MAR 12, 2021

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.btacniaw

Protocol Citation: Franziska Aron, Gunnar U Neumann, Guido Brandt 2021. Full-UDG treated double-stranded ancient DNA library preparation for Illumina sequencing. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.btacniaw>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Mar 12, 2021

Last Modified: Mar 12, 2021

PROTOCOL integer ID:
 48164

Full-UDG treated double-stranded ancient DNA library preparation for Illumina sequencing

Forked from [Full-UDG treated double-stranded ancient DNA library preparation for Illumina sequencing](#)

Guido

Franziska Aron¹, Gunnar U Neumann², Brandt²

¹Friedrich-Schiller Universität Jena;

²Department of Archaeogenetics, Max Planck Institute for the Science of Human History

MPI EVA Archaeogenetics

Gunnar U Neumann

ABSTRACT

Protocol for the preparation of double-stranded genomic libraries for Illumina sequencing, optimised for ancient DNA (aDNA) with initial USER enzyme treatment. This protocol generates adapter ligated DNA fragments that can be used in conjunction with downstream indexing protocols.

The initial treatment with UDG (USER) removes molecular 'damage' in the form of deaminated cytosines characteristic of aDNA. This protocol is modified after Meyer & Kircher (2010) Cold Spring Harb. Protoc. (doi: [10.1101/pdb.prot5448](https://doi.org/10.1101/pdb.prot5448)) and Briggs et al. (2010) Nucleic Acids Research 38 (6) (doi: [10.1093/nar/gkp1163](https://doi.org/10.1093/nar/gkp1163))

IMAGE ATTRIBUTION

Matthäus Rest

Keywords: ancient DNA, sequencing, nonUDG, double-stranded, DNA, genomic DNA, genomics, palaeogenetics, archaeogenetics, paleogenetics, archeogenetics, aDNA, Illumina, library preparation, nucleic acids

GUIDELINES

Working in an Ancient DNA Laboratory

- All steps of the protocol (except the qPCR at the end) should take place in a clean room facility specifically designed for ancient DNA.
- The researcher performing lab work should be dressed in correspondingly suitable lab-wear, such as:
 - full-body suit with hood (e.g., Tyvek)
 - hairnet
 - face mask
 - two pairs of clean gloves
 - clean shoes
 - protective glasses
- Sample processing and buffer/master mix preparation should be carried out in separated work benches with integrated UV irradiation (e.g. Dead Air PCR work bench)
- Surfaces and equipment should be regularly decontaminated with e.g. bleach solution or Thermofisher's DNA AWAY (or similar) and irradiated with UV.
- All home-made buffers should be prepared in a separate dedicated PCR-free ultra-clean room and UV-irradiated for 30 min.

Please see the following for more detailed guidance:

Llamas, B. et al., 2017. From the field to the laboratory: Controlling DNA contamination in human ancient DNA research in the high-throughput sequencing era. *STAR: Science & Technology of Archaeological Research*, 3(1), pp.1–14. Available at: <https://doi.org/10.1080/20548923.2016.1258824>.

Working in an Molecular Biology Laboratory

The qPCR reaction takes place in a standard DNA-based molecular biology lab. Please keep in mind the safety guidelines of your specific country and institution. Recommendations include wearing of:

- lab coats
- closed shoes and trousers
- safety glasses
- nitrile or latex gloves

Protocol Specific Guidelines

This protocol requires the use of two rooms - a dedicated PCR-free ultra-clean library building room and a standard molecular biology lab for qPCR.

MATERIALS

MATERIALS

T4 DNA Polymerase - 750 units New England Biolabs Catalog #M0203L
NEBuffer 2 (10X) New England Biolabs Catalog #B7002S
1.5 mL Biopur Safe-Lock Tubes Eppendorf Catalog #0030121589
Adhesive clear qPCR sheets Biozym Catalog #600238
DNA LoBind Tubes 1.5 mL Eppendorf Catalog #0030108051
FrameStar® 96 Well Semi-Skirted PCR Plate Roche Style Contributed by users Catalog #4ti-0951
0.2 mL PCR Tube strips Eppendorf Catalog #0030124359
Adenosine-5 Triphosphate (ATP) 1 mL New England Biolabs Catalog #P0756S
BSA molecular biology grade 20 mg/ml New England Biolabs Catalog #B9000S
Bst 2.0 DNA Polymerase - 1600 units New England Biolabs Catalog #M0537S
dNTP Mix - 25 mM each Thermo Scientific Catalog #R1121
Ethanol Merck Millipore Catalog #100983
T4 Polynucleotide Kinase - 2500 units New England Biolabs Catalog #M0201L
TWEEN® 20 Sigma Aldrich Catalog #P9416-50ML
Water Chromasolv Plus for HPLC 2.5L Sigma Aldrich Catalog #34877-2.5L
DyNAmo Flash sYBR Green qPCR Kit Thermo Fisher Scientific Catalog #F415L
MinElute PCR Purification Kit Qiagen Catalog #28004
Quick Ligation Kit - 150 reactions New England Biolabs Catalog #M2200L
User Enzyme NEB Catalog #M5505 L

Additional Reagents

Adapter-Mix (10 μ M), for preparation see the following protocol: [Library Adapter Preparation for Dual-Index Double Stranded DNA Illumina Sequencing](https://doi.org/10.17504/protocols.io.btacniaw)

Primers

Primer ID	Sequence (5'-3')	Concentration
IS7	ACACTCTTTCCCTACACGACGC	10 µM
IS8	GTGACTGGAGTTCAGACGTGTGC	10 µM

qPCR-Standard

- Custom-ordered standard based on a synthetic 224 bp oligo including primer binding sites for the primer pairs IS7/8 (and IS5/IS6 - this standard is also used for the indexing protocol Illumina double-stranded DNA dual-indexing for ancient DNA) ranging from 10^9 to 10^3 DNA copies/µl in serial 1:10 dilutions.

Lab equipment

PCR Thermocycler (e.g. Eppendorf Thermomaster Nexus)

Thermomixer or heatblock (to pre-heat buffers)

Centrifuge 1.5/2.0 ml (e.g. Eppendorf 5424)

Rotor 1.5/2.0ml (e.g. Eppendorf F-45-24-11)

Mini table centrifuge

qPCR machine (e.g. Roche LightCycler® 96 System)

PCR work bench (e.g. AirClean Dead Air PCR Werkbank, 48'')

UV irradiation box or cross linker (e.g. Vilber Lourmat Bio-Link BLX-254)

Vortex mixer (e.g. Scientific Industries Vortex-Genie® 2)

Generic Reagents

Solution of household bleach (2-6% NaClO, then diluted to a working solution concentration of 0.2-0.5% NaClO)

Thermofisher DNA AWAY

Paper towels or tissues

SAFETY WARNINGS

Reagents

Household bleach solution (0.2-0.5 % NaClO in total)

- H290 May be corrosive to metals.
- H314 Causes severe skin burns and eye damage.
- H411 Toxic to aquatic life with long lasting effects.
- EUH206 Warning! Do not use together with other products. May release dangerous gases (chlorine). Remove from surface after recommended incubation time with water-soaked tissue.

DNA AWAY

- H314 Causes severe skin burns and eye damage.

Note: Both bleach solutions and DNA AWAY are used for decontamination. DNA AWAY is less corrosive than bleach and should be preferred for decontamination of sensitive equipments such as surfaces of electric devices.

Guanidinium hydrochloride (GuHCl) (in PB buffer of Qiagen MinElute kit)

- H302 Harmful if swallowed.
- H332 Harmful if inhaled.
- H315 Causes skin irritation.
- H319 Causes serious eye irritation.

Ethanol

- H225 Highly flammable liquid and vapour.
- H319 Causes serious eye irritation.

Kits

Check manufacturer's safety information for the High Pure Viral Nucleic Acid Large Volume Kit used in this protocol.

Equipment

UV radiation

- UV radiation can damage eyes and can be carcinogenic in contact with

skin. Do not look directly at unshielded UV radiation. Do not expose unprotected skin to UV radiation.

- UV emitters generate ozone during operation. Use only in ventilated rooms.

BEFORE START INSTRUCTIONS

Planning

This protocol takes approximately 8-9 hours!

While all steps of the protocol are performed in an Ancient DNA facility, the qPCR will be performed in a modern DNA facility with a 1:10 dilution of the samples, which were prepared in the cleanroom facilities. The library remains in the cleanroom for further processing.

Check waste disposal guidance for all reagents in this protocol against your corresponding laboratory regulations.

Preparation of reagents

All home-made buffers should be prepared in a separate dedicated PCR-free ultra-clean room and UV-irradiated for 30 min. Purchased kits should be DNA-free.

Qiagen MinElute kit

- Add ethanol to PE wash buffer according to manufacturer's instructions.
- Add Tween-20 to EB elution buffer to a final concentration of 0.05% (Tween-20 in EB). This solution is referred to as **EBT** throughout the protocol.
- All reagents of MinElute PCR Purification Kit should be decontaminated with a **30 min UV irradiation** before use.

HPLC-Water should be decontaminated with a **30 min UV irradiation** before use.

Equipment

Make sure all necessary equipment is available (see Materials).

Abbreviations

EBT = EB elution buffer with 0.05% Tween-20

GuHCl = Guanidinium chloride or Guanidine hydrochloride

HPLC = High Performance Liquid Chromatography (-Grade Water)

NaClO = Sodium hypochlorite

UV = Ultraviolet (radiation)

Controls

Take along extraction positive and negative (blank) controls generated during your extraction (see example Extraction Protocol [dx.doi.org/10.17504/protocols.io.baksicwe](https://doi.org/10.17504/protocols.io.baksicwe))

For this protocol you should also add another negative control (HPLC water) to monitor the library preparation experiment. Consider these three extra samples in your calculations for mastermixes and buffer preparations.

Additional Tips

It is recommended to prepare 10% more of the calculated volume of all mastermixes to compensate for possible pipetting error.

UDG Treatment and Blunt End Repair (aDNA library prepara..

- 1 Prepare a mastermix for the blunt end repair calculating 75 µL / reaction. Use a new 1.5 ml LoBind tube to set up the mastermix.

A	B	C	D
Reagent	Stock concentration	Final concentration	1 x Volume [µl]
NEB Buffer 2	10 x	1 x	7.5
ATP	10 mM	1 mM	7.5
BSA	20 mg/ml	0.1 mg/ml	0.38
dNTPs	25 mM each	0.3 mM	0.9
T4 PNK	10 U	0.4 U	3
USER Enzyme	1 U	0.06 U	4.5
UV HPLC-water			26.22
DNA or UV HPLC-water			25
Total			75

Do not add the DNA to the mastermix if you set it up for 2 or more reactions!

1.1 Add 50 μL mastermix to each reaction tube and then add 25 μL sample DNA (use 0.2 ml PCR strip-tubes). Mix by flicking the tubes and spin down briefly.

2 Incubate at 37 °C for 03:00:00 in the thermocycler.

3h

Note

During this incubation take MinElute tubes out of the fridge so that they warm to room temperature before use in the next step. Also label two sets of 1.5 ml LoBind tubes per sample and one set of 0.2 ml PCR tubes for the next steps. At this time you can also add the PB-Buffer (650 μl) to one set of 1.5 ml LoBind tubes for Step 5.2

3 Add 3 μL T4 Polymerase (3 U stock, 0.115 U final) to each library.

4 Incubate at 25 °C for 00:20:00, then at 12 °C for 00:10:00 in the thermocycler.

30m

MinElute Purification

5 Purify the UDG-treated and blunt-end repaired DNA with a MinElute kit, with the following modifications to the manufacturer's protocol.

5.1 Pre-heat elution buffer EBT to 50 °C.

5.2 For each reaction, add 650 μL PB (binding) buffer to a new 1.5 ml LoBind tube and add the UDG-treated and blunt end repaired sample, then vortex briefly to mix.

5.3 Load each reaction (PB buffer + sample) onto a MinElute column and incubate at RT for

00:02:00

Note

This allows sufficient time for the DNA to bind to the silica membrane.

5.4 Spin 15800 x g, 00:01:00 and discard flow-through.

Note

Discard flow-through in one of two following ways:

- Remove all liquid in the collection tube with a pipette, or
- Pour off the liquid into a fresh waste tube, and pat the rim of the collection tube dry on a paper tissue or towel. Use just one spot on the paper tissue per sample. Be careful not to touch the rim of the tube on the waste container. After you are finished with all samples, discard the paper and wipe clean the surface underneath with water and then sterilize the surface with bleach (or DNA Away).

Safety information

During cleaning of surfaces after flow-through discard, do NOT apply bleach before first cleaning with water. Residual GuHCl will react with bleach to form toxic gases.

5.5 Add 700 μ L PE (wash) buffer to the MinElute column.

5.6 Spin at 15800 x g, 00:01:00 and discard flow-through *as in step 5.4*.

5.7

Dry spin for

15800 x g,
00:01:00

5.8

Flip columns 180° and dry spin again for

15800 x g,
00:01:00

5.9

Remove columns from their collection tubes and place them in new labeled 1.5 ml LoBind tubes.

5.10

Add 20 µL pre-heated EBT to the column, let stand for 00:01:00 then spin

15800 x g,
00:01:00

to elute.

Note

Carefully pipette EBT directly onto the center of the membrane without touching the membrane.

Optional: In case the library preparation can not be done in one day, this is a good point to pause the protocol. Freeze samples at -20 °C for up to two weeks until continuation.

Adapter Ligation

6

Prepare a mastermix for adapter ligation calculating

40 µL /
reaction

. Use a 1.5 ml LoBind tube to set up the ligation mastermix.

Note

The mastermix is calculated to accommodate addition of Quick Ligase to each reaction individually after aliquotting to individual reaction tubes.

A	B	C	D
Reagent	Stock concentration	Final concentration	1 x Volume [μl]
Quick Ligase Buffer	2 x	1 x	20
Adapter Mix	10 μM	0.25 μM	1
Eluate from Step 5.10			18
Total			40

Do not add the eluate to the mastermix if you set it up for 2 or more reactions!

- 6.1** Aliquot 21 μL of mastermix to each tube (use 0.2 ml PCR strips). Transfer the complete eluate (step 5.10) (~ 18 μL) per sample to each new tube.

Note

Alternatively, if you have a heat block available, you can add the mastermix to the eluate directly in the 1.5 ml tubes from the elution step without transferring it into 0.2 ml PCR strips. For purification after ligation you can then also add the PB-Buffer into these tubes (step 9.2).

- 7** Then add 1 μL of Quick Ligase (5 U stock, 0.125 U final concentration) to each library sample. Mix by flicking the tubes and spin down.

Note

Make sure to add the full volume of ligase by pipetting up and down several times to get all of it off the walls of the pipette tip.

- 8** Incubate at 22 °C for 00:20:00 in the thermocycler.

Note

During this incubation take MinElute tubes out of the fridge so that they warm to room temperature before use in the next step. Also label two sets of 1.5 ml LoBind tubes and 0.2 ml PCR tubes per sample for the next steps. At this time you can also add the PB-Buffer (650µl) to one set of 1.5 ml LoBind tubes for Step 9.2.

MinElute Purification

- 9 Purify the adapter-ligated libraries with a MinElute kit, with the following modifications to the manufacturer's instructions

- 9.1 Pre-heat EBT to 50 °C .

- 9.2 For each sample, add 650 µL PB buffer to a new 1.5 ml LoBind tube and add the entire volume of the adapter ligation mix, then vortex briefly.

- 9.3 Load each reaction (PB buffer + adapter-ligated library) onto a MinElute column and incubate for 00:02:00 .

Note

This allows the DNA sufficient time to bind to the silica membrane.

- 9.4 Spin at 15800 x g, 00:01:00 and discard flow-through *as in step 5.4*.

- 9.5 Add 700 µL PE buffer to the MinElute column.

9.6

Spin at 15800 x g, 00:01:00 and discard flow-through *as in step 5.4*.

9.7

Dry spin at 15800 x g, 00:01:00 .

9.8

Flip columns by 180° and dry spin again at 15800 x g, 00:01:00 .

9.9

Remove columns from their collection tubes and place them in new labeled 1.5 ml LoBind tubes.

9.10

Add 22 µL of pre-heated EBT to column, let stand for 00:01:00 , then spin 15800 x g, 00:01:00 to elute.

Note

Carefully pipette EBT directly onto the center of the membrane without touching it.

Optional: In case the library preparation can not be done in one day, this is a good point to pause the protocol. Freeze samples at -20 °C for up to two weeks until continuation.

Adapter Fill-in

10

Prepare adapter fill-in reaction calculating 40 µL / reaction . Use a 1.5 ml LoBind tube to set up the adapter fill-in mastermix.

A	B	C	D
Reagent	Stock concentration	Final concentration	1 x Volume [μ l]
Isothermal Buffer	10 x	1 x	4
dNTPs	25 mM each	0.125 mM each	0.2
Bst Polymerase	8 U	0.4 U	2
UV HPLC-water			13.8
Eluate from step 9.10			20
Assay total			40

Do not add the eluate to the mastermix if you set it up for 2 or more reactions!

10.1 Add 20 μ L of mastermix and the complete eluate (step 9.10) (~ 20 μ L) to each tube (use 0.2 ml PCR strips). Mix by flicking the tubes and spin down briefly.

11 Incubate at 37 °C for 00:30:00 then 80 °C for 00:10:00 in the thermocycler.

Note

During this incubation label new 0.2 ml tubes for step 12 and new 1.5 ml LoBind tubes for step 13.

12 Aliquot 18 μ L water to the 0.2 ml PCR tubes. Aliquot 2 μ L per library to 0.2 ml PCR tubes with 18 μ L water (making a 1:10 dilution of the library) for the qPCR quality check (steps 15-16).

13 Transfer the remaining ~ 36 μ L of the final library to a fresh 1.5 ml LoBind tube.

- 14 Freeze the library at $-20\text{ }^{\circ}\text{C}$ without purification until further processing.

qPCR_quality check (modern DNA facility)

- 15 Prepare a qPCR assay calculating $20\text{ }\mu\text{L}$ / reaction. Prepare 2 reactions per sample, plus 16 additional reactions for 7 qPCR standards in duplicates and 2 qPCR blanks. This qPCR uses a 1:10 dilution of the samples.

Note

The 1:10 dilutions of the samples are prepared in the cleanroom, but the qPCR is performed in the modern lab.

A	B	C	D
Reagent	Stock concentration	Final concentration	1 x Volume [μL]
DyNAmo MasterMix	2 x	1 x	10
IS7 primer	10 μM	1 μM	1
IS8 primer	10 μM	1 μM	1
HPLC-Water (non UVed)			7
DNA or HPLC-Water (1:10 dilution)			1
Total			20

Do not add the DNA dilutions to the mastermix.

Note

****Important****

Do NOT vortex the DyNAmo mastermix, it will create bubbles that are nearly impossible to remove. The bubbles will interfere with the qPCR measurements. Gently pipette the DyNAmo mastermix to equally distribute the fluorescent dye.

Gently pipette the qPCR mastermix, or gently invert the tube several times to mix. Again avoid creating any bubbles.

- 15.1** Add 19 µL mastermix and 1 µL 1:10 diluted libraries, standard, or water to a fresh 96-well qPCR plate. Seal with adhesive clear qPCR seal sheets and briefly spin down.

Note

Be sure to check that the reactions do not contain bubbles, because this will affect the qPCR readings and subsequent downstream calculations. If bubbles are present, briefly centrifuge the plate at maximum speed to remove them.

- 16** Amplify the qPCR reactions with the following program:

A	B	C
Temperature	Time	
95°C	10 min	Initial denaturation
95°C	30 sec	40 cycles
60°C	1 min	
72°C	30 sec	
60-95°C		Melting curve
Finally hold the reactions at 37°C.		

Note

The number of DNA copies determined with this qPCR is used to determine the amount of sample used as input for indexing protocols.