FEB 24, 2020

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.bam9ic96

Protocol Citation: Marda Jorgensen, Jerelyn Nick 2020. HuBMAP: Paraffin Embedding Tissue Samples . **protocols.io** <https://dx.doi.org/10.17504/protocols.io.bam9ic96>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Dec 18, 2019

Last Modified: Feb 24, 2020

PROTOCOL integer ID:
 31137

Keywords: hubmap, embedding, tissue, histology, histopathology

HuBMAP: Paraffin Embedding Tissue Samples

Marda Jorgensen¹, Jerelyn Nick¹

¹University of Florida

Human BioMolecular Atlas Program (HuBMAP) Method Development Community
 Tech. support email: Jeff.spraggins@vanderbilt.edu

Leigh Propper
 University of Florida

ABSTRACT

The purpose of this Standard Operating Procedure (SOP) is to outline procedures for the paraffin embedding of HuBMAP specimens.

GUIDELINES

- Managers and supervisors - are responsible for making sure that technicians are properly trained and equipment and facility are maintained in good working order.
- Laboratory personnel - are responsible for reading and understanding this SOP and related documents and to perform these tasks in accordance with the SOPs.

MATERIALS

MATERIALS

- Paraplast **Contributed by users Catalog #39501006**
- Gauze 4x4 Non-Sterile Squares **Fisher Scientific Catalog #MSD-1400249**
- Disposable Embedding Molds **Fisher Scientific Catalog #22363553**
- Electron Microscopy Sciences - Tissue Embedding Center **Fisher Scientific Catalog #50-293-24**
- Curved Medium Point General Purpose Forceps **Fisher Scientific Catalog #16100-110**
- General-Purpose Broad-Tipped Forceps **Fisher Scientific Catalog #10-300**
- Tissue Embedding Center OR Paraffin Wax Dispenser and Cold Plate
- Paraplast
- 4x4 Gauze
- Preference of Forceps / Tweezers

SAFETY WARNINGS

- Use physical safety precautions when working with sharps (disposable blades).

BEFORE START INSTRUCTIONS

- Embedding can be a messy process, to protect your clothes it is best to wear a lab coat or apron.
- Gloves are required when working with human specimens.

Post-Processing Tissue Acquisition

- 1 Place processed cassettes in wax holding chamber of embedding center.
Stock station with embedding utensils, gauze, and disposable embedding molds.

3m 30s
- 2 Preheat embedding utensils in the forceps warming chambers located on the sides of the paraffin dispensing nozzle.
Turn on station cold plate module. .

3m 30s
- 3 Open the cassette carefully maintaining tissue orientation. Dispose of cassette lid.

30s
- 4 View the tissue sample and select an appropriately sized disposable embedding mold.

30s
- 5 Using forceps, tap the dispenser plate on the embedding center's dispensing nozzle and partially fill a mold with molten paraffin.

30s

- 6 Using heated forceps, carefully transfer the tissue inside the cassette into the mold, placing the tissue cut side down (surface viewed when opening the cassette).
- 7 Transfer the mold to the cold pad in front of the dispensing nozzle, and gently press tissue flat with forceps or a tamper.
Allow paraffin to solidify in a thin layer, to hold the tissue in position.
- 8 Once oriented with the tissue specimen in the center of the mold, place the lower basket of the emptied cassette on top of the mold.

- 9 Add additional molten paraffin to 2/3 fill the cassette basket.
Remove any bubbles that may form between the mold and the cassette by slowly lifting and repositioning the cassette.
- 10 Carefully transfer paraffin filled mold to freezing/cold plate module of embedding station.
Allow paraffin to completely solidify.

11

If you have additional tissue samples to embed, return to step 4 and repeat through step 11.

⇒ go to step #3 if you have additional samples.