VERSION 1

DEC 12, 2019

OPEN ACCESS

DOI:

dx.doi.org/10.17504/protocols.io.979h9r6

Protocol Citation: Leigh Propper, Marda Jorgensen 2019. HuBMAP - Tissue Sectioning for CODEX Specimens. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.979h9r6>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol in our group and it is working.

Created: Dec 06, 2019

Last Modified: Dec 12, 2019

PROTOCOL integer ID:
30689

🌐 HuBMAP - Tissue Sectioning for CODEX Specimens V.1

Leigh Propper¹, Marda Jorgensen¹

¹University of Florida

Human BioMolecular Atlas Program (HuBMAP) Method Development Community

Tech. support email: Jeff.spraggins@vanderbilt.edu

Leigh Propper

University of Florida

ABSTRACT

This method details our microtomy (sectioning) process for research specimens involved with CODEX diagnostics.

This process follows the CODEX microtomy steps that follow after receiving, processing, and embedding of research specimens into formalin fixed, paraffin embedded tissue blocks.

For best results, the tissue should be devoid of folds and tears. It is critical to meet the exact measurements of 1 cm x 1 cm, and be no more than a thickness of 10 µm due to the the auto-focusing capabilities of the microscope.

FFPE tissues for CODEX® analysis must sectioned onto poly-lysine coated coverslips. These tissue sections can be stored at 4° C for up to one(1) month prior to staining.

GUIDELINES

- Managers and supervisors - are responsible for making sure that technicians are properly trained and equipment and facility are maintained in good working order.
- Laboratory personnel - are responsible for reading and understanding this SOP and related documents and to perform these tasks in accordance with the SOPs.

Keywords: histology, codex, microtomy, tissue sectioning, tissue, pathology, research specimens, histopathology, hubmap

MATERIALS

MATERIALS

☒ Water **Contributed by users**

☒ KimWipes **Fisher Scientific**

☒ Shandon™ Cartilage Curved Thumb Forceps, Curved, Fine Point, standard, 5 in. (12.7cm) **Thermo Fisher Catalog #1631TS**

☒ Flotation Bath **Fisher Scientific**

☒ Microtome Blades (Thermo Scientific Ultra) **Thermo Scientific Catalog #3053835**

☒ Gauze 4x4 Non-Sterile Squares **Fisher Scientific Catalog #MSD-1400249**

☒ Microtomy Brush **Cancer Diagnostics Catalog #SLK1000**

☒ Microtome **Diagnostic Pathology Catalog #HM 315 / HM 325**

☒ Fisherbrand™ Superfrost™ Plus Stain Slides **Fisher Scientific Catalog #22-034979**

☒ EZ-QUIK SLIDE STAINING RACK **Fisher Scientific Catalog #NC0103846**

☒ Tissue-Tek® Cold Plate **VWR Scientific Catalog #25608-942**

☒ Moist Mark Plus Slide/Cassette Marker **Cancer Diagnostics Catalog #SKU: MP2100**

☒ Dumont Forceps (Cover Slip Forceps) **Fine Science Tools Catalog #11251-3**

☒ EMS Cover Glass Staining Racks **Fisher Scientific Catalog #Catalog No.50-949-581**

SAFETY WARNINGS

- ❗
 - Use extreme care when working with microtome blades. They are extremely sharp.
 - Use physical safety precautions when working with sharps (disposable blades).
 - As these specimens are fixed in formaldehyde, gloves and other PPE are optional / personal preference.

BEFORE START INSTRUCTIONS

- Ensure you have proper slides, blades, forceps, and your personal preference of gauzes/wipes.
- Use EXTREME CARE with the poly-lysine squares for mounting the CODEX tissue. Any nicks or dings in the mounting coverslip will make it immediately unusable for this process.
- Always use the specialized CODEX approved forceps to handle the poly-lysine square coverslips.

Microtome Preparation

1 Locate your tissue flotation bath / water bath and fill it completely with de-ionized or purified water. 5m

2 Turn the flotation bath on, and set the water temperature to 42°C. 5m

42 °C Flotation Bath

Note

At this step, also inspect the microtome you are planning to use; Ensure it is clean, well maintained, and set at the correct angle.

Tissue Block Preparation

3

- The best practice for most all facing (trimming) and sectioning is to place a few paper towels or a Wypall on top of the cold plate tray, and dampen it with water.

Cold Plate Example: Sakura Tissue Tek Poly Cold Plate

Note

- Ensure the tissue blocks you have chosen to section have been correctly embedded (1cm x 1cm), and all wax has been scraped/cleaned off the sides of the block.
- Ensure the tissue blocks have been correctly labeled with proper identification (case #, type, etc)

Coverslip Preparation

- 4 If the supply of the coated poly-L-lysine coverslips for CODEX microtomy is getting low, additional slips must be made ready.
Please follow the protocol below if you are close to expiration on or running low of CODEX coverslips.

CITATION

Francesca Farris, Marda Jorgensen. Poly-Lysine Coverslip Preparation.

LINK

<https://protocols.io/view/poly-lysine-coverslip-preparation-baeribd6>

Tissue Block Facing

- 5 After locating the appropriate blades to use for your microtome, carefully select a blade from it's container, and place it inside the microtome's knife holder area. Be sure to secure it in place with the knife clamp/lock spanner. 10m

Microtome blade dispensing from storage box.

Note

Before putting a microtome blade into the knife holder, BE SURE to utilize the locking lever under the flywheel.

- 6 After securing your knife and double checking your microtome settings one final time, retrieve a block from your ice tray and secure it in the microtome's chuck (block holder). 3m

A set up, tidy microtome, with a secured knife in the knife holder and tissue block in the microtome chuck.

- 7 After the block is secured, use the coarse advance wheel on the left side of the microtome to carefully, approach the block with the blade and cut a few thin sections to ensure the positioning is correct. Adjust if necessary.
- 8 Notate all pertinent information on the [CODEX Microtomy Tracking Sheet](https://dx.doi.org/10.17504/protocols.io.979h9r6) .

Cut Date	Logged Date	Tissue	Case #	Block ID	Trim Date	H/E Sections Collected	CODEX Sections Collected	Rack Location	CODEX Storage Location
					☐ New ☐ Recut µm removed: _____	Thickness: _____	Thickness: _____		
					☐ New ☐ Recut µm removed: _____	Thickness: _____	Thickness: _____		
					☐ New ☐ Recut µm removed: _____	Thickness: _____	Thickness: _____		
					☐ New ☐ Recut µm removed: _____	Thickness: _____	Thickness: _____		
					☐ New ☐ Recut µm removed: _____	Thickness: _____	Thickness: _____		
					☐ New ☐ Recut µm removed: _____	Thickness: _____	Thickness: _____		
					☐ New ☐ Recut µm removed: _____	Thickness: _____	Thickness: _____		

Small view of the Codex Microtomy Sheet.

Note

The process of sectioning CODEX specimens requires specific documentation at the tissue block trimming and microtomy stage.

As you begin to cut into a new or already used tissue block, you must keep track of how many microns of tissue are removed from the block during trimming, and also during microtomy. Attached is a generic document that is used to keep record of what tissue block is being cut. All identification factors, trimming data, what tissue sections were used and their purpose, as well as storage information.

Formal documentation of how far into the tissue block you have traveled as well as how many sections were used is an extremely important and necessary function in this process.

- 9 Trim gently into the block to expose the tissue surface to a level where a complete representative section can be cut.

Note

Trimming is normally done at a thickness of 10-30 µm. This can be performed with the advance flywheel alone, or a combination of both the advance and coarse advance wheels using the rocking method.

- 10** After each tissue block has been trimmed to expose a representative surface of the specimen, place each block back on your ice tray. Let each block chill for approximately 10-15 minutes.

Note

Cold wax allows thinner sections to be obtained by providing support for harder elements within the tissue specimen. The small amount of moisture that penetrates the block from the melting ice pieces or ice water will also make the tissue easier to cut.

Coverslip Preparation

11

10m

- Prepare a clean, dry surface near the microtome, and place your poly-L-lysine dish with the coverslips there.
- There is not a way to mark or identify these slips due to the nature of the processing on CODEX. Therefore, it is extremely important to pay attention and keep track of what you're cutting and where you place it in the special CODEX slide rack.

Note

Wear gloves for this step to keep the tiny slips free of smudges, and to keep from contaminating ANY part of the container the slips are kept in.

poly-l-lysine coverslips secured in a sanitized petri dish with creation and expiration date.

- 12 Use an aerosol spray to clean coverslips from dust and lint prior to use.

Note

Wear gloves for this step to keep the tiny slips free of smudges, and to keep from contaminating ANY part of coverslips or the container the slips are kept in.

Performing Microtomy

- 13 After your tissue blocks have chilled on the ice tray for 10 to 15 minutes, and are very cold to the touch, they should now be suitable for precision sectioning. 1h 30m

Remove your first block from the ice tray and secure it into the microtome's block chuck.

- 14 If you used the current exposed part of the microtome's blade on trimming, be sure to slide the knife over to a new, clean section before performing microtomy.

- 15** Using your coarse adjustment wheel on the left, adjust the block holder to be as close as possible to the edge of the knife, but not touching it.

Note

A helpful tip: When you adjust your chuck holder towards the blade and begin to see small water droplets from the condensation from the frozen block accumulate near the knife holder, stop using the coarse advance wheel.

- 16** Very carefully, unlock and rotate the hand wheel on the right side of the microtome so the block holder is moving up and down in a steady, even manner.
A ribbon of wax and tissue should begin to form down the front of the metal plate covering the knife holder.

Note

- - Double check the micron thickness setting prior to this step. Normal thickness for CODEX sections is 5-10 μm .
- - It is normal to have to scrap the first few sections that appear on your ribbon due to holes or other cutting artifacts.

- 17** After your ribbon has begun to form on the front of the knife holder plate, use a pair of forceps (or whatever tool you prefer) to gently grip the bottom of the ribbon and another pair of forceps to gently grip the top of the ribbon nearest the blade.

Gently pull the ribbon up and away from the microtome and towards the waterbath.

A selection of tools ideal to use for securing and floating tissue ribbons during microtomy.

Lifting a ribbon of complete sections away from the knife holder plate.

h

[via GIPHY](#)

Note

"Clip of sectioning a spleen by MJ @ University of Florida"

- 18
- As carefully as possible, shift the ribbon of tissue sections toward your waterbath, and then quickly but gently lay the tissue out on the bath in a "dragging" type motion (either gently towards you, or gently away from you).
 - Wait a few moments while the tissue sections sit on the waterbath, as the heated water will help expand any compression and remove some of the wrinkling or folding in the section.

Preparing to place a paraffin ribbon of tissue sections across a waterbath prior to creating a slide.

Small ribbon of tissue sections afloat on a waterbath - note they are very nice, with no wrinkling, folding, or knifelines.

h

[via GIPHY](#)

Note

Small clip of moving a paraffin tissue ribbon to waterbath by MJ @ University of Florida

- 19** After your paraffin ribbon has floated on the waterbath for approximately 20-45 seconds, use your forceps or tool of choice to separate the sections from each other.
- 20** After selecting your section, use the specialty CODEX forceps and VERY carefully pick up the corner of the poly-l-lysine coverslip.

Dumont #5/45 - Cover Slip Forceps

21 VERY gently, dip the poly-l-lysine coverslip into the waterbath, and place adjacent to and slightly under your chosen section.

22 Adjust the section as desired on the slide, and gently lift upwards out of the waterbath.

[h](#)

[via GIPHY](#)

Note

"Clip of a tech carefully selecting a poly-l-lysine coverslip and picking up a section for CODEX staining. Note the specialized staining rack."

23 Place your newly made slides/coverslips into the specialized metal staining rack and let your slides air dry overnight. **Following the air drying process, the sections must be stored at 4 °C for no more than a month, in a freezer-safe box where the sections cannot be stacked or damaged.**

1d

🔥 4 °C

Specialized custom staining rack appropriate for the poly-L-lysine coverslips.

Note

As there is no way to mark these types of slides with identification, it is best to keep one case per rack / tray for organizational and accuracy purposes.

Cleanup Area

10m

24

- After you have sectioned your last tissue block, unlock the microtome knife blade holder's lever.
- Using a magnet or forceps, carefully remove the microtome blade and place into the waste container on the blade's box dispenser, or in a sharps container.

Note

It is a good practice to clean your microtome if you are done for the day. This prevents paraffin gunk buildup on your microtome, waterbath and floor area, in addition to being ideal for safety.

- 25** Using a microtome brush, brush away all remnants of tissue and paraffin around your microtome, it's catch tray, chuck and behind the knife holder.

Note

A commercially prepared product known as "ParaGuard" can assist with the removal of wax and provide a more efficient microtome clean up. It should be lightly used and vigilantly wiped off with gauze after use.

[Example of Paraguard](#)

- 26** Carefully remove the glass dish from your waterbath and dump the remaining water into your nearest sink.
- 27** Clean the emptied waterbath with warm water and dawn dish soap, then replace to the waterbath's bench unit.