JUL 01, 2018

🌐 iGEM 2018 Interlab Study Protocol: Calibration 3

Ylenia Longo¹

¹Heinrich Heine University

iGEM Duesseldorf 2018

Ylenia Longo

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.qpadvie

External link:
<http://2018.igem.org/Measurement/InterLab>

Protocol Citation: Ylenia Longo 2018. iGEM 2018 Interlab Study Protocol: Calibration 3. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.qpadvie>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol in our group for the Interlab challenge and it is working

Created: Jun 02, 2018

Last Modified: Jul 01, 2018

PROTOCOL integer ID:
12738

ABSTRACT

This year's interlab study allows participants to fulfil Bronze medal requirements. For this purposes a set of experiments has to be performed, which in the end will be compared and validated with other team's data. Part of this Challenge are the Calibration protocols. For the third calibration, a fluorescein standard curve is prepared and fluorescence (bandpass width: 520nm/30nm bandpass, 25-30nm width; excitation; 485nm; emission: 520-530nm) is measured.

GUIDELINES

Make sure to always use the same plates, volumes and settings for the measurement as will be used for the other calibrations and the cell measurements. Also take care to remain constant with your pipetting techniques.

MATERIALS

MATERIALS

96 well plate (black, flat bottom preferred) Contributed by users

Fluorescein Contributed by users

1x PBS (pH 7.4-7.6) Contributed by users

BEFORE START INSTRUCTIONS

Make sure to adjust the temperature of your plate reader to room temperature (22°C-25°C) before measurement.

Also prepare the fluorescein stock solution before starting. Follow the steps in this protocol.

Preparation of fluorescein stock solution

- 1
 - Spin down fluorescein kit tube
 - Resuspend fluorescein in 1mL of 1x PBS (this is the 10x fluorescein stock solution)
 - Pipet up and down and make sure that no particulates are visible
 - Dilute the 10x fluorescein stock solution to a 1x fluorescein stock solution by making a 1:10 dilution (e.g. 100µl 10x fluorescein stock solution and 900µl 1x PBS)

Preparation of serial dilutions: 1xPBS

- 2 Pipet 100µl 1xPBS into wells A2-A12. Do the same for row B,C and D.

Preparation of serial dilutions: 1x fluorescein stock solution

- 3 Pipet 200µl of 1x fluorescein stock solution into A1,B1,C1 and D1.

Serial dilutions of fluorescein stock solutions

- 4
 - Transfer 100µl of 1x fluorescein stock solution from A1 to A2.
 - Mix 3x by pipetting up and down. Then transfer 100µl from A2 to A3.
 - Mix again 3x by pipetting up and down and transfer again 100µl from A3 to A4.

Continue this procedure until arrived at well A11. Mix 3x by pipetting up and down and transfer 100µl into the **LIQUID WASTE** and **NOT** in A12.

As replicates are performed, the same procedure is performed for row B, C and D as well.

5

Measurement

- 6 Measure fluorescence: (bandpass width: 520nm/30nm bandpass, 25-30nm width; excitation; 485nm; emission: 520-530nm)

Data transfer

- 7 Import your data into the Excel sheet provided by iGEM (fluorescein standard curve tab)