OCT 20, 2019

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.8hmht46

Protocol Citation: Jorge Fernández, Manuela De Las Casas 2019. Microfluidic channels wax priming.
protocols.io
<https://dx.doi.org/10.17504/protocols.io.8hmht46>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 Protocol used for performing experimentation in the AEGIS project. Team Madrid_UCM 2019 has tested it continuously and it works.

Created: Oct 20, 2019

Last Modified: Oct 20, 2019

PROTOCOL integer ID:
 28941

Microfluidic channels wax priming

Manuela De Las

Jorge Fernández¹, Casas¹

¹Universidad Complutense de Madrid

AEGIS - Madrid iGEM 2019

Jorge Fernandez Mendez
 Universidad Complutense de Madrid

ABSTRACT

Procedure for printing microfluidic hydrophobic channels in nitrocellulose membranes.

This protocol depicts the steps for easily printing wax channels using plastic stamps and molten wax.

GUIDELINES

Nitrocellulose membranes that will furtherly used for analytical purposes must be handled with gloved hands.

The following protocol uses, pressure and heat for creating wax channels in microfluidic membranes. If the membranes are going to be used for flow assays, pressure applied must be mild, in order to avoid changing the microscopic structure of the pores.

MATERIALS

MATERIALS

- Glass Petri dishes 90 x 15 cm Contributed by users
- nitrocellulose membrane sheets size 210 mm x 297 mm thickness 200 µm Sigma Aldrich Catalog #Whatman® FF170HP Din A
- Wax crayons (non water-soluble) Contributed by users
- Whatman® FF80HP Din A4 Contributed by users Catalog #FF80HP DIN A4 10/pk
- Laboratory Thermoblock or a thermostated hot plate
- 3d Printed plastic Stamps

Keywords: Microfluidic, Wax Printing, Nitrocellulose, Membrane, iGem, Lateral Flow, AEGIS

BEFORE START INSTRUCTIONS

Pre-heat a thermoblock at 105 °C.

Cut previously a nitrocellulose membranes with the proper dimensions required.

- 1 Set the hot plate to 105°C or at least warm enough to melt the wax. Cut a small amount from one of the wax pencils and place it on a Petri dish. Set the Petri dish on the hot plate and wait for the wax to melt.
- 2 Cut to their appropriate size the nitrocellulose pieces to prime with the designed microfluidic path.
- 3 Once the wax is perfectly melted, take the plastic stamp and wet their sealing ends by immersion for 1-2 seconds in the molten wax. Lift the stamp and observe that the stamping surface is fully covered in wax.
- 4 As fast as possible place the stamp against the membrane, in order to release the wax on the surface of the nitrocellulose membrane. Apply mild pressure for 2-5 seconds, and lift the stamp.

It is possible that the membrane goes up with the stamp. In that case, touch softly the outer region of the sealed membrane in order to detach it from the stamp.
- 5 Cover the nitrocellulose strip with plastified paper that protects the membrane (one sheet on top, another underneath). Place the sandwich on the hot place with a Petri dish on top (this is just to apply soft pressure, any temperature-resistant flat object is valid here). Allow the strip to warm for 5 minutes. This will allow the wax to penetrate all through the strip.
- 6 Remove the strip from the hot plate and let it cool down again. You should see the shape of the channel wax primed on the membrane. Usually it is visible a thin "white shadow" near the border of the wax impression, that represents the limit of the primed channel. If the channel is not wide enough, or it is not uniform, consider repeating the procedure.