FEB 20, 2019

PCL:PEG Electrospinning

Kenneth Schackart¹, Kattika Kaarj¹

¹University of Arizona

481b Laboratory

Kenneth Schackart
University of Arizona

ABSTRACT

This protocol details how to electrospin a PCL:PEG copolymer onto glass cover slip.

GUIDELINES

Lab coat and gloves must be worn at all times.

MATERIALS

Materials:

- 70% ethanol solution
- Syringe pump
- 10 mL syringe with 23 gauge needle tip
- 15 kV power source
- Glass cover slip (1 cm × 1 cm)
- Aluminum foil
- Tape
- Copper plate adhered to stand
- Non-conducting material (i.e. pipette tip, inoculating loop)
- Blade
- Laboratory wax film (Parafilm®)

Reagents

- Polycaprolactone (PCL)
- Polyethylene glycol (PEG)
- Trichloromethane (Chloroform)
- Acetone

OPEN ACCESS

DOI:

dx.doi.org/10.17504/protocols.io.yaffsbn

Protocol Citation: Kenneth Schackart, Kattika Kaarj 2019. PCL:PEG Electrospinning. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.yaffsbn>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Feb 18, 2019

Last Modified: Feb 20, 2019

PROTOCOL integer ID:
20519

Make polymer solution

1 In 50 mL tube, add 14 mL chloroform and 6 mL acetone. This is your solvent solution.

Note

The solvent solution should be 70% chloroform and 30% acetone. You can adjust volumes accordingly.

Safety information

Always work with these solvents in chemical fume hood.

- 2 In 15 mL tube dissolve 1 g PCL in 10 mL solvent solution to make a 10 Mass / % volume solution of PCL in solvent.
- 3 In a second 15 mL tube dissolve 500 mg PEG in 10 mL solvent solution to make a 5 Mass / % volume solution of PEG in solvent.
- 4 Place the solvent solutions on a rocker overnight to fully dissolve.
- 5 Combine the polymer solutions at a rate of 3 parts PCL solution to 1 part PEG solution.

Load the dock

- 6 Fold a 10 cm × 10 cm piece of aluminum foil.

- 7 Attach foil square to copper plate.
- 8 Using double-sided tape, attach cover slips onto aluminum foil.
- 9 Face the copper plate normal to the syringe pump within the enclosure, and move until the plate is approximately 9 cm away from the needle.

Note

Increasing the distance will decrease fiber diameter.

- 10 Vortex the PCL:PEG solution for 3 minutes
- 11 Pour PCL:PEG solution onto petri dish and draw solutin into a 10 mL syringe with 23 ga. tip.
- 12 Purge any bubbles from the syringe by holding the syringe with the tip facing upward and depressing the plunger.
- 13 Load syringe onto syringe pump, and secure.

Electrospin

14 Clip the ground (black) wire to the leads coming from the copper plate.
Clip positive (red) wire to the syringe needle.

15 Set syringe pump rate to 20 $\mu\text{L}/\text{min}$, and begin pumping.

16 Turn on power source set to 15,000 V.

Safety information

Do not touch any of the power source leads. Turn off power source to make any adjustments to the setup.

17 If necessary, "aim" the needle/syringe pump to obtain a uniform layer on all coverslips.

18 If clumping occurs at the needle, use a non-conducting material to clear.

Harvest material

19 Once a desired thickness has been spun, turn off power supply and allow to cool for 2-3 min.

20 Detach power supply leads.

-
- 21** Use a blade to cut the fibers between the cover slips. Use caution not to disturb the fibers on the cover slips.
 - 22** Remove cover slips carefully.