MAY 18, 2021

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.bfzdjp26

Protocol Citation: Brett Hanzlicek, Margot Damaser 2021. SPARC Cat - Sham Control Chronic Cat 3, Day 0. [protocols.io](https://dx.doi.org/10.17504/protocols.io.bfzdjp26)
<https://dx.doi.org/10.17504/protocols.io.bfzdjp26>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](https://creativecommons.org/licenses/by/4.0/), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: May 05, 2020

Last Modified: May 18, 2021

PROTOCOL integer ID:
 36613

🌐 SPARC Cat - Sham Control Chronic Cat 3, Day 0

Margot

Brett Hanzlicek¹, Damaser²

¹Advanced Platform Technology Center, Louis Stokes VA Hospital, Cleveland, Ohio;

²Department of Biomedical Engineering, Cleveland Clinic Lerner Research Institute, Cleveland, Ohio

SPARC

Tech. support email: info@neuinfo.org

Brett Hanzlicek

ABSTRACT

This is a procedure for a sham control chronic cat experiment (Day 0) for cystotomy (bladder surgery). The cystotomy is performed without UroMOCA implantation. The cat is observed daily and imaged on day 0, 14 and 30 to track changes to the bladder and overall cat health in response to the cystotomy. This protocol includes basic surgery, urodynamics and imaging for Day 0 in the chronic experiments.

MATERIALS

Cat - Domestic short-haired cat. Male or female. 6-24 months; 3.5-5.0kg
 Syringe Pump - Genie Touch; Kent Scientific
 Pressure Transducer - Catalog # 503067
 WPI Amplifier - 4 channel transbridge
 WPI National Instruments multifunction I/O device - NI USB 6259
 National Instruments Laptop with Labview software
 Tubing - Masterflex L/S Platinum-Cured Silicone Tubing ID 3/16 "; Cole Parmer
 BNC cables
 Tubing to catheter - APIS
 Laborie Catheter - Argyl Suction Catheter, 3.5 Fr Catalog # 8890703211
 Covidien Sutures - 4-0 Vicryl Polysorb (Covidien UL212)
 3-0 Prolene (Ethicon 8762)
 2-0 Silk Syringe
 60ml Contrast
 Visipaque 320mg/ml
 Surgilube
 Surgical instruments

BEFORE START INSTRUCTIONS

1 week before start of experiment - Confirm absence of bladder spasm; healthy cat

12 hours before experiment, start fasting the cat

You must transport the animal chart along with the cat to surgery site. The veterinary team will record all relevant data in the chart. The chart must then go back to the housing site.

Transport Cat

- 1 Transport cat from housing site to surgery site.

Animal Prep and catheter placement

- 2 Animal is anesthetized and abdomen is shaved by the vet team. The cat is then moved into the surgery room and attached to monitors by the vet team.
- 3 Drape animal and perform betadine scrub on abdomen and genitals.
- 4 Put surgilube on 3.5Fr catheter and insert into bladder through the urethra. Advance the catheter until resistance is met, then pull back 2-3cm.
- 5 Use gentle suction with syringe to withdraw urine from bladder through the catheter. Measure the volume and save the urine for urinalysis.

Cystogram - DYNA CT

- 6 Use 1:5 dilution of contrast to saline to visualize bladder.

Take a 3D CT image with 30ml contrast:saline in the bladder

7 Empty Bladder

Urodynamics/Cystometry 1

8

Note

Performed after cat is transferred from Isoflurane to propofol anesthetic.

Note

Fill rate is 2ml saline/minute using syringe pump.

Note

Data is recorded using Labview software.

Note

Pressure is recorded using an external pressure transducer connected to syringe pump on one end and tubing that leads to the catheter on the other end.

9 Fill bladder with saline and record pressure using pressure transducer connected to LabView

10 Empty Bladder

Cat transitioned back to isoflurane

Surgery

- 11 See protocol titled "SPARC Cat surgery Day 0" for details on accessing and opening the bladder for device insertion.
- 12 Place device in bladder, suture the bladder closed with 4-5 stitches and add 25 ml of dilute contrast through the catheter. Check for leaks and place bladder back into body.
- 13 Take a picture with DYNA-CT and a 3D CT
- 14 Remove stitches from bladder, remove device and suture the bladder and abdomen per protocol titled "SPARC Cat surgery Day 0"

Urodynamics/cystometry 2

- 15 Fill bladder with saline at 2ml/min
- 16 Fill bladder with saline and record pressure using pressure transducer connected to LabView

Wake and return cat

- 17 Wait for cat to wake up and return to housing site.