MAY 18, 2021

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.bfy9jpz6

Protocol Citation: Brett Hanzlicek, Ben Abelson, Margot Damaser 2021. SPARC Cat surgery Day 0. [protocols.io](https://dx.doi.org/10.17504/protocols.io.bfy9jpz6)
<https://dx.doi.org/10.17504/protocols.io.bfy9jpz6>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: May 05, 2020

Last Modified: May 18, 2021

PROTOCOL integer ID:
 36609

SPARC Cat surgery Day 0

Brett Hanzlicek¹, Ben Abelson², Margot Damaser³

¹Advanced Platform Technology Center, Louis Stokes VA Hospital, Cleveland, Ohio;

²Cleveland Clinic Lerner Research Institute, Cleveland, Ohio;

³Department of Biomedical Engineering, Cleveland Clinic Lerner Research Institute, Cleveland, Ohio

SPARC

Tech. support email: info@neuinfo.org

Brett Hanzlicek

ABSTRACT

This protocol for cat surgery to expose the bladder for inactive device insertion.

MATERIALS

Sutures - 4-0 Vicryl Polysorb (Covidien UL212), 3-0 Prolene (Ethicon 8762), 2-0 Silk
 Surgical instruments

Animal Prep and catheter placement

1

Note

Cat is anesthetized and abdomen is shaved by the Cleveland Clinic vet team. The cat is then moved into the surgery room and attached to monitors by the vet team.

- 2 Drape cat and perform betadine scrub on abdomen and genitals.
- 3 Put surgilube on 3.5Fr catheter and insert into bladder through the urethra. Advance the catheter until resistance is met, then pull back 2-3 cm

Surgery - Incision and delivery of bladder

- 4 Mark a line with a skin marker that is midline and 3-4 cm in length.

Note

Use the imaging results to determine the location of the bladder. The feline bladder is intraperitoneal and mobile, therefore the location can vary significantly based on stool burden, positioning etc. The bladder is typically deviated to one side of midline.

- 5 Make the incision through the skin with a #15 blade. Continue to cut through the fat (which separates nicely from the external fascia). Bluntly dissect the skin off of the muscle and use a Weitlaner retractor to keep the incision open.
- 6 Use a scalpal or scissors to make a small incision in the midline muscle (be careful not to go through). Use a right angle or small hemostat to enter the abdomen bluntly and open the muscle/fascia to the length of the incision. Replace the retractor to incorporate the abdominal musculature or use two fingers to spread the abdomen open and visualize the bladder.
- 7 Use a blunt pick-up to grasp the bladder and deliver it out of the incision. Place it on several wet pieces of gauze so the bladder does not come in contact with fur/instruments.

Note

It is a good idea to remove some fluid from the bladder before delivering it - this will decrease the needed length of the incision.

Surgery - Bladder incision

- 8 Mark a 1 cm line on the dome of the distended bladder using a skin marker. Place a 4-0 vicryl full thickness stay-suture at each apex of your planned incision and keep them untied in a hemostat.

Note

When deciding where to mark/cut, identify an area on the dome that appears to be less vascular and not covered in fat. The ureters enter dorsally near the bladder neck.

- 9 Incise the bladder using a #10 blade. Quickly place a closed hemostat or pickup inside the lumen of the bladder so you don't lose the lumen. Use a tissue scissor to open the rest of the mucosa.

Note

The bladder is quite stretchable, so you may not need the entire 1 cm of the mucosa opened.

- 10 Hold one apical suture and have your assistant hold the other suture to prepare for the device to be placed into the bladder.

Surgery - Bladder closure

- 11 Irrigate the bladder with saline, then close the cystotomy. Close the mucosa with a running 4-0 vicryl suture, then the muscle with several interrupted 4-0 vicryl sutures, finishing by tying the initial stay sutures.

Note

Occasionally there is some bleeding from the detrusor, and this is easily controlled with manual pressure or just by throwing a suture.

Note

Given the small capacity of the bladder to start with, be sure to take bites that are as small as possible to offer good closure.

- 12 Perform a quick leak test while you are visualizing the incision in the bladder.

Note

This will also give you a sense of how much you are willing to fill the bladder during post-op cystogram and cystometry.

- 13 Replace the bladder in its orthotopic position.

Surgery - Abdominal closure

- 14 Close the abdominal wall in one layer with 3-0 surgipro running suture and irrigate the wound.

Note

You can also place 1-2 interrupted sutures in the middle of the incision for extra support.

15 Use leftover vicryl for a few Scarpa's or subcutaneous fat stitches.

16 Close the skin with simple, interrupted nylon sutures. Place them closely together.

Note

Don't over tighten the nylon sutures and also cut the tails short. This is so the sutures won't irritate the cat and so the cat isn't able to mess with the sutures.

Notes

17

Note

You will not need any cautery – the most bleeding is from the subcutaneous fat and the detrusor, and this stops quickly with a little pressure.

Note

Wear loupes.

Note

You will not get spontaneous drainage of fluid through the catheter given its small size, you will have to use a syringe to aspirate urine.

Note

When catheterizing the penis, it is almost impossible to see a meatus. Basically retract the foreskin and advance the catheter directly into the center of the triangular shaped glans and it will open up for you. There are usually two areas of the urethra that cause slight resistance.