UF H&E Staining V.1

Francesca Farris¹, Marda Jorgensen¹

¹University of Florida

Human BioMolecular Atlas Program (HuBMAP) Method Development Community

Tech. support email: Jeff.spraggins@vanderbilt.edu

Francesca Farris

VERSION 1
OCT 22, 2019

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.8jthunn

Protocol Citation: Francesca Farris, Marda Jorgensen 2019. UF H&E Staining. [protocols.io](https://dx.doi.org/10.17504/protocols.io.8jthunn) <https://dx.doi.org/10.17504/protocols.io.8jthunn>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](https://creativecommons.org/licenses/by/4.0/), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol in our group and it is working.

Created: Oct 21, 2019

Last Modified: Oct 22, 2019

PROTOCOL integer ID:
29011

ABSTRACT

UF H&E Staining

MATERIALS

MATERIALS

⊗ Eosin-Y OPTIK Contributed by users Catalog #RS4359-A

⊗ Hematoxylin OPTIK DK Contributed by users Catalog #RS4576-A

⊗ Bluing Reagent OPTIK Contributed by users Catalog #RS-4363-B

⊗ Aqueous Clarifier Contributed by users Catalog # RS4361-B

1 Place slides into xylene compatible rack.

- 2 Immerse slide holder in 2 changes of xylene, 5 minutes each.
- 3 Remove slide holder from xylene and transfer to 2 changes of 100% EtOH for 5 minutes each.
- 4 Transfer to 95% EtOH for 3 minutes.
- 5 Transfer to 70% EtOH for 3 minutes.
- 6 Transfer to 50% EtOH for 3 minutes.
- 7 Transfer to water for 2 changes, each 2 minutes.
- 8 Transfer slides to Hematoxylin for 1 minute and 15 seconds.
- 9 Do a quick dip in water and then transfer slides to water for 30 seconds.

- 10 Transfer again to water for two changes, each one minute.
- 11 Transfer to Aqueous Clarifier for 45 seconds.
- 12 Do a quick dip in water and then transfer to water for 1 minute.
- 13 Transfer to bluing reagent for 1 minute.
- 14 Place in water for 5 minutes.
- 15 Transfer to 80% EtOH for 1 minute.
- 16 Transfer to Eosin-Y for 1 minute.
- 17 Transfer to 2 changes of 100% EtOH, first change is 2 minutes, second change is 5 minutes.
- 18 Transfer to xylene for two changes, each 5 minutes.

19 After the second xylene change, use a xylene compatible mountant.