MAY 17, 2019

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.y4bfysn

External link:
<https://mmpc.org/shared/document.aspx?id=213&docType=Protocol>

Protocol Citation: John Stack, Gary Cline 2019. Yale - Triglycerides. **protocols.io**
<https://dx.doi.org/10.17504/protocols.io.y4bfysn>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Mar 12, 2019

Last Modified: May 17, 2019

PROTOCOL integer ID:
 21347

Keywords: Triglycerides

Yale - Triglycerides

John Stack¹, Gary Cline¹

¹Yale University

Mouse Metabolic Phenotyping Centers
 Tech. support email: info@mmpc.org

Lili Liang

ABSTRACT

Summary:

Procedure used to determine the concentration of triglycerides in blood, serum, and plasma. Triglycerides are determined by coupling lipase, glucokinase, glycerol phosphate oxidase, and peroxidase to form a quinonemine dye which is measured at 500 nm.

MATERIALS

MATERIALS

- ⊗ Triglyceride Reagent and Activator **Cliniqa Catalog #R85457**
- ⊗ Multi Analyte Calibrator **Prolabs(cliniqa) Catalog #R60010**
- ⊗ Assayed Control Serum 1 **Prolabs(cliniqa) Catalog #R83082**
- ⊗ Assayed Control Serum 2 **Prolabs(cliniqa) Catalog #R83083**

Reagent Preparation:

Triglyceride Reagent: Add 40mL of Triglyceride Activator to the Reagent bottle.

Multi Analyte Calibrator: Add the appropriate amount of water (6.5mL) to the chemical control bottle. Invert to mix, allowing 15 minutes for the reagent to settle.

Assayed Control Serum 1: Add the appropriate amount of water (6.5mL) to the chemical control bottle. Invert to mix, allowing 15 minutes for the reagent to settle.

Assayed Control Serum 2: Add the appropriate amount of water (6.5mL) to the chemical control bottle. Invert to mix, allowing 15 minutes for the reagent to settle.

BEFORE START INSTRUCTIONS

Analysis by automated system Cobas Mira Plus

- 1 Calibrate Cobas for Triglyceride analysis by running a multi-analyte calibrator and two control serum.

- 2 Sample handling as performed by Cobas Mira Plus.
 - a) Pipette 4 μ L of sample into cuvette.
 - b) Add 275 μ L of Triglyceride liquid reagent.
 - c) Incubate at 37°C for 10 minutes.
 - d) Absorbance is measured at 500nm.