JUL 26, 2019

ABTS decolorization assay – in vitro antioxidant capacity

Daniel C Moreira¹

¹Universidade de Brasília

Daniel C Moreira
Universidade de Brasília

ABSTRACT

This protocol describes how to perform the ABTS decolorization assay to assess potential in vitro antioxidant capacity of molecules and extracts using microtiter plates. Procedures are based on the method described in R. Re, N. Pellegrini, A. Proteggente, A. Pannala, M. Yang, C. Rice-Evans, Antioxidant activity applying an improved ABTS radical cation decolorization assay, Free Radic. Biol. Med. 26 (1999) 1231–1237.

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.42xgyfn

Protocol Citation: Daniel C Moreira 2019. ABTS decolorization assay – in vitro antioxidant capacity.
protocols.io
<https://dx.doi.org/10.17504/protocols.io.42xgyfn>

MANUSCRIPT CITATION:

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol in our group and it is working.

Created: Jul 02, 2019

Last Modified: Jul 26, 2019

PROTOCOL integer ID:
25399

Keywords: Antioxidant, Free radical, 2, 2'-Azino-bis(3-ethylbenzothiazoline-6-sulfonic acid) diammonium salt, Colorimetric assay, Oxidative stress

MATERIALS

MATERIALS

- ⊗ Ultrapure water (Type 1) **Contributed by users**
- ⊗ Corning® 96 well NBS™ Microplate **Sigma Aldrich Catalog #CLS3651**
- ⊗ 22'-Azino-bis(3-ethylbenzothiazoline-6-sulfonic acid) diammonium salt (ABTS) **Sigma Aldrich Catalog #A1888**
- ⊗ Ammonium persulfate (APS) **Sigma Aldrich Catalog #A3678**
- ⊗ (±)-6-Hydroxy-2578-tetramethylchromane-2-carboxylic acid (Trolox) **Sigma Aldrich Catalog #238813**
- ⊗ Phosphate buffered saline (PBS) **Contributed by users**

Equipment	
SpectraMax M3 Multi-Mode Microplate Reader	NAME
Microplate Reader	TYPE
Molecular Devices	BRAND
8002482	SKU
https://www.moleculardevices.com/	LINK
Multi-mode microplate readers (Absorbance, Fluorescence (top/bottom read), and Luminescence (top/bottom read)). Ranges: Abs, 200–1000 nm; FL, 250–850 nm; Lumi, 250–850 nm. Light source: Xenon flashlamp. Detector: Silicon photodiode, Photomultiplier tube. Readtypes: Endpoint, Kinetic, Spectrum scan, and Well scan.	SPECIFICATIONS

ABTS radical preparation

1 Prepare a 7 mM ABTS (e.g., A1888, Sigma-Aldrich) stock solution in ultrapure water.

Example: Dilute 3.8408 mg in a final volume of 1,000 µL¹.

¹ Note that you will need 570 µL (190 µL for each replicate) of the final ABTS[•] stock solution per sample; 400 µL of the ABTS solution produces approximately 10,000 µL of ABTS[•] stock solution

(see step 6).

2 Prepare a 245 mM APS (e.g., A3678, Sigma-Aldrich) solution in ultrapure water.

Example: Dilute 5.5909 mg in a final volume of 100 μ L.

3 Add APS to the ABTS solution so that the final APS concentration is 2.45 mM. This step is necessary to generate the ABTS radical (ABTS $^{\bullet}$).

Example: Add 5.05 μ L of APS to 500 μ L of ABTS; final volume 505.05 μ L.

ABTS solution before APS addition.

ABTS solution right after APS addition.

4 Incubate it overnight (12–16 h) at room temperature in the dark.

ABTS[•] solution after overnight incubation.

5 Check the concentration of the ABTS radical (ABTS[•]) stock solution at 734 nm.

Example: Dilute 10 μL of ABTS[•] solution in a final volume of 1,000 μL using ultrapure water; read it at 734 nm.

6 Prepare an ABTS[•] solution that absorbs ~0.700 at 734 nm.

Example: If the solution prepared in the previous step absorbed 0.689, dilute 100 μL of the ABTS[•] stock solution in a final volume of 9,842.9 μL ².

²Remember that you will need 190 μL per well in the assay; each sample/control/standard is analyzed in triplicate (3 wells).

Example: If you are going to assess two samples at four concentrations each, build a standard curve with six concentrations, and read a blank reaction control (all in triplicate), you will need 8,550 μL of the ABTS[•] stock solution (absorbing ~0.700).

7 Check the absorbance at 734 nm, adjust if necessary, and store until use.

Example: If the solution prepared in the previous step absorbed 0.805, diluted it 1.15-fold (9,000 μL in a final volume of 10,350 μL) to achieve an absorbance of ~0.700.

This is what an ABTS[•] solution that absorbs ~0.700 at 734 nm looks like.

Trolox standard solutions preparation

- 8 Prepare a 2 mM Trolox (e.g., 238813, Sigma-Aldrich) stock solution in PBS³.**

Example: Dilute 1.0012 mg in a final volume of 2,000 μ L.

³If compatible, use the same solvent/buffer in which the sample to be analyzed is prepared to make the Trolox standard solutions.

- 9 Prepare several Trolox solutions at concentrations from 12.5 to 400 μ M⁴ using PBS in Eppendorf tubes.**

Example: First, dilute the 4 mM stock by 5-fold to 400 μ M, and dilute it serially to 200, 100, 50, 25, and 12.5 μ L (e.g., 100 μ L of the previous concentration + 100 μ L PBS).

⁴Under the conditions described in this protocol, the change in absorbance at 734 nm is linear within the 12.5–400 μ M Trolox range (see *Calculation section*).

Sample preparation

- 10 Dilute⁵ the samples at the desired concentrations⁶.**

⁵If a solvent other than PBS is necessary to dilute the sample, prepare adequate solvent controls in the next step.

Example: If you need 50% (v/v) DMSO to dilute your sample, also assess 10% DMSO (without sample) solution in the assay to check for any interference.

⁶For peptides, we usually use 2.0, 1.0, 0.5, and 0.25 mg/mL concentrations. Note that for

peptides with strong activity (i.e., 100% ABTS[•] scavenging), we further dilute them to 0.125–0.031 mg/mL.

ABTS decolorization assay

- 11 **Pipet 10 μ L of PBS (or other solvent used) plus 190 μ L of ultrapure water into separate microtiter plate wells in triplicate.** These will be used as reference/zero for the readings.
- 12 **Pipet 10 μ L of each trolox standard solution (including the control⁷, solvent only) and each sample dilution into separate microtiter plate wells in triplicate.**

⁷These are the reference wells of maximum ABTS[•] concentration, in which no sample or standard were added.
- 13 **Add 190 μ L of the ABTS[•] solution prepared in Step 7 into each well.**
- 14 **Mix the wells content using the 'shake' function of the microtiter plate reader, incubate it for 5 minutes in the dark and read it at 734 nm.**

Calculation

- 15 **Using the average values of the triplicates for each standard concentration, calculate the decolorization effect caused by each samples/standard relative to the absorbance**

of the control (ABTS[•] + solvent) at 734 nm.

$$\text{Decolorization (\%)} = \left(\frac{\text{Control Abs} - \text{Sample Abs}}{\text{Control Abs}} \right) \times 100$$

Example:

Trolox		Absorbance at 734 nm				Decolorization (%)
μM	mg/mL	Read 1	Read 2	Read 3	Average	
0	0	0.399	0.402	0.402	0.401	0.00
12.5	0.0031	0.383	0.392	0.387	0.387	3.41
25	0.0063	0.379	0.381	0.380	0.380	5.24
50	0.0125	0.355	0.357	0.357	0.356	11.14
100	0.0250	0.312	0.314	0.310	0.312	22.19
200	0.0501	0.229	0.232	0.227	0.229	42.81
400	0.1001	0.064	0.062	0.059	0.062	84.62

Trolox standard solutions.

Sample	Absorbance at 734 nm				Decolorization (%)
	mg/mL	Read 1	Read 2	Read 3	Average
0.25	0.203	0.199	0.205	0.202	49.54

Sample.

- 16 Build a standard curve: plot trolox concentrations in mg/mL on the X-axis and decolorization (%) on the Y-axis. Calculate a linear regression ($Y = a \times X + b$; e.g., 'add a linear trendline' in Microsoft Excel).**

Example:

- 17 Calculate sample's antioxidant capacity relative to that of trolox using the equation generated in the previous step.

$$\text{Trolox} - \text{eq (mg/mg)} = \left(\frac{\text{Sample decolorization (\%)} - b}{a} \right) \div \text{Sample concentration (mg/mL)}$$

Example:

$$\text{Trolox} - \text{eq (mg/mg)} = \left(\frac{49.54 - 0.4704}{843.7} \right) \div 0.250$$

$$\text{Trolox} - \text{eq (mg/mg)} = 0.233$$