JUN 03, 2020

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.bfx9jpr6

Protocol Citation: Neilier Junior 2020. Acetate Buffer.
protocols.io
<https://dx.doi.org/10.17504/protocols.io.bfx9jpr6>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: May 05, 2020

Last Modified: Jun 03, 2020

PROTOCOL integer ID:
 36577

Keywords: pH, Henderson-Hasselback, Biochemistry, Molecular Biology

Acetate Buffer

In 1 collection

Neilier Junior¹

¹Universidade Federal de Viçosa

Neilier Junior

Universidade Federal de Viçosa, University of Manitoba

ABSTRACT

A buffer solution has the function of resisting changes in pH even when adding powerful acids or bases. However, in the physiological environment the buffered system also provides cofactors for enzymatic reactions, critical salts and even essential nutrients for cells and tissues. Therefore, when trying to reproduce biological conditions in vitro, we must make the appropriate choice of the buffer. After all, it will provide the appropriate medium in which reactions will occur.

MATERIALS

- Deionized Water
- pH Meter (sensitive)
- Acetic Acid
- Sodium Acetate (anhydrous and trihydrate)

SAFETY WARNINGS

Wear personal protective equipment: gloves, lab coat and mask.

BEFORE START INSTRUCTIONS

Organize your workspace.

Make sure all solutions and equipment are available.

Acetate Buffer

1

Note

pH range: 3.6 to 5.6

(a) 0.1 M Acetic acid (5.8 mL made to 1000 mL)

(b) 0.1 M Sodium acetate; 8.2 g L⁻¹ (anhydrous; M.W. 82.0 g mol⁻¹) or 13.6 g L⁻¹ (trihydrate; M.W. 136.0 g mol⁻¹)

Mix acetic acid and sodium acetate solutions in the proportions indicated:

mL of Acetic acid	46.3	41.0	30.5	20.0	14.8	10.5	4.8
mL of Sodium acetate	3.7	9.0	19.5	30.0	35.2	39.5	45.2
pH	3.6	4.0	4.4	4.8	5.0	5.2	5.6

2 Adjust the final volume to 100 mL with deionized water.

3 Adjust the final pH using a sensitive pH meter.