APR 15, 2019

AFM tip functionalization with glutaraldehyde

George Lykotrafitis¹

¹University of Connecticut

Chemistry Method Development Community

George Lykotrafitis

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.zzuf76w

Protocol Citation: George Lykotrafitis 2019. AFM tip functionalization with glutaraldehyde. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.zzuf76w>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol in our group and it is working.

Created: Apr 11, 2019

Last Modified: Apr 15, 2019

PROTOCOL integer ID:
 22292

ABSTRACT

Attach ligand protein to the AFM cantilever tip through functionalization. Further use it in the single molecule force spectroscopy to detect corresponding receptors on the sample surface (such as the red blood cell membrane).

MATERIALS

Silicon nitride AFM probe: MLCT from Bruker Nano Inc., Camarillo, CA.

- 1 Silanize the tip with 2% v/v 3-aminopropyltriethoxysilane (APTES) in acetone for 10 min at 25°C.

- 2 Rinse the tip with deionized (DI) water.
- 3 Immerse the tip in 0.5% v/v glutaraldehyde in DI water for 30 min at 25°C.
- 4 Rinse the tip with DI water.
- 5 Incubate the tip in protein solution (100-300 µg/mL, eg. 100µg/mL α v β 3 protein) for 30 min at 25°C.
- 6 Rinse the tip with DI water.
- 7 To block remaining aldehyde groups on the probe surface, treat the probe with 100 µg/mL bovine serum albumin (BSA) in tris buffered saline (TBS) for 1 min at 25°C.
- 8 Functionalized tips can be stored at 4°C in phosphate buffered saline (PBS) for 3 days.