OCT 15, 2019

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.728hqhw

External link:
<https://pubs.acs.org/doi/10.1021/acssynbio.8b00427>

Protocol Citation: Konstantinos Ragios 2019. Buffer preparation for OnePot PURE cell-free system .
protocols.io
<https://dx.doi.org/10.17504/protocols.io.728hqhw>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Oct 09, 2019

Last Modified: Oct 15, 2019

PROTOCOL integer ID:
 28480

🌐 Buffer preparation for OnePot PURE cell-free system

Konstantinos Ragios¹

¹EPFL - EPF Lausanne

iGEM EPFL

Konstantinos Ragios
 EPFL - EPF Lausanne

ABSTRACT

In this protocol we explain the procedure to create the Buffers used for Protein and Ribosome purification for the production of OnePot PURE cell-free system.

MATERIALS

Material/Consumables:

- HEPES (*Sigma-Aldrich: H0887-100ML*) pH=7.6 KOH
- Magnesium acetate (*Sigma-Aldrich: M0631*)
- Magnesium chloride (*Sigma-Aldrich: 63020-1L*)
- Potassium chloride (*Sigma-Aldrich: P5405-1KG*)
- Ammonium chloride (*Sigma-Aldrich: 09718-250G*)
- Ammonium sulfate (*Sigma-Aldrich: A4418*) pH=7.6 KOH
- Sucrose (*Sigma-Aldrich: 84097*)
- β-Mercaptoethanol (*Sigma-Aldrich: M6250-100ML*)
- Imidasol (*Sigma-Aldrich: I2399*) pH=7.6KOH
- Glycerol (*Sigma-Aldrich: G7757-1L*)
- Distilled water

Equipment:

- Flow Bottle Top Filter with 0.22μm aPES membrane
- Syringe
- Syringe Filter with 0.22μm PES membrane
- Beakers
- Glass Bottles for storage
- Magnetic stirrer

Keywords: Buffers, Protein , Ribosome, purification, PURE, OnePot, iGEM

SAFETY WARNINGS

When handling β -Mercaptoethanol the researcher should work in a chemical hood and wear protective glasses.

1

Add the materials needed the buffer you want to produce in a beaker. The final concentration of the components for the different buffers is presented in *Table 1* and *Table 2*

1.1

Table 1: Buffers for Protein Purification

Compound	Buffer A	Buffer B	Buffer HT	Stock buffer B
	mM	mM	mM	mM
HEPES	50	50	50	50
Ammonium chloride	1000			
Magnesium chloride	10	10	10	10
Potassium chloride		100	100	100
Imidazole		500		
Glycerol				60%
β -mercaptoethanol	7	7	7	7

Note

In Stock Buffer B, Glycerol should consists of 60% of the final volume

1.2 Table 2: Buffers for Ribosome Purification

Compound	Suspe nsion buffer	Suspe nsion buffer high salt	Buffer C	Buffer D	Cusio n buffer	Ribos ome buffer
	mM	mM	mM	mM	mM	mM
HEPES	10	10	20	20	20	20
Magnesium acetate	10	10	10	10	10	6
Potassium chloride	50	50				30
Ammonium chloride					30	
Ammonium sulfate		3000	1500			
Sucrose					30%	
β -mercaptoethanol	7	7	7	7	7	7

Note

In Cusion buffer, Sucrose should consists of 30% of the final volume

- 2 Add some distilled water and mix with a magnetic stirrer until all the solid components are dissolved

Note

Be careful so the volume at this point does not surpass the desired one, otherwise the components' concentration will be wrong on the final product.

3 Add as much distilled water is needed to reach the final volume of the buffers

4 Filter the solution.

Step 4 includes a Step case.

Stock Buffer B

All the other buffers

step case

Stock Buffer B

Use a syringe filter with 0.22µm PES membrane to filter the buffer before storing it.
Due to the viscosity of glycerol, it might be hard for the solution to be filtered but eventually all the solution will pass through.

5 The buffer must be stored at 4°C

6 Because β-mercaptoethanol has a short half-life we need to add it again to the buffer every time before we perform an experiment.