SEP 19, 2020

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.ber9jd96

External link:
<https://www.nature.com/articles/s41598-017-01731-2>

Protocol Citation: Aizea Morales Kastresana, Bryce Killingsworth, Jennifer Jones 2020. Bulk EV staining with CFDA-SE (with NAP-5 purification). **protocols.io** <https://dx.doi.org/10.17504/protocols.io.ber9jd96>

MANUSCRIPT CITATION: Morales-Kastresana, A., Telford, B., Musich, T.A. et al. Labeling Extracellular Vesicles for Nanoscale Flow Cytometry. Sci Rep 7, 1878 (2017). <https://doi.org/10.1038/s41598-017-01731-2>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

🌐 Bulk EV staining with CFDA-SE (with NAP-5 purification)

Aizea Morales
 Kastresana¹,

Bryce
 Killingsworth¹,

Jennifer Jones¹

¹Translational Nanobiology Section, Laboratory of Pathology, Center for Cancer Research, National Cancer Institute, National Institutes of Health

Translational Nanobiology Section

Jennifer Jones

DISCLAIMER

This protocol summarizes key steps for a specific type of method, which is one of a collection of methods and assays used for EV analysis in the NCI Translational Nanobiology Section at the time of submission of this protocol. Appropriate use of this protocol requires careful, cohesive integration with other methods for EV production, isolation, and characterization.

ABSTRACT

A protocol for bulk CFSE staining of EVs.

GUIDELINES

- When possible CFDA-SE dye and CFSE-stained EVs should be protected from significant light exposure
- Fresh aliquots of CFDA-SE should be prepared from solid CFDA-SE dye every few months to avoid using dye with diminished dying ability due to hydrolysis (however in our lab older aliquots of dye have been used without reduced staining capacity)
- See this link for useful information about handling CFSE and using it for labeling cells for flow cytometry: <https://med.virginia.edu/flow-cytometry-facility/wp-content/uploads/sites/170/2015/10/Protocol-for-CFSE-Labeling.pdf>

Created: Apr 07, 2020

Last Modified: Sep 23, 2020

PROTOCOL integer ID:
35361

Keywords: flow cytometry,
EVs, CFSE, bulk staining

MATERIALS

MATERIALS

DPBS Invitrogen - Thermo Fisher Catalog #14190

DMSO, Anhydrous Thermo Fisher Catalog #D12345

Vybrant™ CFDA SE Cell Tracer Kit Thermo Fisher Catalog #V12883

illustra NAP-5 Columns Ge Life Sciences Catalog #17085301

For preparing CFDA-SE aliquots:

- 1 vial of solid dye from Vybrant CFDA-SE Cell Tracer Kit
- Anhydrous DMSO
- Small volume tubes for aliquoting CFDA-SE (0.5 mL or PCR tubes)
- Large volume tube (5 mL snap tube or 15 mL conical) for diluting CFDA-SE

For staining EVs with CFDA-SE:

- 1 aliquot of CFDA-SE
- 1 Nap-5 column
- 1 500 mL bottle of DPBS
- 1 ring stand to hold Nap-5 column
- Eppendorf 0.5 mL and 1.5 mL LoBind tubes
- Preparation of EVs to stain
- Foil or other cover to protect stained EVs from light
- 37 °C water bath or heat block

Preparing CFDA-SE dye aliquots

- 1 Determine whether or not you need to prepare new aliquots of CFDA-SE dye.
- 2 Let a new vial of solid CFSE-DA dye warm to RT (should take less than 10 minutes.)
- 3 Per the Vybrant™ CFDA SE Cell Tracer Kit instructions, dissolve the solids in the vial in 90 µL anhydrous DMSO (based on the quantity of dye in each vial this creates a 10 millimolar (mM) solution.)

- 4 Dilute the solution to $\text{4500 } \mu\text{L}$ total volume with the same anhydrous DMSO, creating a $\text{200 } \mu\text{M}$ solution.
- 5 Aliquot volumes of choice into tubes and freeze at -20°C , under desiccating conditions to prevent dye hydrolysis during storage.

Dying EVs with CFDA-SE

- 6 Warm one $\text{200 } \mu\text{M}$ aliquot of CFDA-SE in your hand, or in a 37°C water bath until just thawed.
- 7 Dilute the CFDA-SE with DPBS to a concentration of $\text{40 } \mu\text{M}$, pipetting then vortexing to ensure the DMSO in the aliquot fully mixes with the DPBS.
- 8 Prepare a mixture of EVs in DPBS, diluting the mixture to $\text{50 } \mu\text{L}$ in a 0.5 mL low protein binding tube.
- 9 Pipette $\text{50 } \mu\text{L}$ of $\text{40 } \mu\text{M}$ CFDA-SE into the tube with the EV mixture and vortex to mix
- 10 Cover with foil and float onto a 37°C water bath for 2 hours, inverting and flicking the tube halfway through the incubation

Removing free dye with Nap-5 size exclusion column

- 11 Remove top and bottom caps from column and equilibrate with ~ 10 mL of DPBS. Ensure that the column is flushed continuously and does not dry
- 12 Mark 2 Eppendorf LoBind 1.5 mL tubes at the 0.5 mL line on the side of the tube with a pen
- 13 Vortex and quickly spin down stained EV mixture
- 14 The moment after the last drop of buffer elutes from the Nap-5 column, load the entire 100 µL volume of EVs on top of the gel bed of the column and immediately begin collecting eluate in the first marked 1.5 mL tube.
- 15 The moment after the loaded EV mixture has been absorbed into the Nap-5 gel, gently fill the buffer reservoir at the top of the column to the top, using ~ 3 mL of DPBS
- 16 After 0.5 mL of eluate has filled the first 1.5 mL tube, start collecting eluate in the second 1.5 mL tube
- 17 Upon elution of 0.5 mL into the second 1.5 mL tube, the Nap-5 column can be filled with DPBS and flushed
- 18 The first 1.5 mL tube is considered Fractions 1 and 2 and should consist of void DPBS and the second 1.5 mL tube is considered Fraction 3 and 4 and should consist of eluted EVs

- 19** The column should be flushed with ~ 10 mL of DPBS then loaded with 3 mL of filtered 20% Ethanol for storage