OCT 07, 2020

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.bmwk7de

Protocol Citation: yang1832
2020. High resolution Nano-DESI mass spectrometry imaging of lipidomics and metabolomics of tissue.
protocols.io
<https://dx.doi.org/10.17504/protocols.io.bmwk7de>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Sep 30, 2020

Last Modified: Oct 07, 2020

PROTOCOL integer ID:
42670

High resolution Nano-DESI mass spectrometry imaging of lipidomics and metabolomics of tissue

yang1832¹

¹Purdue University

NanoDESI MSI Julia Laskin group Purdue

yang1832

ABSTRACT

Scope:

Acquire imaging mass spectrometry (IMS) datasets of lipids and metabolites on human kidney tissue with ~12µm spatial resolution.

Expected Outcome:

Visualize the lipids distribution localizing to physiological regions within the human kidney by generating ion images of lipids precursor ions.

- 1 Scanned the tissue section with PathScan Enabler IV to visualize the morphology in optical image.

- 2 Calibrate the instrument with Agilent tune mix.
- 3 Set up the appropriate method for lipids and metabolites.
- 4 Add lipid standards into 9/1 MeOH/H₂O solvent as the extracting solvent. Add extracting solvent into the syringe.
- 5 Place the slide on the slide holder and set up the primary capillary and secondary capillary and the solvent flow rate until there is liquid bridge between the two capillaries when land on the tissue surface. Direct the secondary capillary to the mass spectrometry inlet and clamp the capillary voltage on the syringe, adjust the positions of the capillaries until there are stable and intensive signals in the spectrum.
- 6 Using the Labview software to train the shear force probe until it can appropriately recognize the sample surface from the air.
- 7 Place the shear force probe close to the liquid bridge so that it can lead the moving of the capillaries and enable the liquid bridge landing on the sample surface without scratching the tissue.
- 8 Set the start point and the end point of the scanning region.
- 9 Set up the worklist.

10 Start the acquisition.