MAR 30, 2020

OPEN ACCESS

DOI:
[dx.doi.org/10.17504/protocols.io.9gph3vn](https://doi.org/10.17504/protocols.io.9gph3vn)

External link:
<https://doi.org/10.1128/mSystems.00200-20>

Protocol Citation: Carlos Gonzalez, Josh Elias 2020. High-Throughput Stool Metaproteome Extraction. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.9gph3vn>

MANUSCRIPT CITATION: Gonzalez CG, Wastyk HC, Topf M, Gardner CD, Sonnenburg JL, Elias JE, High-Throughput Stool Metaproteomics: Method and Application to Human Specimens. *mSystems* 5(3). doi: [10.1128/mSystems.00200-20](https://doi.org/10.1128/mSystems.00200-20)

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](https://creativecommons.org/licenses/by/4.0/), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

High-Throughput Stool Metaproteome Extraction

mSystems

Carlos Gonzalez¹, Josh Elias²

¹Stanford University; ²Chan Zuckerberg Biohub

Carlos Gonzalez

ABSTRACT

The gut microbiome is strongly associated various disease related periods. In order to better understand how the host and microbiome interact during these periods, it is necessary to survey the proteomic response of both the host and microbes in a large portion of a population. However to date, techniques used to isolate stool proteins have been low-throughput and due to their lack of purity can foul columns and increase mass spectrometer downtime. To address these shortcomings, this protocol was developed. It allows for the processing of 96 samples in parallel and is compatible with common multiplexing labeling technology. It has thus far been used to process anywhere between 10 and 400 samples, with very reproducible results.

GUIDELINES

1. The optimal place to stop first part of protocol is after elution of digested peptides from S-trap column/plate
2. Small Nitrogen tanks (R-tanks) run out really quickly, order at least 3.

MATERIALS

MATERIALS

- 96-well Sample Collection Plate 2 mL Square well 50/pk **Waters Catalog #186002482**
- 2 ML DEEP WELL PLATES PRE-FILLED WITH 0.1 MM CERAMIC BEADS – 10 PACK **Omni International Catalog #27-6007**
- Protifi S-trap 96-well plate **Contributed by users Catalog #C02-96well-1**
- Abgene™ 96 Well 1.2mL Polypropylene Deepwell Storage Plate **Thermo Fisher Scientific Catalog #AB0787**
- Eppendorf twin.tec® PCR plate 96 LoBind skirted 150 µL PCR clean colorless 25 plates **Eppendorf Catalog #30129512**
- Agilent AssayMap Bravo RPS Cartridges **Agilent Technologies Catalog #G549660033 {RPSM07}**

Protocol status: Working
We use this protocol and it's working

Created: Nov 18, 2019

Last Modified: Mar 30, 2020

PROTOCOL integer ID:
29935

Keywords: Proteome,
metaproteome, stool, mass
spectrometry

⊗ Triethylammonium bicarbonate buffer **Merck MilliporeSigma (Sigma-Aldrich) Catalog #T7408-100ML**

⊗ Methanol Optima™ LC/MS Grade Fisher Chemical **Fisher Scientific Catalog #A456-4**

⊗ Benzonase **Merck Millipore (EMD Millipore) Catalog #101656**

⊗ Urea **Millipore Sigma Catalog #U4884**

⊗ Acetonitrile Optima™ LC/MS Grade Fisher Chemical **Fisher Scientific Catalog #A955-500**

⊗ TMT multiplex **Thermo Fisher Scientific Catalog #varies-by-kit**

⊗ DTT **Merck MilliporeSigma (Sigma-Aldrich) Catalog #DTT-RO**

⊗ Iodoacetamide **Merck MilliporeSigma (Sigma-Aldrich) Catalog #I1149**

⊗ Waters 96 well sealing mat **Waters Catalog #186006335**

⊗ Axygen™ AxyMats™ Sealing Mat for 96 Well PCR Microplates **Fisher Scientific Catalog #14-222-024**

⊗ Promega trypsin **Promega Catalog #V5113**

⊗ HEPES-Na **Merck MilliporeSigma (Sigma-Aldrich) Catalog #H7006-100G**

⊗ Hydroxylamine solution **Millipore Sigma Catalog #438227**

STEP MATERIALS

⊗ 2 ML DEEP WELL PLATES PRE-FILLED WITH 0.1 MM CERAMIC BEADS – 10 PACK **Omni International Catalog #27-6007**

⊗ 96-well Sample Collection Plate 2 mL Square well 50/pk **Waters Catalog #186002482**

⊗ Protifi S-trap 96-well plate **Contributed by users Catalog #C02-96well-1**

⊗ DTT **Merck MilliporeSigma (Sigma-Aldrich) Catalog #DTT-RO**

⊗ Abgene™ 96 Well 1.2mL Polypropylene Deepwell Storage Plate **Thermo Fisher Scientific Catalog #AB0787**

⊗ Triethylammonium bicarbonate buffer **Merck MilliporeSigma (Sigma-Aldrich) Catalog #T7408-100ML**

⊗ Promega trypsin **Promega Catalog #V5113**

⊗ TMT multiplex **Thermo Fisher Scientific Catalog #varies-by-kit**

⊗ Eppendorf twin.tec® PCR plate 96 LoBind skirted 150 µL PCR clean colorless 25 plates **Eppendorf Catalog #30129512**

⊗ HEPES-Na **Merck MilliporeSigma (Sigma-Aldrich) Catalog #H7006-100G**

⊗ Axygen™ AxyMats™ Sealing Mat for 96 Well PCR Microplates **Fisher Scientific Catalog #14-222-024**

⊗ Benzonase **Merck Millipore (EMD Millipore) Catalog #101656**

⊗ Iodoacetamide **Merck MilliporeSigma (Sigma-Aldrich) Catalog #I1149**

⌘ Abgene™ 96 Well 1.2mL Polypropylene Deepwell Storage Plate **Thermo Fisher Scientific Catalog #AB0787**

⌘ Methanol Optima™ LC/MS Grade Fisher Chemical **Fisher Scientific Catalog #A456-4**

⌘ Triethylammonium bicarbonate buffer **Merck MilliporeSigma (Sigma-Aldrich) Catalog #T7408-100ML**

⌘ 2 ML DEEP WELL PLATES PRE-FILLED WITH 0.1 MM CERAMIC BEADS – 10 PACK **Omni International Catalog #27-6007**

BEFORE START INSTRUCTIONS

- Make all buffers prior to starting protocol. It's also highly suggested that you plate all samples the day prior to starting the protocol. Keep them in -80.

Lysis and solubilization

- 1 Spin down bead beater plates for 1 minute to pull beads into well ⌚ 00:01:00 at ⚙ 1000 x g . Aliquot approximately ⚗ 200 mg of stool into 96 well beads plate. This protocol will work with less stool at the risk of increasing preparative replicate bias. The samples should be arrayed in a logical way, especially if the end goal is to use multiplexing reagents. Make sure samples are pushed to the bottom of the plate or the lysis buffer may overflow into neighboring wells.

⌘ 2 ML DEEP WELL PLATES PRE-FILLED WITH 0.1 MM CERAMIC BEADS – 10 PACK **Omni International Catalog #27-6007**

- 2 To each sample, add ⚗ 750 µL 750 uL of lysis buffer:

Urea [M] 6 Molarity (M)

Tris-Base [M] 50 millimolar (mM)

SDS [M] 5 % volume

Ⓜ 08.1

Use a multichannel pipette or get carpal tunnel syndrome instantly.

- 3 Seal plate with provided top. Plate the sealed plate into 96-well bead beater. 20 Hz for

00:10:00 . Spin down samples in plate centrifuge at 3000 x g for 00:10:00 at 4 °C .

2 ML DEEP WELL PLATES PRE-FILLED WITH 0.1 MM CERAMIC BEADS – 10 PACK **Omni International Catalog #27-6007**

- 4 Observe the samples and make sure they are sufficiently homogenated/solubilized. Aliquot 500 µL of the homogenated sample into a new Waters 2 mL deep well plate. Spin the new plate for 00:10:00 at 3000 x g and take supernatant into new 2 mL Waters plate, this will be the sample stock.

96-well Sample Collection Plate 2 mL Square well 50/pk **Waters Catalog #186002482**

- 5 Add 3 3 µL benzonase to each sample and place in incubator at 37 °C for 00:10:00

Benzonase **Merck Millipore (EMD Millipore) Catalog #101656**

- 6 To each well, add 10 µL 500 millimolar (mM) DTT. Reseal with same mat. Place samples in incubator at 47 °C for 00:30:00

DTT **Merck MilliporeSigma (Sigma-Aldrich) Catalog #DTT-RO**

- 7 Remove plates from incubator and let cool to room temperature. Spin plates down for 00:00:30 at 1000 x g After plate has cooled, remove sealing mat and add 30 µL of 500 millimolar (mM) iodoacetamide. Place into totally dark environment (e.g. closed

drawer) for 01:00:00

⊗ Iodoacetamide **Merck MilliporeSigma (Sigma-Aldrich) Catalog #I1149**

⊗ Abgene™ 96 Well 1.2mL Polypropylene Deepwell Storage Plate **Thermo Fisher Scientific Catalog #AB0787**

Protifi Plate Digestion

- 8 Aliquot 50 µL of sample into new Thermo 1.2 mL plate (Waters plate works as well but is harder to pipette from). Add 5 µL of 12 % volume phosphoric acid. Add 300 µL Protifi Sample Binding Buffer:

90 % volume methanol

10 % volume triethylammonium bicarbonate (TEAB)

⊗ Methanol Optima™ LC/MS Grade Fisher Chemical **Fisher Scientific Catalog #A456-4**

pH 7.1

Mix each sample by pipetting up and down for 00:00:10 .

Expected result

You will often see a cloudy colloidal suspension after adding the binding buffer.

⊗ Triethylammonium bicarbonate buffer **Merck MilliporeSigma (Sigma-Aldrich) Catalog #T7408-100ML**

- 9 Add the mixture from step 7 to the Protifi S-trap 96-well plate. Place S-trap on top of Waters 96 well 2 mL plate. This will be waste plate. Use the positive pressure machine to press sample through. Our experience suggests that 6 psi on the main dial and 15 on the secondary control dial will push through a majority of samples. There will be clogging and this can be corrected by gently scraping the top of the well with a pipette tip.

⊗ Protifi S-trap 96-well plate **Contributed by users Catalog #C02-96well-1**

Equipment

Waters 96-well Positive Pressure Processor

NAME

Waters

BRAND

NA

SKU

https://www.waters.com/waters/en_US/Waters-Positive-Pressure-96-Processor/nav.htm?cid=10161512&locale=en_US

LINK

- 10 Wash samples with $\text{500 } \mu\text{L}$ fresh Protifi Binding Buffer 5 times. You may have a few clogs at this point as well, clear them as before. Be sure to empty waste plate as needed. After washes are done, place S-trap plate on fresh 1.2 mL Thermo plate.

Abgene™ 96 Well 1.2mL Polypropylene Deepwell Storage Plate **Thermo Fisher Scientific Catalog #AB0787**

- 11 To each well, add $\text{5 } \mu\text{g}$ of trypsin dissolved in $\text{125 } \mu\text{L}$ of $\text{50 millimolar (mM)}$ TEAB. Place Protifi S-trap lid back on plate (should be loose fitting). Place in incubator for 03:00:00 . After 02:00:00 have passed, check that digestion mixture has been taken up by wells. If it is still sitting on top, place 96 well plate and its collection plate into the positive pressure machine for approximately 00:00:05 and check if liquid drained into collection plate. If any liquid came out (it is normal that it does), place back into appropriate well and continue with digestion.

Triethylammonium bicarbonate buffer **Merck MilliporeSigma (Sigma-Aldrich) Catalog #T7408-100ML**

Promega trypsin **Promega Catalog #V5113**

- 12 After digestion, elute peptides using positive pressure. Once initial digestion volume has been eluted, add $\text{100 } \mu\text{L}$ of TEAB and use positive pressure to wash directly into previously eluted peptides. Repeat this with $\text{100 } \mu\text{L}$ of $\text{0.2 \% volume}$ formic acid (FA), then $\text{100 } \mu\text{L}$ of a mixture of $\text{50 \% volume}$ acetonitrile and $\text{0.2 \% volume}$ FA. This should be

approximately $\text{425 } \mu\text{L}$ of digested peptides and wash. Speedvac to dryness.

RPS or C18 cleanup

- 13 Resuspend the dry peptides in $\text{150 } \mu\text{L}$ of $\text{0.2 \% volume}$ FA. Pipetting up and down as well as washing well walls is critical in getting maximum peptide recovery. Spin plate at 3000 x g for 00:10:00 . Carefully avoiding any debris left in the well, move peptide suspension into fresh plate.
- 14 Consult owner of Assaymap Bravo to use Peptide Cleanup V2 app using either RPS or C18 tips. These tips have a capacity of approximately $\text{100 } \mu\text{g}$ but you will likely lose quite a bit of it during this step. Dry down samples in speedvac
- 15 Resuspend dried down peptides in $\text{30 } \mu\text{L}$ of $\text{0.2 \% volume}$ FA.
- 16 If samples will not be labeled (eg TMT, see below) use nanodrop to adjust concentration that is appropriate for your mass spectrometer (usually $\text{0.5 } \mu\text{g}$ to $\text{1 } \mu\text{g}$ is sufficient for nano-flow LC systems.

OPTIONAL - TMT labeling

- 17 From step 15, nanodrop samples and record concentration. If everything was properly done and you started with enough sample, each well should have upwards of $\text{40 } \mu\text{g}$ of unlabeled peptide. We will use $\text{20 } \mu\text{g}$ of this for TMT labeling. Resuspend each well at a concentration of $\text{0.5 } \mu\text{g}$ per $\text{1 } \mu\text{L}$. Transfer $\text{20 } \mu\text{g}$ of peptide from each well into a new plate. Dry down both plates. Leave your original plate dry and store in $\text{-20 } ^\circ\text{C}$.
- 18 From the concentrations obtained in [go to step #17](#), calculate the ratio of TMT reagent to peptide. Thermo suggests that you have at least 8:1 TMT to peptide, however YMMV. For the example below our ratio was approximately 6.5:1 TMT to peptide.

Note

Kuster paper showing TMT ratio as low as 1:1 if concentrations are kept at least 4ug/uL.:
<https://www.mcponline.org/content/early/2019/04/09/mcp.TIR119.001385>

- 19 Resuspend 20 µg plate in 50 µL of [IM] 50 millimolar (mM) Na-HEPES at 08.5 (should be around that pH already). Move peptide suspension into fresh Eppendorf 150 uL plate
Eppendorf twin.tec® PCR plate 96 LoBind skirted 150 µL PCR clean colorless
25 plates **Eppendorf Catalog #30129512**
- HEPES-Na **Merck MilliporeSigma (Sigma-Aldrich) Catalog #H7006-100G**
- 20 Take TMT kit out of freezer and let warm to room temperature for approximately 00:10:00 , do not open lids to avoid condensation . Spin down each reagent tube to collect residue on top on benchtop micro centrifuge. For each sample to be labeled with a specific channel, add 20 µL of acetonitrile (ACN). EXAMPLE: if you have a single 96 well plate and a TMT-11plex, and every sample in column 1 will be labeled with channel 126, add (n+1)*20 uL of ACN, where n is the number of samples in column 1. After each reagent has been resuspended, close lid and quickly vortex then wait 00:05:00 for reagent to completely dissolve, with another quick vortex 00:02:30 into 5 minute period . After reagent is dissolved, spin down and aliquot into fresh 96 well plate first row (up to TMT-11), you will use a multichannel in next step to redistribute into each sample.
TMT multiplex **Thermo Fisher Scientific Catalog #varies-by-kit**
- 21 With a multichannel pipette, carefully redistribute 20 µL of the appropriate TMT reagent into each well. Cover loosely with Axygen silicone cover to avoid ACN loss. Incubate for 01:00:00
Axygen™ AxyMats™ Sealing Mat for 96 Well PCR Microplates **Fisher Scientific Catalog #1222-024**
- 22 Quench reaction with 10 µL of [IM] 5 % volume hydroxylamine solution in

[M] 50 millimolar (mM) HEPES-Na. Incubate for 15 minutes at room temperature

- 23** Acidify each well down to approximately 2 with [M] 25 % volume formic acid. This should be done on a dummy sample with no peptides in it. In general this may be up to 15 μ L .
- 24** You now need to construct your ratio check samples. Each ratio check should have a total of 10 μ g peptide. This means that each channel needs to contribute equally to that amount so the total taken from each well will depend on what TMT kit is used. For example if a TMT-11 kit is used, each sample/channel would contribute $10 \text{ ug}/11 = 0.9 \text{ ug}$. Transfer appropriate amount from each sample/channel into its ratio check tube
- If you are doing a bridge channel, each bridge will need a total of 20 ug so make sure you calculate that too.
- 25** Resuspend sample in 10 μ L [M] 0.2 % volume FA and check concentration on nanodrop. Dilute to 0.5 ug/uL. Bottle up samples and shoot on mass spec. Quant ratios
- 26** Run resulting raw files through Proteome Discoverer 2.2. Calculate ratios from each channel using PSM quant values. Use these ratio values to adjust each channel on original plate for a 1:1 ratio. Compile new sample and reshoot.