FEB 24, 2020

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.basniede

Protocol Citation: Marda Jorgensen, Jerelyn Nick 2020. HuBMAP: Embedding Fixed Frozen OCT Samples.
protocols.io
<https://dx.doi.org/10.17504/protocols.io.basniede>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Dec 20, 2019

Last Modified: Apr 02, 2020

PROTOCOL integer ID:
31278

HuBMAP: Embedding Fixed Frozen OCT Samples

Marda Jorgensen¹, Jerelyn Nick¹

¹University of Florida

Human BioMolecular Atlas Program (HuBMAP) Method Development Community

Tech. support email: Jeff.spraggins@vanderbilt.edu

Marda Jorgensen

ABSTRACT

The purpose of this Standard Operating Procedure (SOP) is to outline procedures for the OCT embedding of HuBMAP frozen fixed specimens.

GUIDELINES

- Managers and supervisors - are responsible for making sure that technicians are properly trained and equipment and facility are maintained in good working order.
- Laboratory personnel - are responsible for reading and understanding this SOP and related documents and to perform these tasks in accordance with the SOPs.

MATERIALS

MATERIALS

✂ KimWipes **Fischer Scientific**

✂ Tissue-Tek® O.C.T. Compound, Sakura® Finetek **VWR International Catalog #25608-930**

✂ 16% Paraformaldehyde **Fisher Scientific Catalog #15710**

✂ D-Sucrose (Molecular Biology) Fisher BioReagents **Fisher Scientific Catalog #BP220-1**

✂ PBS Phosphate Buffered Saline 10X Solution Fisher BioReagents **Fisher Scientific Catalog #BP399-1**

✂ Tissue Tek Cryomold (25mmx20mmx5mm) **Contributed by users Catalog #25608-916**

✂ 2-Methylbutane **Fisher Scientific Catalog #03551-4**

✂ Ice / Dry Ice Bucket (EVA Foam) **Fisher Scientific Catalog #03-395-152**

STEP MATERIALS

✂ Tissue-Tek® O.C.T. Compound, Sakura® Finetek **VWR International Catalog #25608-930**

✂ PBS Phosphate Buffered Saline 10X Solution Fisher BioReagents **Fisher Scientific Catalog #BP399-1**

16% Paraformaldehyde

PBS 10x Solution

D-Sucrose

OCT

Tissue Tek Cryomold

Methylbutane

Dry Ice

Ice Bucket

SAFETY WARNINGS

- Use physical safety precautions when working with sharps (disposable blades).

BEFORE START INSTRUCTIONS

- Ensure you have proper scalpel blades, forceps, and your personal preference of gauzes/wipes.
- Embedding can be a messy process, to protect your clothes it is best to wear a lab coat or apron.
- Gloves are highly suggested to protect your fingers from the spectrum of hot and cold one encounters during the process.

Reagent Preparation

1h

1

Prepare 1x PBS

PBS is required to prepare reagents needed for this procedure. Dilute 10x PBS 1:10 in deionized water to make working 1x solution.

PBS Phosphate Buffered Saline 10X Solution Fisher BioReagents **Fisher Scientific Catalog**
#BP399-1

2

Prepare a 4% paraformaldehyde solution.

Safety information

Paraformaldehyde is toxic. Use gloves, wear a lab coat and work in a fume hood.

2.1

Add 60ml of 100mM PBS to a sample cup.

60 mL PBS

Note

Prepare containers to accommodate number and size of tissues using at least a 1:20 tissue to fixative volume ratio.

- 2.2 Open 2 -10mL ampules of 16% paraformaldehyde stock.
Add contents to the 1x PBS in the sample cup, invert to mix.

🧪 20 mL 16% Paraformaldehyde Stock

- 2.3 Label containers, solution expires one week after being made. Store at 4° C if not immediately used.

3 Prepare **30% sucrose** solution

- 3.1 Combine 300g Sucrose with 1 liter of 1X PBS. Add stir bar and mix on a stir plate until dissolved.

🧪 300 g sucrose

🧪 1 L 1x PBS

- 3.2 Store at 4° C in labeled container. Check for contamination prior to use, no expiration date.

Tissue Preparation Procedure

3d 8h

- 4 Collect tissue specimen from the designated common coordinate framework sites.
(See case processing SOP diagrams)

30m

Document

NAME

SOP Appendix for Spleen

CREATED BY

Marda Jorgensen

PREVIEW

Document

NAME

SOP Appendix for Thymus

CREATED BY

Marda Jorgensen

PREVIEW

Document

NAME

SOP Appendix for Lymph Node

CREATED BY

Marda Jorgensen

PREVIEW

- 5 Place tissue into pre-labelled cassettes maintaining orientation.

15m

- 6 Transfer the tissue into a 120mL specimen container, pre-filled with 80mL freshly prepared fixative (4% paraformaldehyde in PBS).

1d

Fix specimen for 24 hours at room temperature under mild agitation using a rocker.

🕒 24:00:00 In Fixative on Rocker | 🌡️ Room temperature

- 7 Drain fixative (collect as hazardous waste) and wash the tissue **three (3) times** for 10 minutes each in 1X PBS at a volume that generously covers. Invert several times during this process, or return to rocking platform.

1h

🕒 00:30:00

- 8 Infiltrate and cryoprotect the tissue with 30% sucrose.

2d

🌡️ 4 °C in Sucrose/PBS Mixture | 🕒 72:00:00

- 8.1 Combine equal volumes of 30% sucrose and 1x PBS to form 15% Sucrose. Replace PBS wash with 15% sucrose and place at 4° C for 8 hours

- 8.2 Drain 15% sucrose and replace with 30% sucrose. Equilibrate tissue 4° C for at least 48 hours. Tissue is stable in sucrose for at least one week.

Freeze the Blocks

30m

- 9 Prepare a pre-labeled Cryomold

1m

Equipment	
Cryomold®	NAME
Histology	TYPE
Tissue Tek®	BRAND
25608-916	SKU
https://us.vwr.com/store/product/4639407/tissue-tek-cryomold-molds-adapters-sakura-finetek	LINK
25mm x 20 mm x 5mm	SPECIFICATIONS

and fill it half way with OCT compound.

Tissue-Tek® O.C.T. Compound, Sakura® Finetek **VWR International Catalog #25608-930**

- 10

Remove the tissue from the cassette using foceps and quickly touch the tissue to a Kimwipe to remove external sucrose droplet from tissue surface.

1m
- 11

Place the tissue into the OCT-containing Cryomold, maintaining original tissue orientation.

1m
- 12

Using forceps, push the tissue lightly to the bottom of the Cryomold to secure it.

1m
- 13

Prepare dry ice/methylbutane slurry for freezing OCT blocks.

13.1 Place 1-2 inches of dry ice pellets into the bottom of an ice bucket or styrofoam box.

13.2 Add enough 2-methylbutane solution to cover the dry ice by roughly 5mm .

13.3 Place lid on freezing chamber and allow methylbutane to chill.
Chamber is ready when fog dissipates and bottom of bucket becomes visible.

14 Freeze the tissue in the Cryomold by resting it on the surface of the methylbutane slurry.
As the OCT inside the Cryomold begins to freeze, lightly push the tissue into the bottom of the mold one last time.

15 Add additional OCT to cover the tissue completely and fill the Cryomold.
Allow the tissue to equilibrate in the mold for ten (10) minutes.

20m

00:10:00 In Cryomold

16 When the OCT Cryomold is completely frozen and opaque, wrap the mold containing the tissue in a pre-labeled aluminum foil square, and store at -80° C in a freezer rack box.

Note

Enter block location in Freezer Log for future retrieval