VERSION 1

OCT 20, 2019

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.8htht6n

Protocol Citation: Jorge Fernandez Mendez 2019. Latex beads migration assay test. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.8htht6n>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Oct 20, 2019

Last Modified: Oct 20, 2019

PROTOCOL integer ID:
 28947

🌐 Latex beads migration assay test V.1

Jorge Fernandez Mendez¹

¹Universidad Complutense de Madrid

AEGIS - Madrid iGEM 2019

Jorge Fernandez Mendez
 Universidad Complutense de Madrid

ABSTRACT

The following protocol details how to test the migration of conjugated latex beads through different nitrocellulose membranes.

GUIDELINES

For preparation of sealed membranes we have used the protocol available in : dx.doi.org/10.17504/protocols.io.8hdht26.

MATERIALS

- Wax sealed nitrocellulose membranes
- BSA 0.2 % in PBS Buffer
- Conjugated latex beads Stocks at 1% wt in PBS-T (0.1 %) buffer.

BEFORE START INSTRUCTIONS

Cut the nitrocellulose previously to the desired size of the strip.

ddMembra Preparatin

- 1 Prepare two FF170HP strips and three FF80HP strips of 1cm wide x 4 cm long. Wax print the microfluidic membranes following the protocol mentioned in the guidelines section.
- 2 Block one FF170HP and two FF80HP membranes by immersion in 0.2 % BSA solution in PBS. Let the membranes dry for 1h at room temperature, and let them on a dissecator at 4°C overnight.

Migration test

- 3 Aspire 20 μ L of conjugated latex beads stock, and pipette them on the sample deposition area of the sealed membranes.

It's recommendable placing the strips with a briefly inclination degree, avoiding the sample to fall down through the membrane surface. (Placing the sample deposition region on the down region).
- 4 Wait 15 minutes until the liquid in the sample has migrated completely. Results can be directly visualized. Wait until the membranes have dried to manipulate them.