OCT 28, 2020

Long Read Viromics Amplification Library Preparation (VIRION 2)

In 1 collection

Marie Burris¹, Natalie Solonenko¹, Olivier Zablocki¹, Ben Temperton²

¹The Ohio State University; ²University of Exeter

Sullivan Lab

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.5yug7ww

Protocol Citation: Marie Burris, Natalie Solonenko, Olivier Zablocki, Ben Temperton 2020. Long Read Viromics Amplification Library Preparation (VIRION 2). **protocols.io** <https://dx.doi.org/10.17504/protocols.io.5yug7ww>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Jul 29, 2019

Last Modified: Oct 28, 2020

PROTOCOL integer ID:
26356

Marie Burris

GUIDELINES

Use DNA from "preparation of extracted DNA for long read library prep" as starting material for this protocol.

Use DNA LoBind tubes throughout this entire protocol (except for PCR tubes).

DNA LoBind Tubes **Eppendorf Catalog ##022431021**

Sample Concentration

1

Prepare 48 ul of sample to use as input for the next step. Sample should have between 1ng - 100 ng of DNA for reliable library success. See "Preparation of extracted DNA for long-read library prep" concerning preparation of DNA for this protocol.

DNA repair, End repair and dA tailing

2 Prepare reaction mix using the following, making enough master mix for the total number of samples you are working with.

- 3.5 ul NEB Ultra II End Repair/dA Tailing reaction buffer
- 3 ul NEB Ultra II End Repair/dA Tailing enzyme mix
- 3.5 ul NEB FFPE DNA repair buffer
- 2 ul NEB FFPE DNA enzyme mix

NEBNext Ultra II End Repair/dA-Tailing Module - 24 rxns **New England Biolabs Catalog #E7546S**

NEBNext FFPE DNA Repair Mix - 24 rxns **New England Biolabs Catalog #M6630S**

Note

We recommend making 0.2 reactions worth of extra master mix to account for pipetting error.

2.1 In a PCR tube, add 12 ul master mix to 48 ul DNA from step 1.

2.2 Using a thermal cycler, incubate at 25 C for 5 minutes and 65 C for 5 minutes.

25 °C	00:05:00
65 °C	00:05:00

2.3 Clean up using AMPure XP beads (1:1 sample:beads) and elute in 31ul nuclease-free water into a 1.5mL tube.

- See "Ampure Bead Clean up For HMW DNA" protocol.

- For final elution step, incubate at 55 °C 00:02:00

Ampure XP beads **Beckman Coulter Catalog #A63881**

2.4 Use 1ul to assess DNA concentration with Qubit.

Adapter ligation

3 Add the following to 30 ul DNA from previous step:

- 50 ul NEB Blunt/TA ligase
- 20 ul BCA (from Oxford Nanopore PCR Barcoding Expansion 1-12 kit)

NEB Blunt/TA Ligase Master Mix **Contributed by users Catalog #M0367**

PCR Barcoding Expansion 1-12 **Contributed by users Catalog #EXP-PBC001**

3.1 Incubate at room temperature for 10 minutes.

Room temperature 00:10:00

3.2 Clean up using AMPure XP beads (1:0.4 sample:beads) and elute in 15ul Nuclease-free water into a PCR tube.

- See "Ampure Bead Clean up For HMW DNA" protocol.
- For final elution step, incubate at 55 °C 00:02:00

3.3 Use 1ul to assess DNA concentration with Qubit.

PCR Amplification

- 4 Prepare reaction mix using the following from the LA TaKaRa Hot Start kit, making enough master mix for the total number of sample you are working with.
- 16 ul dNTPs
  - 10 ul 10x reaction buffer
  - 1 ul LA TaKaRa enzyme
  - 66 ul water

LA TaKaRa Hot Start **Takara Bio Inc. Catalog #RR042A**

Note

We recommend making 0.2 reactions worth of extra master mix to account for pipetting error.

- 4.1 Add 2 ul of your chosen barcode from Oxford Nanopore PCR Barcoding Expansion 1-12 kit to 5 ul of DNA from previous step.

Note

Be sure to use different barcodes for any samples that will be sequenced together.

- 4.2 Add 93 ul of master mix to the barcode - DNA mix

- 4.3 Use the following thermocycler conditions to amplify the library using minimum of 15 cycles.
- repeat steps 2-4 of this sub-step 15-25 times

- 1.) 94 °C 00:01:00
- 2.) 94 °C 00:00:30
- 3.) 62 °C 00:00:30
- 4.) 68 °C 00:16:00 for 20kb
- 5.) 72 °C 00:16:00 for 20kb

- 4.4 Clean up using AMPure XP beads (1:0.5 sample:beads) and elute in 20ul Nuclease-free water.

- See "Ampure Bead Clean up For HMW DNA" protocol.
- For final elution step, incubate at 55 °C 00:02:00

4.5 Check the concentration (we recommend Qubit) and purity (NanoDrop) of your DNA, and run on a Genomic DNA TapeStation to assess library size.

5 The amplified libraries should be used as input for the Oxford Nanopore 1D Genomic DNA by Ligation (SQK-LSK109) protocol, beginning with the "DNA repair and end-prep" step. Libraries with different barcodes can be pooled at your desired ratio before beginning. We recommend loading 10 - 100 fmol of DNA into the flow cell.

1D Genomic DNA by Ligation **Contributed by users Catalog #SQK-LSK109**