OCT 21, 2020

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.be6rjhd6

Protocol Citation: Eric Adams, Stephen Wandro, Julio Avelar-Barragan, Andrew Oliver, Katrine Whiteson 2020. Low Volume Methodology for Nextera DNA Flex Library Prep Kit (96 Samples). **protocols.io** <https://dx.doi.org/10.17504/protocols.io.be6rjhd6>

MANUSCRIPT CITATION: Adams, E. et al. Comparing Fecal, Saliva, and Chicha Microbiomes Between Mothers and Children in an Indigenous Ecuadorian Cohort. *bioRxiv* 2020.10.02.323097 (2020)
 doi:10.1101/2020.10.02.323097.

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it works for us in our lab.

Low Volume Methodology for Nextera DNA Flex Library Prep Kit (96 Samples)

In 1 collection

Eric Adams¹, Stephen Wandro¹, Julio Avelar-Barragan¹, Andrew Oliver¹, Katrine Whiteson¹

¹Department of Molecular Biology and Biochemistry, University of California, Irvine, Irvine, CA, United States

Eric Adams

DISCLAIMER

DISCLAIMER – FOR INFORMATIONAL PURPOSES ONLY; USE AT YOUR OWN RISK

The protocol content here is for informational purposes only and does not constitute legal, medical, clinical, or safety advice, or otherwise; content added to [protocols.io](#) is not peer reviewed and may not have undergone a formal approval of any kind. Information presented in this protocol should not substitute for independent professional judgment, advice, diagnosis, or treatment. Any action you take or refrain from taking using or relying upon the information presented here is strictly at your own risk. You agree that neither the Company nor any of the authors, contributors, administrators, or anyone else associated with [protocols.io](#), can be held responsible for your use of the information contained in or linked to this protocol or any of our Sites/Apps and Services.

ABSTRACT

This protocol presents a low volume methodology for the Nextera DNA Flex Library Prep Kit (96 Samples). This method increases the number of sequencing libraries which can be generated using each kit from 384 samples (4 x 96-wells) to 864 samples (9 x 96-wells). While other low-cost methods have been developed for this purpose, this protocol is a very straightforward method utilizing reduced reagent and sample volumes.

Update: The "Nextera DNA Flex Library Prep" kit has been renamed to "Illumina DNA Prep" with the appropriate indexes having been similarly renamed. While all reagents and steps remain identical, an updated version of this protocol may be published to account for any differences between the protocols.

Created: Apr 15, 2020

Last Modified: Oct 21, 2020

PROTOCOL integer ID:
35761

GUIDELINES

Primers used with the Kapa HiFi ReadyMix:

KAPA-PCR-F: AATGATACGGCGACCACCG*A

KAPA-PCR-R: CAAGCAGAAGACGGCATACG*A

Order these from IDT at 1umole scale with HPLC purification.

The * is a phosphothioate bond that prevents polymerases with 3'-5' proof-reading activity from chewing back the oligos

MATERIALS

MATERIALS

- ☒ Proteinase K **Contributed by users**
- ☒ Nuclease-free Water **Contributed by users**
- ☒ Kapa HiFi Hotstart ReadyMix (2x) **Kapa Biosystems Catalog #KK2612**
- ☒ Fresh 80% Ethanol **Contributed by users**
- ☒ Magnetic Stand-96 **Thermofisher Catalog #AM10027**
- ☒ Sterile reagent reservoirs **Contributed by users**
- ☒ Nextera DNA Flex Library Prep **Illumina, Inc. Catalog #20018705**
- ☒ Adhesive PCR Plate Foils **Thermo Fisher Catalog #AB0626**
- ☒ 0.2mL PCR Tube Strips, 8-Tube Strip; 120/Pk. **Thermo Fisher Catalog #E0030124286**
- ☒ 96-well PCR plates **Contributed by users**
- ☒ IDT for Illumina Nextera DNA Unique Dual Indexes **Illumina, Inc. Catalog #20027213**

BEFORE START INSTRUCTIONS

1. Enter and save the **TAGflex** tagmentation protocol on the thermal cyclers:
 - a. Enable the heated lid (to 100°C if the option is available)
 - b. 55°C for 15m followed by a hold at 10°C
2. Enter and save the **TAGstop** tagmentation stop protocol on the thermal cyclers:
 - a. Enable the heated lid (to 100°C if the option is available)
 - b. 37°C for 15m followed by a hold at 10°C
3. Enter and save the **flexPCR** protocol on the thermal cyclers:
 - a. 72°C for 3m
 - b. 98°C for 3m
 - c. 12 cycles of:
 - i. 98°C for 45s
 - ii. 62°C for 30s
 - iii. 72°C for 2m
 - d. 72°C for 1m
 - e. 4°C hold
4. Enter and save the **protK** protocol on the thermal cyclers:
 - a. 37°C for 30m
 - b. 68°C for 10m
 - c. 4°C hold

Preparation

- 1 Equilibrate the following reagents at Room temperature for 00:30:00
Bead-Linked Transposomes (**BLT**)
Tagmentation Buffer (**TB1**)
Tagment Stop Buffer (**TSB**)
Tagment Wash Buffer (**TWB**)
Sample Purification Beads (**SPB**)
- 2 Thaw the **Resuspension Buffer (RSB)** and bring to Room temperature then vortex to mix
- 3 Prepare a **proteinase K** solution at 300 µg/mL

Note

For a 1mL solution: add 15µL of 20mg/mL proteinase K to 985µL of nuclease-free water

4 Thaw **KAPA HiFi HotStart ReadyMix (2X)** 🌡️ On ice

5 Thaw the **i5 and i7 indexes** at 🌡️ Room temperature

Note

Index tubes: vortex and spin down briefly

Index plates: spin down at 🌀 1500 rpm to ensure no droplets remain on the plate cover

Index stocks should be diluted to [1M] 10 micromolar (μM) working stocks

6 Prepare a **Tagmentation Master Mix (TMM)**

TMM contains 1μL BLT and 1μL TB1 per reaction

Vortex BLT vigorously before use and ensure the beads are evenly resuspended

6.1 Make a 110X mix: 🧴 110 μL TB1 + 🧴 110 μL BLT

Vortex to mix

7 Prepare **PCR Master Mix (PCR MM)** 🌡️ On ice

PMM contains 2.75μL nuclease-free water, 0.5μL KAPA-PCR-F primer, 0.5μL KAPA-PCR-R primer, and 6.25μL KAPA HiFi HotStart ReadyMix (2X) per reaction

Note

See Guidelines section for KAPA primer design

KAPA primer stocks should be diluted to [1M] 10 micromolar (μM)

7.1 Make a 110X mix: 🧴 302.5 μL nuclease-free water + 🧴 55 μL KAPA-PCR-F +
🧴 55 μL KAPA-PCR-R + 🧴 687.5 μL KAPA HiFi HotStart ReadyMix (2X)

Vortex to mix and briefly spin down

8 Prepare a diluted **SPB Master Mix (SPB MM)**

🧪 54 μ L SPB + 🧪 48 μ L nuclease-free water

96-Well Tagmentation

9 Transfer at least 🧪 100 ng genomic DNA (up to 500ng) into each well of a 96-well PCR plate in **1-5 μ L**

10 Adjust the volume of each well to 🧪 5 μ L total volume using nuclease-free water

11 Load 🧪 27 μ L TMM into each tube of an 8-strip of PCR tubes

Vortex TMM thoroughly before use and ensure the beads remain evenly suspended while being aliquoted into the 96-well plate

12 Add 🧪 2 μ L TMM to each well using an 8-channel pipette

Thoroughly mix by gentle pipetting

Note

If beads are adhered to the top or side of the 96-well plate, briefly centrifuge and fully resuspend the bead pellet by pipetting until thoroughly mixed

13 Seal the plate with a PCR plate cover, place in a thermal cycler, and run the **TAGflex** program

Note

It is especially important to be able to remove the plate seal as easily as possible to prevent cross contamination

Proceed **immediately** to the next steps upon completion of the TAGflex cycle

Post Tagmentation Cleanup

- 14 Load 15 μL TSB per tube in an 8-strip of PCR tubes
- 15 Gently remove the plate seal and add 1 μL TSB into each tagmentation reaction using an 8-channel pipette

Mix by gently pipetting the entire volume, ensuring the beads are fully resuspend
- 16 Seal the plate, place in a thermal cycler, and run the **TAGstop** program
- 17 Remove the seal and place the plate on a 96-well magnetic plate stand for 00:03:00 or until solution is clear
- 18 Carefully remove the supernatant using an 8-channel pipette without disturbing the beads
- 19 Load 6 mL TWB into a sterile trough to pipette from
- 20 Remove the plate from the magnetic stand and add 20 μL TWB to each well using an 8-channel pipette

Mix by gently pipetting (slowly, to minimize foaming) until beads are fully resuspended
- 21 Place the plate on the magnetic stand for 00:03:00 or until solution is clear

22 Carefully remove the supernatant using an 8-channel pipette without disturbing the beads

23 Repeat steps 20-22 one more time for a total of 2 washes

24 Remove the plate from the magnetic stand and add 20 µL TWB to each well

Gently pipette until beads are fully resuspended

25 Seal the plate and place on the magnetic stand to incubate until needed in the next section

Note

Keeping the pellet in TWB helps prevent over-drying of the beads

Amplify Tagmented DNA

26 Load 135 µL PCR MM per tube into an 8-strip of PCR tubes (store On ice until needed)

27 Carefully remove the TWB supernatant from the samples while on the magnetic stand

Note

Any remaining foam on the well walls should not adversely affect the library

28 Remove the plate from the magnetic stand and proceed immediately to the next step to prevent excessive drying of the beads

- 29 Add 10 μL PCR MM to each sample and pipette the mix to ensure the beads are thoroughly resuspended

Note

Pipette with moderate force as the beads can be difficult to fully resuspend

- 30 Seal the plate and spin down briefly up to 1000 rpm

- 31 Add 2.5 μL of an equimolar mix of each i7 and i5 index combination to their respective wells

Note

Individual index tubes: 1.25 μL i7 index (N7xx) + 1.25 μL i5 index (N5xx)

Pre-mixed index plate: Transfer 2.5 μL of each index combination using an 8-channel pipette

- 32 Pipette to mix a minimum of 10 times, then seal the plate and briefly spin up to 1000 rpm

- 33 Place the plate in a thermal cycler and run the **flexPCR** program

- 34 Remove the plate from the thermal cycler and spin down for 00:01:00 at 280 x g

- 35 Load 35 μL of [M] 300 $\mu\text{g}/\text{mL}$ proteinase K per tube into an 8-strip of PCR tubes

36 Remove the plate seal and add 2.5 µL proteinase K to each PCR reaction using an 8-channel pipette

Mix the wells by pipetting a 10uL volume at least ten times

37 Seal the plate, place in a thermal cycler, and run the **protK** program

38 If stopping, keep the plate sealed and store at 4°C for up to 3 days

Otherwise, continue with the next section

Post-PCR Library Clean Up

39 Remove the seal and place the plate on the magnetic stand for 00:05:00 or until the supernatant is clear

40 Using an 8-channel pipette, transfer 2 µL PCR supernatant from each well into an 8-strip of PCR tubes

41 From the 8-strip of PCR tubes, transfer all samples to a single 1.5mL Eppendorf tube

Note

Each tube in the strip should contain ~24µL of pooled sample, yielding ~192µL of pooled libraries

42 Vortex and briefly spin down to mix the pooled libraries evenly

- 43 Transfer a 45 µL aliquot of the pooled libraries to a new 1.5mL Eppendorf tube
- 44 Vortex and invert **SPB MM** multiple times to ensure full resuspension
- 45 Add 85 µL SPB MM to the pooled library aliquot
- Pipette until thoroughly mixed
- Note

Complete mixing is critical to proper size distribution of libraries
- 46 Incubate at Room temperature for 00:05:00
- 47 Place the Eppendorf tube on a magnetic stand for 00:05:00 or until the supernatant is clear
- 48 Transfer 120 µL supernatant into a new 1.5mL tube without disturbing the beads
- 49 Vortex and invert the **SPB** (undiluted stock) until thoroughly resuspended
- 50 Add 14.4 µL SPB (undiluted stock) to the new 1.5mL tube containing the supernatant

- 51 Pipette a 120µL volume until thoroughly mixed
- 52 Incubate at Room temperature for 00:05:00
- 53 Place the Eppendorf tube on a magnetic stand for 00:05:00 or until clear
- 54 Remove and discard the supernatant without disturbing the beads
- 55 With the tube on the magnetic stand, add 200 µL 80% ethanol without mixing and incubate for 30s
- Note**

Add enough 80% ethanol so that the beads are entirely submerged
- 56 Pipette to remove the ethanol without disturbing the beads
- 57 Repeat steps 55-56 one more time for a total of 2 washes
- 58 Remove any excess liquid from the tube using a pipette without disturbing the beads

- 59 Air-dry beads on the magnetic stand for 00:05:00
- 60 Warm 35 μ L RSB at 50 °C to increase final library yield
- 61 Remove the 1.5mL tube from the magnetic stand
- 62 Add 32 μ L RSB (warm) to the beads
Pipette mix until thoroughly resuspended
- 63 Incubate on the bench at Room temperature for 00:02:00
- 64 Place the 1.5mL tube back on the magnetic stand for 00:02:00 or until clear
- 65 Transfer 30 μ L supernatant into a new 1.5mL Eppendorf tube
- 66 Let the tube with the eluted library sit at 50 °C for 00:05:00 to ensure complete dissolution of the library

67 Quantify the library using a Qubit fluorometer

Determine fragment size distribution using a Bioanalyzer