OCT 23, 2019

Microplastic SEM Sample Prep

Forked from [SEM Sample Prep](#)

Melissa B Duhaime¹, Rachel Cable¹

¹University of Michigan

Duhaime Lab

ELA Microplastics Team

Melissa B Duhaime

University of Michigan

OPEN ACCESS

DOI:

dx.doi.org/10.17504/protocols.io.uy8exzw

Protocol Citation: Melissa B Duhaime, Rachel Cable 2019. Microplastic SEM Sample Prep.

protocols.io

<https://dx.doi.org/10.17504/protocols.io.uy8exzw>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Oct 24, 2018

Last Modified: Oct 23, 2019

PROTOCOL integer ID:
17152

Sample Dehydration

- 1 Fill a petri dish with enough PBS to submerge your microplastic sample. Rinse the plastic in the PBS bath to remove loosely associated debris.

- 2 Next, create similar baths of ethanol or HMDS, as indicated below.
Submerge each piece of plastic in the bath, let incubate in solution for 00:15:00

Washes:

1. 25% ETOH
2. 50% ETOH
3. 70% ETOH
4. 95% ETOH
5. 100% ETOH
6. 100% ETOH
7. 2 ETOH: 1 HMDS
8. 1 ETOH: 1 HMDS
9. 1 HMDS

Drying

- 3 Air-dry the dehydrated samples overnight in desiccator underneath a fume hood.
12:00:00 overnight

Affix

- 4 Affix plastic to double-side carbon tape on aluminum stud.
Draw a strap of carbon paint from stud base to top of plastic. Dry overnight in desiccator.
12:00:00 overnight

Microscopy

- 5 The next day, sputter-coat plastic sample with heavy metal.
- 6 Image sample under scanning electron microscope as soon as possible following sputter-coating.

Note

Samples keep for a maximum of 2 weeks after prep.