SEP 08, 2020

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.bbnmimc6

External link:
<http://lab.loman.net/protocols/>

Protocol Citation: Josh Quick 2020. One-pot native barcoding of amplicons. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.bbnmimc6>

MANUSCRIPT CITATION: Fernández-Rodríguez A, Casas I, Culebras E, Morilla E, Cohen MC, Alberola J, COVID-19 and post-mortem microbiological studies. Spanish Journal of Legal Medicine doi: [10.1016/j.remle.2020.05.007](https://doi.org/10.1016/j.remle.2020.05.007)

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Jan 22, 2020

One-pot native barcoding of amplicons

Josh Quick¹

¹University of Birmingham

Josh Quick

ABSTRACT

This is a 'one-pot ligation' protocol for Oxford Nanopore native barcoded ligation libraries using shearing.

ATTACHMENTS

[One-pot native barcoding protocol \(1\).pdf](#)

GUIDELINES

Scope:

There has been no evidence of a reduction of performance compared to standard libraries, yet it can be made faster by using the Ultra II ligation module which is compatible with the Ultra II end repair/dA-tailing module removing a clean-up step.

The FFPE DNA repair step is optional. If you have the time, we recommend using the double incubation times in **bold**. If you are in a hurry, the times in *italic* are a good compromise between speed and efficiency.

Required:

g-TUBEs (optional)
 SQK-LSK108 1D ligation kit
 Native barcoding kit
 Ultra II End Repair/dA-Tailing Module
 Ultra II Ligation Module
 FFPE DNA Repair Mix (optional)
 Ampure XP beads
 80% ethanol
 EB (10 mM Tris-HCl pH 8)

PROTOCOL integer ID:
32173

See SDS (Safety Data Sheet) for safety warnings and hazards.

- 1 Set up the following reaction for each sample:

Component	Volume
DNA amplicons	5 μ L
Nuclease-free water	7.5 μ L
Ultra II End Prep Reaction Buffer	1.75 μ L
Ultra II End Prep Enzyme Mix	0.75 μ L
Total	15 μ L

- 2 Incubate at room temperature for 00:10:00
Incubate at 65 °C for 00:05:00
Incubate on ice for 00:01:00

- 3 Add the following directly to the previous reactions:

Component	Volume
NBXX barcode	2.5 μ L
Ultra II Ligation Master Mix	17.5 μ L
Ligation Enhancer	0.5 μ L
Total	35.5 μ L

Note

Use one native barcode from the EXP-NBD104 (1-12) or EXP-NBD114 (13-24) per sample.
Use from 6 to 24 barcodes in a library, any fewer and there will be insufficient total material to achieve good yields.

- 4 Incubate at room temperature for 00:15:00
Incubate at 70 °C for 00:10:00
Incubate on ice for 00:01:00

Note

The 70°C incubation is to inactivate the DNA ligase to prevent barcode cross-ligation when reactions are pooled in the next step.

- 5 Pool all barcoded fragments together into a new 1.5 ml Eppendorf tube.

Protocol

NAME

Amplicon clean-up using SPRI beads

CREATED BY
Josh Quick

PREVIEW

- 5.1 Vortex SPRI beads thoroughly to ensure they are well resuspended, the solution should be a homogenous brown colour.

Agencourt AMPure XP **Beckman Coulter Catalog #A63880**

- 5.2 Add an equal volume (1:1) of SPRI beads to the sample tube and mix gently by either flicking or pipetting. For example add 50 µL SPRI beads to a 50 µL reaction.

- 5.3 Pulse centrifuge to collect all liquid at the bottom of the tube.

- 5.4 Incubate for 00:05:00 at room temperature.

- 5.5 Place on magnetic rack and incubate for 00:02:00 or until the beads have pelleted and the supernatant is completely clear.

5.6 Carefully remove and discard the supernatant, being careful not to touch the bead pellet.

5.7 Add 200 µL of room-temperature 70 % volume ethanol to the pellet.

5.8 Carefully remove and discard ethanol, being careful not to touch the bead pellet.

5.9 go to step #5.7 and repeat ethanol wash.

5.10 Pulse centrifuge to collect all liquid at the bottom of the tube and carefully remove as much residual ethanol as possible using a P10 pipette.

5.11 With the tube lid open incubate for 00:01:00 or until the pellet loses it's shine (if the pellet dries completely it will crack and become difficult to resuspend).

5.12 Resuspend pellet in 30 µL Elution Buffer (EB), mix gently by either flicking or pipetting and incubate for 00:02:00 .

Elution Buffer (EB) **Qiagen Catalog #19086**

5.13 Place on magnet and transfer sample to a clean 1.5mL Eppendorf tube ensuring no beads are transferred into this tube.

5.14 Quantify 1 μ L product using the Quantus Fluorometer using the ONE dsDNA assay.

QuantiFluor(R) ONE dsDNA System, 100rxn **Promega Catalog #E4871**

Equipment	
Quantus	NAME
Fluorometer	TYPE
Promega	BRAND
E6150	SKU
https://www.promega.co.uk/products/microplate-readers-fluorometers-luminometers/fluorometers/quantus-fluorometer	LINK

6 Quantify the barcoded amplicon pools using the Quantus Fluorometer using the ONE dsDNA assay.

Protocol

NAME

DNA quantification using the Quantus fluorometer

CREATED BY

Josh Quick

PREVIEW

6.1 Remove Lambda DNA 400 ng/ μ L standard from the freezer and leave on ice to thaw. Remove ONE dsDNA dye solution from the fridge and allow to come to room temperature.

QuantiFluor(R) ONE dsDNA System, 500rxn **Promega Catalog #E4870**

- 6.2** Set up two 0.5 mL tubes for the calibration and label them 'Blank' and 'Standard'
- 6.3** Add 200 μ L ONE dsDNA Dye solution to each tube.
- 6.4** Mix the Lambda DNA standard 400 ng/ μ L standard by pipetting then add 1 μ L to one of the standard tube.
- 6.5** Mix each sample vigorously by vortexing for 00:00:05 and pulse centrifuge to collect the liquid.
- 6.6** Allow both tubes to incubate at room temperature for 00:02:00 before proceeding.
- 6.7** Selection 'Calibrate' then 'ONE DNA' then place the blank sample in the reader then select 'Read Blank'. Now place the standard in the reader and select 'Read Std'.
- 6.8** Set up the required number of 0.5 mL tubes for the number of DNA samples to be quantified.
- Note**

Use only thin-wall, clear, 0.5mL PCR tubes such as Axygen #PCR-05-C
- 6.9** Label the tubes on the lids, avoid marking the sides of the tube as this could interfere with the sample reading.

6.10 Add 199 μL ONE dsDNA dye solution to each tube.

6.11 Add 1 μL of each user sample to the appropriate tube.

Note

Use a P2 pipette for highest accuracy.

6.12 Mix each sample vigorously by vortexing for 00:00:05 and pulse centrifuge to collect the liquid.

6.13 Allow all tubes to incubate at room temperature for 00:02:00 before proceeding.

6.14 On the Home screen of the Quantus Fluorometer, select `Protocol`, then select `ONE DNA` as the assay type.

Note

If you have already performed a calibration for the selected assay you can continue, there is no need to perform repeat calibrations when using ONE DNA pre diluted dye solution. If you want to use the previous calibration, skip to step 11. Otherwise, continue with step 9.

6.15 On the home screen navigate to 'Sample Volume' and set it to 1 μL then 'Units' and set it to ng/ μL .

6.16 Load the first sample into the reader and close the lid. The sample concentration is

automatically read when you close the lid.

6.17 Repeat step 16 until all samples have been read.

6.18 The value displayed on the screen is the dsDNA concentration in ng/μL, carefully record all results in a spreadsheet or laboratory notebook.

7 Set up the following AMII adapter ligation reaction:

Component	Volume
Barcoded amplicon pools	30 μL
NEBNext Quick Ligation Reaction Buffer (5X)	10 μL
AMII adapter mix	5 μL
Quick T4 DNA Ligase	5 μL
Total	50 μL

Note

The input of barcoded amplicon pools will depend on the number of barcoded pools and should be between 40 ng (8 barcodes) and 160 ng (24 barcodes).

8 Incubate at room temperature for 00:15:00

9 Add 50 μL (1:1) of SPRI beads to the sample tube and mix gently by either flicking or pipetting.

Note

Vortex SPRI beads thoroughly before use to ensure they are well resuspended, the solution should be a homogenous brown colour.

- 10 Pulse centrifuge to collect all liquid at the bottom of the tube.
- 11 Incubate for 00:05:00 at room temperature.
- 12 Place on magnetic rack and incubate for 00:02:00 or until the beads have pelleted and the supernatant is completely clear.
- 13 Carefully remove and discard the supernatant, being careful not to touch the bead pellet.
- 14 Add 200 µL SFB and resuspend beads completely by pipette mixing.

Note

SFB will remove excess adapter without damaging the adapter-protein complexes. Do not use 70% ethanol as in early clean-ups.

- 15 Pulse centrifuge to collect all liquid at the bottom of the tube.

- 16** Remove supernatant and discard.
- 17** Repeat steps 14-16 to perform a second SFB wash.

- 18** Pulse centrifuge and remove any residual SFB.

Note

You do not need to allow to air dry with SFB washes.

- 19** Add 15 µL EB and resuspend beads by pipette mixing.

- 20** Incubate at room temperature for 00:02:00 .

- 21** Place on magnetic rack.

- 22** Transfer final library to a new 1.5mL Eppendorf tube.