SEP 08, 2020

Slot/Dot Blot protocol.

beldenwj¹

¹Rutgers University

XPRIIZE Rapid Covid Testing

beldenwj

DISCLAIMER

DISCLAIMER – FOR INFORMATIONAL PURPOSES ONLY; USE AT YOUR OWN RISK

The protocol content here is for informational purposes only and does not constitute legal, medical, clinical, or safety advice, or otherwise; content added to [protocols.io](https://dx.doi.org/10.17504/protocols.io.bk3mkyk6) is not peer reviewed and may not have undergone a formal approval of any kind. Information presented in this protocol should not substitute for independent professional judgment, advice, diagnosis, or treatment. Any action you take or refrain from taking using or relying upon the information presented here is strictly at your own risk. You agree that neither the Company nor any of the authors, contributors, administrators, or anyone else associated with [protocols.io](https://dx.doi.org/10.17504/protocols.io.bk3mkyk6), can be held responsible for your use of the information contained in or linked to this protocol or any of our Sites/Apps and Services.

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.bk3mkyk6

Protocol Citation: beldenwj 2020. Slot/Dot Blot protocol.. [protocols.io](https://dx.doi.org/10.17504/protocols.io.bk3mkyk6)
<https://dx.doi.org/10.17504/protocols.io.bk3mkyk6>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](https://creativecommons.org/licenses/by/4.0/), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol in our lab and it is a great time saver.

Created: Sep 08, 2020

Last Modified: Sep 08, 2020

PROTOCOL integer ID:
41805

ABSTRACT

This is a simple slot/dot blot protocol for detecting antigen on a membrane. Using the method outline here, one can achieve results in under 90 min because it eliminates the need for running a gel, transferring the protein in a transfer apparatus, blocking, secondary antibody incubation and the washes between primary and secondary antibodies.

Set up Slot/Dot blot apparatus

5m

1. Assemble 3 sheets of cut GB003 blotting paper pre-wetted with transfer buffer (25 mM Tris,

5m

200 mM Glycine, 20% methanol) to the dot blot apparatus.

2. Pre-wet a cut sheet of PVDF in 100% methanol for 30 sec and then wash the PDVF in transfer buffer for 2 min.

3. Lay the PVDF membrane on the GB003 blotting paper and seal the slot/Dot blot apparatus.

Add sample

5m

- 2
 1. Apply individual (or pooled) saliva or processed nasal swabs to the slot/dot blot apparatus making note of sample location.
 2. Turn on the vacuum source so the sample get drawn onto the membrane.
 3. Disassemble the slot/dot blot apparatus and place the membrane back in 100 % methanol.
 4. Air dry the membrane for 5 minutes.

5m

Incubate with HRP-conjugated antibody, wash and develop

1h

- 3
 1. Once the membrane is dry, add it to 10 ml of TBST (20 mM Tris, 150 mM NaCl, 0.1% Triton X-100, pH 7.5) (or PBST) containing HRP-conjugated antibody and incubate with gentle shaking 40 minutes.
 2. Wash the blot 4 times for 5 minutes with 10 ml of TBST
 3. Add ECL or colorimetric substrate, develop for 2-5 min, and image blot.
 4. Record the results.

1h