MAY 14, 2019

UC Davis - Blood Pressure/Heart Rate by Telemetry

Lynette Bower¹

¹University of California, Davis

Mouse Metabolic Phenotyping Centers

Tech. support email: info@mmpc.org

Lili Liang

OPEN ACCESS

DOI:

dx.doi.org/10.17504/protocols.io.yevfte6

External link:

<https://mmpc.org/shared/document.aspx?id=131&docType=Protocol>

Protocol Citation: Lynette Bower 2019. UC Davis - Blood Pressure/Heart Rate by Telemetry . **protocols.io** <https://dx.doi.org/10.17504/protocols.io.yevfte6>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's working

Created: Feb 21, 2019

Last Modified: May 14, 2019

PROTOCOL integer ID:
20661

ABSTRACT

Summary:

Utilizing this telemetry we have the ability to simultaneously measure a pressure signal and biopotential signal (ECG, EEG, EMG) in a single mouse. This can provide a more comprehensive physiological assessment of cardiovascular function, the presence of any damage to the heart, the effects of drugs, specific genes or interventions used to regulate the heart.

Modified from: Butz et al. *Physiol Genomics*. 2001 Mar 8;5(2):89-97.

Keywords: Telemetry, blood pressure, heart rate, mouse

MATERIALS

MATERIALS

- ✘ Isoflurane **Baxter**
- ✘ Ophthalmic Ointment **Butler Catalog #007312**
- ✘ Electric shaver **Contributed by users**
- ✘ Sterile Saline (0.9% NaCl) **Contributed by users**
- ✘ Surgical Scrub **Operand Catalog #82-217**
- ✘ Sterile Field Drape **Contributed by users**
- ✘ Heating Pad **Gaymar Catalog #TP22B**
- ✘ sterile cotton swabs **Puritan Catalog #806-WC**
- ✘ 5-0 suture **Medical Resources Catalog #L00797B**
- ✘ 4-0 suture **George Tiemann Catalog #160-1215**
- ✘ Surgical scissors **Contributed by users**
- ✘ Mouse Surgery Instruments **Data Scientific International Catalog #276-0034-001**
- ✘ Hemostat **Contributed by users**
- ✘ Vannas spring micro-scissors **Fine Science Tools Catalog #15610-08**
- ✘ Vessel cannulation forceps **Fine Science Tools Catalog #00608-11**
- ✘ Blunt dissecting **Fine Science Tools Catalog #14018-14**
- ✘ 25-gauge needles **Monoject Catalog #20046**
- ✘ 1cc syringe **Monoject Catalog #501400**
- ✘ 3cc syringe **Monoject Catalog #513918**
- ✘ veterinary adhesive **Contributed by users**
- ✘ Buprenex (buprenorphine hydrochloride) **Contributed by users**
- ✘ Gel leading micro-pipette tip **Contributed by users**
- ✘ HD-X11 transmitter **Data Scientific International**
- ✘ Dataquest ART data acquisition system **Data Scientific International**

Note:

Baxter [RRID:SCR_003974](https://rrid.nlm.nih.gov/rrid/SCR_003974)

SAFETY WARNINGS

WARNING

All blood components and biological materials should be handled as potentially hazardous. Follow universal precautions established by CDC when handling and disposing of infectious agents.

1 Surgical Preparation

1. Administer the appropriate concentration of Isoflurane anesthesia so animal is in deep anesthetic plane. Isoflurane will be administered throughout the duration of the procedure.
2. Remove the body hair from all intended incision sites by shaving.
3. Surgically scrub the incision sites.
4. Once the animal is prepped for surgery and a sterile field has been established, the surgery is ready to begin.

2 Carotid Cannulation (*Tissue hydration should be maintained throughout the procedure by irrigations with saline (0.9% sodium chloride) to the tissues as needed.*)

1. Position the animal in dorsal recumbency on the surgery table with the head closest to the surgeon.
Provide supplemental warmth during the surgery.
2. Loosely tape the animal's forelimbs to the table.
3. Establish a sterile surgical field and apply sterile draping material.
4. Using small surgical scissors make a 1.5 cm midline incision through the skin on the neck.
5. Carefully separate the mandibular glands using sterile cotton tip applicators.
6. Carefully retract the left mandibular gland using an elastic stay hook and tape the hook to the surgery table.
7. Locate the carotid artery along the left side of the trachea using sterile cotton tip applicators. Using fine tipped, curved forceps, carefully isolate the vessel from the surrounding tissue, making sure not to disturb the vagus nerve.
8. Pass three pieces of 5-0 or 6-0 non-absorbable suture underneath the isolated artery section. The furthest cranial suture will be used to permanently ligate the carotid artery while the suture closer to the heart will be used to temporarily occlude blood flow to allow for placement of the catheter. The middle suture will be used to hold the catheter in place after cannulation of the artery.
9. Position the ligation suture just proximal to the bifurcation of the interior and exterior carotid arteries. Tie a secure knot around the artery to ligate the vessel and tape the suture tails to the surgery table.

10. Make a loose knot in both the occlusion suture and the middle suture and position them as close to the clavicle as possible thus isolating at least 6 mm of the artery.
11. After making a loose knot in both pieces of suture, clamp a hemostat on one of the tails of the middle suture.
12. Remove the transmitter from the sterile package and transfer it to the sterile field. Do not handle the transmitter by grasping the catheter. This may cause damage to the catheter or the pressure sensor.
13. Turn the AM radio on and carefully remove the tip cover. Removal of the tip cover should be done by alternating gentle traction and release. Take care to prevent gel loss due to compression of the catheter or sudden release of the tip cover. Always examine the catheter under high magnification before implantation for gel loss or bubbles. If there is gel loss or bubbles, the catheter will need to be re-gelled.
14. Prepare a catheter introducer by bending the beveled tip of a 25-gauge syringe needle. Hold the syringe needle with the beveled side facing up. Grasp just the beveled area of the needle with a needle holder and bend the tip downward to an angle of approximately 90°. The syringe needle may be placed onto a 1 cc syringe to be used as a handle to hold onto the needle and allow for a clear view of the surgical area.
15. Gently apply tension to the occlusion suture closest to the clavicle using a hemostat. This will elevate the artery and occlude blood flow. Caution: Excessive tension can damage the artery.
16. Grasp the tip of the catheter just distal to the thin-walled section using a Vessel Cannulation Forceps.
17. Using the 25-gauge needle as an introducer, pierce the artery just proximal to the ligation suture and insert the catheter upstream toward the aorta. Once the catheter is inserted into the vessel, withdraw the catheter introducer.
18. Advance the catheter into the artery until it reaches the occlusion suture.
19. Position the middle suture around the artery and catheter. Secure the catheter by pulling the loose suture tail to tighten the knot. Releasing the catheter before it is secured may cause it to come out of the vessel.
20. Once the catheter is secured, release the tension on the occlusion suture and advance the catheter beyond the suture into the thoracic cavity.
21. Continue to advance the catheter so that at least 2 mm of the sensing region of the catheter is positioned in the aortic arch.

22. Tighten the occlusion suture and the middle suture around the artery and catheter to seal the artery wall around the catheter stem.
23. Release the tension on the ligation suture and tie the loose ends around the catheter stem to help anchor it in place.
24. Trim all suture tails as short as possible. A very small drop of Vetbond tissue adhesive may be applied only to the suture knots to ensure that they remain secure. A gel-loading micropipette tip is recommended to dispense the tissue adhesive.

3 Subcutaneous Device Placement

1. Insert small surgical scissors into the incision and form a subcutaneous pocket by using blunt dissection. If the pocket is not made large enough, the skin will be stretched too tightly across the contours of the transmitter and pressure necrosis may result.
2. Once the pocket is formed, irrigate the pocket with a 3 cc syringe filled with warm, sterile saline. The syringe should easily slide down the full length of the pocket. Insert the HD-X11 transmitter against the body.
3. After inserting the transmitter, a small drop of Vetbond tissue adhesive can be used to secure the transmitter in place. Draw the Vetbond up in a 1 cc syringe and insert the syringe into the pocket with the needle removed to dispense.
4. Secure the catheter to the surrounding tissue using a few small drops of Vetbond tissue adhesive. This will prevent the catheter from being accidentally incorporated into the closing suture. A gel-loading micropipette tip is recommended to dispense the tissue adhesive.

4 ECG Lead Placement with Subcutaneous Device Placement

Once the transmitter is in place the leads will be tunneled subcutaneously to the desired ECG electrode locations.

1. Shorten the lead material to the appropriate length with a pair of scissors. A small amount of lead may be coiled under the skin to account for growth of the animal and re-use of the transmitter.
2. Cut around the silicone tubing at the tip of the lead using a sharp sterile scalpel blade and remove approximately 1 cm of the silicone tubing to expose the stainless steel wire.
3. Make tip covers by using the excess silicone tubing. After the silicone tubing is cut (Step 2), pull it to the end of the lead but do not remove it from the lead. Tie a piece of 5-0 or 6-0 non-absorbable suture around the silicone tubing and lead to secure the tubing in place. Cut off the excess silicone tubing that extends past the lead as this is not needed.

4. Place another suture around the silicone tubing just proximal to the exposed portion of the wire. This will inhibit fluids from migrating along the interior of the lead.
5. Ensure Steps 2 through 4 are completed for each lead.
6. Grasp the terminal end of the positive lead (red tubing) with a small hemostat and tunnel it subcutaneously from the neck incision to the left caudal rib region. This lead is positioned approximately 1 cm to the left of the xyphoid process.
7. Release the lead and withdraw the hemostat leaving the lead in place under the skin.
8. Grasp the terminal end of the negative lead (clear tubing) with a small hemostat and tunnel it subcutaneously from the neck incision to the right pectoral muscle.
9. Release the lead and withdraw the hemostat leaving the lead in place under the skin.
10. Ensure both leads are lying flat against the muscle for the whole length of the lead. This will avoid irritation of the tissue.
11. Secure both leads near the neck incision by placing a stay suture through the chest muscle and around the leads using 5-0 or 6-0 non-absorbable suture.
12. Close the skin incision using 5-0 or 6-0 absorbable or non-absorbable suture. Once closed, seal the incision with Vetbond tissue adhesive.

13. Surgical Recovery

14. Discontinue surgical anesthesia.
15. Maintain supplemental warmth throughout the anesthetic recovery.
16. The analgesic Buprenex is administered post-surgically.
17. Monitor animal closely for the return of normal postures and behaviors.