VERSION 2

AUG 09, 2019

OPEN ACCESS

DOI:
dx.doi.org/10.17504/protocols.io.56wg9fe

External link:
<https://mmpc.org/shared/document.aspx?id=116&docType=Protocol>

Protocol Citation: Lori Haapanen 2019. UC Davis - Luminex/Multiplex.
protocols.io
<https://dx.doi.org/10.17504/protocols.io.56wg9fe>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
 We use this protocol and it's working

Created: Aug 05, 2019

Last Modified: Aug 09, 2019

PROTOCOL integer ID:
 26550

UC Davis - Luminex/Multiplex V.2

Lori Haapanen¹

¹University of California, Davis

Mouse Metabolic Phenotyping Centers
 Tech. support email: info@mmpc.org

Lili Liang

ABSTRACT

Summary:

This core will provide services for quantification and comparison in animal models for hormone measurements; kidney function analytes; lipid metabolism analytes; liver function analytes; miscellaneous protein analytes; and immune function including cytokines/chemokines. The Luminex assay enables the quantification of all or any combination of analytes for which there are assay beads in tissue/cell lysate, tissue culture supernatant samples and plasma/serum. For example, cytokines and chemokines are peptides, which act as regulators in normal and pathological conditions, effecting interactions between cells as well as regulating processes occurring in the extracellular environment.

MATERIALS

MATERIALS

- ⊗ Human Cytokine/Chemokine standard – lyophilized **Millipore Catalog #MXH8060 OR MXH8060-2**
- ⊗ Human Cytokine Quality Controls 1 and 2 - lyophilized **Millipore Catalog #MHX6060 OR MXH6060-2**
- ⊗ Serum Matrix- lyophilized **Millipore Catalog #MXHSM**
- ⊗ Set of one 96-well filter plate with 2 plate sealers **Millipore Catalog #MX-PLATE**
- ⊗ 96 well plate stand **Millipore Catalog #MX-STAND**
- ⊗ Assay Buffer 30 mls **Millipore Catalog #L-AB**
- ⊗ 10 x Wash buffer 30 mls **Millipore Catalog #L-WB**
- ⊗ Human Cytokine Detection Antibodies 3.2 mls **Millipore Catalog #MXH1060-1,2,3,or 4**
- ⊗ Streptavidin-Phycoerythrin 3.2 mls **Millipore Catalog #*L-SAPE 9,3,10 OR 11**

Keywords: Luminex assay

⊗	Bead Diluent 3.5 mls Millipore Catalog #LBD
⊗	Mixing Bottle – 1 bottle Millipore
⊗	Human Cytokine/Chemokine Antibody Immobilized Premixed beads. Example given premixed 14-plex beads Millipore Catalog #MXHPMX14
⊗	Sheath Fluid- Bio-plex BioRad Sciences Catalog #171-000055
⊗	Calibrator Beads-Bio-plex 10 mls BioRad Sciences Catalog #171-203060
⊗	Validation Beads – Bio-plex BioRad Sciences Catalog #171-203001
⊗	Adjustable Pipettes with tips 25-1000 uls Rainin
⊗	Multichannel Pipettes 5 25 50 200 uls Rainin
⊗	Reagent Reservoirs Fisher Scientific
⊗	Polypropylene Microfuge Tubes Contributed by users
⊗	Aluminum Foil Contributed by users
⊗	Rubber Bands Contributed by users
⊗	Absorbent Pads or paper towels Contributed by users
⊗	Laboratory Vortex Mixer Contributed by users
⊗	Sonicator- Ultrasonic Cleaner or equivalent Branson Catalog #Model B200 or equivalent
⊗	Titer Plate Shaker Lab-Line Instrument Catalog #Model 4625 or equivalent
⊗	Vacuum Manifold Filtration Unit Millipore Catalog #MSVMHTS00 or equivalent
⊗	Bio-Plex- 200 (or Luminex 200 by Luminex Corporation) BioRad Sciences Catalog #Bio-Plex 200 System
⊗	Vacuum Pump for use with Vacuum Manifold Millipore Catalog #WP6111560 or equivalent

*L-SAPE 9,3,10 OR 11 depending on detection antibody

Note:

Bio-Rad Laboratories, [RRID:SCR_008426](#)

Fisher Scientific, [RRID:SCR_008452](#)

Reagent Preparation:

1. Preparation of antibody – Immobilized beads

- For individual beads, sonicate each antibody-bead vial for 30 seconds.
- For pre-mixed beads, sonicate each bottle for 30 seconds.
- Vortex each antibody-bead vial for one minute.
- For pre-mixed beads, vortex bottle for one minute.
- For individual beads, add 60 ul from each individual antibody-bead vial to the Mixing Bottle and bring final volume to 3.0 ml with bead diluent.
- Vortex the mixed beads/bead diluent well.

2. Preparation of Quality Controls

- a. Before use, reconstitute Quality Control 1 with 250 µl of deionized water.
- b. Before use, reconstitute Quality Control 2 with 250 µl of deionized water.
- c. Invert Quality Control 1 and Quality Control 2 vials several times.
- d. Vortex gently Quality Control 1 and Quality Control 2 vials.
- e. Allow both vials to sit for 10 minutes at room temperature.
- f. Transfer Quality Control 1 and Quality Control 2 contents to appropriately labeled polypropylene microfuge tubes.

3. Preparation of Wash Buffer

- a. Bring the 10X Wash Buffer to room temperature.
- b. Dilute 30 ml of 10X Wash Buffer with 270 ml of deionized water.
- c. Wash Buffer should be room temperature before use.
- d. Wash Buffer can be stored at 2-8 degrees C for up to one month.

4. Preparation of Serum Matrix (required for serum or plasma samples only).

- a. Add 1.0 ml of deionized water to the bottle containing lyophilized Serum Matrix.
- b. Mix well.
- c. Allow Serum Matrix to sit 10 minutes for complete reconstitution.

5. Preparation of Human Cytokine Standard

- a. Reconstitute the Human Cytokine Standard with 250 µl of deionized water.
- b. Reconstituted standard concentration will be 10,000 pg/ml.
- c. Invert the vial several times to mix.
- d. Vortex the vial for 10 seconds.
- e. Allow the vial to sit for 5-10 minutes at room temperature.
- f. Transfer contents to an appropriately labeled polypropylene microfuge tube.
- g. The vial should be at room temperature before use.

6. Preparation of Working Standards

- a. Label five polypropylene microfuge tubes, 2000, 400, 80, 16, and 3.2 pg/ml.
- b. Transfer 200 µl of Assay Buffer to each of the five tubes.

Prepare serial dilutions of standards.

♣ Transfer 50 µl of the 10,000 pg/ml tube to the 2000 pg/ml tube.

♣ Mix the tube gently.

♣ Transfer 50 µl of the 2,000 pg/ml tube to the 400 pg/ml tube.

♣ Mix the tube gently.

- ♣ Transfer 50 ul of the 400 pg/ml tube to the 80 pg/ml tube.
- ♣ Mix the tube gently.
- ♣ Transfer 50 ul of the 80 pg/ml tube to the 16 pg/ml tube.
- ♣ Mix the tube gently.
- ♣ Transfer 50 ul of the 16 pg/ml tube to the 3.2 pg/ml tube.
- ♣ Mix the tube gently.

7. Vortex all Reagents before adding to plate.

SAFETY WARNINGS

WARNING:

All blood components and biological materials should be handled as potentially hazardous. Follow universal precautions established by CDC and OSHA when handling and disposing of infectious agents.

Sodium azide or Proclin has been added to some reagents as a preservative. When disposing, flush with a large volume of water to prevent azide build up.

BEFORE START INSTRUCTIONS

IMPORTANT: All plasma, serum, tissue supernatants must be centrifuged for 10 minutes at 12,000 rpms to clarify the biological fluid. Avoid multiple freeze thaws >2. All reagents must be prepared prior to step one and be at room temperature, beads must be sonicated and vortexed, standards and QC controls reconstituted and after 10 minutes and transferred to a polypropylene tube. Always place filter plate on the plate stand except when blotting post wash. Thorough blotting post wash and pre-incubation is critical to avoid leakage due to capillary action. During the incubation step, the filter plate must be covered with a plate sealer and wrapped in foil due to light sensitivity of the beads. Never invert the plate. Vacuum suction <100mmHg.

- 1 Pre-wet the filter plate with 200 ul assay buffer, agitate, incubate for 10 minutes RT and vacuum.

- 2 Add 25 ul of standards, controls, assay buffer, samples, matrix serum and beads to appropriate wells on the filter plate.
- 3 Place filter plate on plate stand, seal, wrap in foil and incubate overnight while agitating on a Titer Plate Shaker at 4 degrees C (16-18 hours).
- 4 Remove fluid from the filter plate by vacuum and wash. Bolt well.
- 5 Add 25 ul of detection antibody to each well, place filter plate on plate stand, seal, wrap in foil, agitate on a Titer Plate Shaker for 1 hour at RT.
- 6 Without removing detection antibody, add 25 ul of Streptavidin- Phycoerythrin to each well. Place filter plate on plate stand, seal, wrap in foil, agitate on the Titer Plate Shaker. Incubate for 30 mins RT.
- 7 Remove the fluid by vacuum and wash the plate. Bolt well.
- 8 Add 150 uls of Sheath Fluid to each well, place on plate stand, seal, wrap in foil, agitate on the Titer Plate Shaker at RT for 5 minutes.
- 9 Set up protocol on the Bio-Plex 200: add analytes and regions, standards, quality controls and sample dilutions to Bio-Plex 6.0 Manager software.

- 10** Run plate on Bio-Plex (Luminex) 200.
- 11** Save and analyze the median fluorescent intensity data using a 5-parameter logistic or spline curve fitting method for calculating cytokine/chemokines concentrations in samples in pg/ml.