

Jun 24, 2019

Version 2

## Standard method for microCT-based additive manufacturing quality control 5: witness specimen analysis V.2

DOI

[dx.doi.org/10.17504/protocols.io.4njgvcn](https://dx.doi.org/10.17504/protocols.io.4njgvcn)

Anton Du Plessis<sup>1</sup>

<sup>1</sup>University of Stellenbosch



Anton Du Plessis

### Create & collaborate more with a free account

Edit and publish protocols, collaborate in communities, share insights through comments, and track progress with run records.

Create free account

OPEN ACCESS



DOI: <https://dx.doi.org/10.17504/protocols.io.4njgvcn>

External link: <https://www.liebertpub.com/doi/10.1089/3dp.2018.0060>

**Protocol Citation:** Anton Du Plessis 2019. Standard method for microCT-based additive manufacturing quality control 5: witness specimen analysis. **protocols.io** <https://dx.doi.org/10.17504/protocols.io.4njgvcn>

**Manuscript citation:**

A du Plessis, I Yadroistava, SG le Roux, I Yadroitsev, 'X-ray microcomputed tomography in additive manufacturing: a review of the current technology and applications', 3D printing and additive manufacturing. <http://doi.org/10.1089/3dp.2018.0060>

**License:** This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](#), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

**Protocol status:** Working

**We use this protocol and it's working**

**Created:** June 24, 2019

**Last Modified:** June 24, 2019

**Protocol Integer ID:** 25003

**Keywords:** x-ray tomography, microCT, additive manufacturing, quality control, witness specimen, specimen analysis microct, additive manufacturing quality control, based additive manufacturing quality control, standard method for microct, standard geometry witness specimen, porosity information from the smaller part, such defects during the building process, parts for potential defect, porosity information, layered defect, such as excessive porosity, excessive porosity, building process, microct, acceptability of the entire build, analysis procedure, powder levelling in individual layer, powder levelling, potential defect, such defect, entire build

## Abstract

MicroCT is a well known technique and is often used for non-destructive analysis of parts produced by additive manufacturing. This is especially useful to inspect the parts for potential defects such as excessive porosity or layered defects due to imperfect powder levelling in individual layers. While various online monitoring methods are under development, there is currently not yet any accepted method to identify such defects during the building process. Post-production microCT of the entire part allows for the identification of such errors, but its limitation is the resolution which depends on part size. Hence a large part may have small but important porosities which may be missed by microCT. This can be overcome by using a witness specimen built in the same process, and analysing this smaller sample at a high resolution. The porosity information from the smaller part can be used to evaluate the acceptability of the entire build. The workflow presented here serves to standardize this process: with a simple process, a standard geometry witness specimen and hence standardized scan and analysis procedures. A layered stop-start flaw is shown in the witness specimen to demonstrate the ability to detect this type of flaw.

## Attachments



[Method for standard ...](#)

975KB



[05 Bracket witness s...](#)

10.6MB



[05 Bracket porosity ...](#)

18.8MB



[witness specimen.mp4](#)

26.9MB

## Troubleshooting

