

Oct 17, 2019 Version 1

Copy of Fabrication of Microneedle Patches V.1

DOI

dx.doi.org/10.17504/protocols.io.8cdhss6

Stephania Konstantinidi¹, Hana Samet¹

¹iGEM EPFL

iGEM EPFL



Dana Mozaffari

OPEN  ACCESS



DOI: dx.doi.org/10.17504/protocols.io.8cdhss6

External link: <https://2019.igem.org/Team:EPFL/Microneedles>

Protocol Citation: Stephania Konstantinidi, Hana Samet 2019. Copy of Fabrication of Microneedle Patches. **protocols.io**
<https://dx.doi.org/10.17504/protocols.io.8cdhss6>

License: This is an open access protocol distributed under the terms of the [Creative Commons Attribution License](https://creativecommons.org/licenses/by/4.0/), which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working

We use this protocol and it's working

Created: October 17, 2019

Last Modified: October 17, 2019

Protocol Integer ID: 28773


Keywords: Microneedles




Abstract

The goal is to create a microneedle. patch, which, by applying it on a leaf, will extract amplification-ready DNA. All MN patches used for DNA extraction were fabricated using polydimethylsiloxane molds. These molds were fabricated by laser ablation, and the dimension of each mold is approximately 10 mm × 10 mm, which has 15 × 15 arrays of microneedle conical cavities. The height of each cavity is 800 μm, and the diameters of the tip and base are 10 and 300 μm, respectively.

Mold preparation

- 1 Clean the polydimethylsiloxane molds.
- 1.1 Heat deionised water to 100 degrees Celsius  100 °C using a becher.
- 1.2 Put the mold(s) into the water and stir softly.
- 1.3 Remove the molds and let them dry in a chemical hood for 1-2 hours.

A solutionPVA SPVA SolutionP

- 2 Prepare the PVA solution
- 2.1 Heat 28g of deionised water to 110 degrees Celsius  110 °C .
- 2.2 Add 4g of poly(vinyl alcohol) (30– 70 kDa, 10 wt %) powder and stir until transparent.

Microneedle Fabrication

- 3 Fabricate the Microneedles
- 3.1 Stick the molds on the bottom of an adequate recipient using double-sided tape.
- 3.2 Add 1.5 mL of PVA solution on top of the mold.
- 3.3 Centrifuge at 4000 rpm for 20 minutes at 40 degrees Celsius.



3.4 Let the microneedles dry under a chemical hood overnight.

3.5 Remove the microneedles from the molds.

Use Microneedles !

4 The microneedles are ready for use.