


Jul 28, 2020

🌐 Direct wastewater RNA extraction via the "Milk of Silica (MoS)" method - A companion method to "Sewage, Salt, Silica and SARS-CoV-2 (4S)"



DOI

<https://dx.doi.org/10.17504/protocols.io.biwfkfbn>

Oscar Whitney¹, Basem Al-Shayeb², Alex Crits-Cristoph³, Mira Chaplin⁴, Vinson Fan¹, Hannah Greenwald⁴, Adrian Hinkle⁴, Rose Kantor⁴, Lauren Kennedy⁴, Anna Maurer¹, Robert Tjian⁵, Kara L. Nelson⁶, UC Berkeley Wastewater-based epidemiology consortium⁶

¹University of California, Berkeley, Tjian & Darzacq laboratory;

²University of California, Berkeley, Banfield & Doudna laboratory;

³University of California, Berkeley, Banfield laboratory; ⁴University of California, Berkeley, Nelson laboratory;

⁵University of California, Berkeley, HHMI; ⁶University of California, Berkeley

Coronavirus Method De...



Oscar N Whitney

University of California, Berkeley, Tjian & Darzacq Laborato...

Create & collaborate more with a free account

Edit and publish protocols, collaborate in communities, share insights through comments, and track progress with run records.

Create free account

OPEN  ACCESS



DOI: <https://dx.doi.org/10.17504/protocols.io.biwfkfbn>

Protocol Citation: Oscar Whitney, Basem Al-Shayeb, Alex Crits-Cristoph, Mira Chaplin, Vinson Fan, Hannah Greenwald, Adrian Hinkle, Rose Kantor, Lauren Kennedy, Anna Maurer, Robert Tjian, Kara L. Nelson, UC Berkeley Wastewater-based epidemiology consortium 2020. Direct wastewater RNA extraction via the "Milk of Silica (MoS)" method - A companion method to "Sewage, Salt, Silica and SARS-CoV-2 (4S)". **protocols.io** <https://dx.doi.org/10.17504/protocols.io.biwfkfbn>

License: This is an open access protocol distributed under the terms of the **Creative Commons Attribution License**, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working

We use this protocol in our laboratory to routinely isolate RNA from wastewater samples

Created: July 23, 2020

Last Modified: July 28, 2020

Protocol Integer ID: 39591

Keywords: SARS-CoV-2, COVID19, Wastewater-based epidemiology, Direct capture, RNA extraction, direct wastewater rna extraction, rna from wastewater, dry silica powder as an rna, extract rna, rna extraction, handling raw wastewater sample, raw wastewater sample, rna, using dry silica powder, wastewater, silica, silica spin column, extraction, sewage,

Abstract

The following protocol describes the "4S" (**Sewage, Salt, Silica and SARS-CoV-2**) workflow applied to using dry silica powder as an RNA-binding matrix instead of silica spin columns. This offers an even more economical alternative, requiring only centrifugation to extract RNA from wastewater. This procedure is intended to be carried out in a BSL2+ laboratory space, with precautions when handling raw wastewater samples.




Image Attribution

Figures created with BioRender.com

Guidelines

DISCLAIMER – FOR INFORMATIONAL PURPOSES ONLY; USE AT YOUR OWN RISK

The protocol content here is for informational purposes only and does not constitute legal, medical, clinical, or safety advice, or otherwise; content added to [protocols.io](https://www.protocols.io) is not peer reviewed and may not have undergone a formal approval of any kind. Information presented in this protocol should not substitute for independent professional judgment, advice, diagnosis, or treatment. Any action you take or refrain from taking using or relying upon the information presented here is strictly at your own risk. You agree that neither the Company nor any of the authors, contributors, administrators, or anyone else associated with [protocols.io](https://www.protocols.io), can be held responsible for your use of the information contained in or linked to this protocol or any of our Sites/Apps and Services.

Materials

MATERIALS

✕ Tris

✕ EDTA

✕ Sodium Chloride **Catalog #PubChem CID: 5234**

✕ Sodium acetate **Merck Millipore (EMD Millipore) Catalog #1.06268.1000**

✕ Centrifuge

✕ TE buffer **Thermo Fisher Scientific**

✕ Ethanol

✕ Isopropanol **Merck Millipore (EMD Millipore) Catalog #109634**

✕ Silicon dioxide ~99% 0.5-10 μm (approx. 80% between 1-5 μm) **Merck MilliporeSigma (Sigma-Aldrich) Catalog #SIGMA S5631**

STEP MATERIALS

✕ Durapore® Membrane Filter 5.0 μm **Merck MilliporeSigma (Sigma-Aldrich) Catalog #SVLP04700**

✕ Swinnex Filter Holder **Merck MilliporeSigma (Sigma-Aldrich) Catalog #SX0004700**

✕ Magnetic Funnel 300mL 47mm **Pall Catalog #4242**

✕ Silicon dioxide ~99% 0.5-10 μm (approx. 80% between 1-5 μm) **Merck MilliporeSigma (Sigma-Aldrich) Catalog #SIGMA S5631**

✕ Bovilis Coronavirus Calf Vaccine **Merck Animal Health Catalog #16445**

✕ Isopropanol **Merck Millipore (EMD Millipore) Catalog #109634**

✕ Sodium acetate **Merck Millipore (EMD Millipore) Catalog #1.06268.1000**

Protocol materials

 Sodium acetate **Merck Millipore (EMD Millipore) Catalog #1.06268.1000**

 Ethanol

 Tris

 Swinnex Filter Holder **Merck MilliporeSigma (Sigma-Aldrich) Catalog #SX0004700**

 Silicon dioxide ~99% 0.5-10 μm (approx. 80% between 1-5 μm) **Merck MilliporeSigma (Sigma-Aldrich) Catalog #SIGMA S5631**

 Isopropanol **Merck Millipore (EMD Millipore) Catalog #109634**

 Durapore® Membrane Filter 5.0 μm **Merck MilliporeSigma (Sigma-Aldrich) Catalog #SVLP04700**

 Centrifuge

 TE buffer **Thermo Fisher Scientific**

 EDTA

 Magnetic Funnel 300mL 47mm **Pall Catalog #4242**

 Bovilis Coronavirus Calf Vaccine **Merck Animal Health Catalog #16445**

 Sodium Chloride **Catalog #PubChem CID: 5234**

Troubleshooting

Safety warnings

 Wastewater is intrinsically hazardous, so we advise handling wastewater samples in a biosafety cabinet.

Before start

We developed this alternate procedure to allow the purification of wastewater RNA without access to a vacuum source or silica spin column. This companion method to "4S" enables highly efficient and extremely economical extraction of SARS-CoV-2 RNA from wastewater, but is more time and labor consuming. Using this procedure at the University of California Berkeley, we have captured and quantified SARS-CoV-2 and pepper mild mottle virus (PMMoV) present in a variety of San Francisco Bay Area raw wastewater influent samples and samples collected upstream of wastewater treatment plants. Results may vary depending on wastewater sample type and laboratory setting.

This procedure relies on centrifugation. In our laboratory setting, this procedure yields pure Wastewater RNA in approximately 6 hours.

In our laboratory, this purification method enables the detection of SARS-CoV-2 N and E gene RNA as well as PMMoV RNA via RT-qPCR probe-mediated detection. Depending on sample origin, we are able to recover an average of 25.7 ng RNA/mL of purified wastewater sample (min = 13.1 ng/mL, max = 58.2 ng/mL).

Preparing RNA wash buffers

- 1 Prepare 1 L each of two wash buffers - Wash buffer #1 (4S-WB1) and #2 (4S-WB2), for later use during cleanup of RNA bound to silica particles.

Prepare a "Milk of Silica" suspension of dry silica.

1.1 4S-WB1 composition:

Reagent	Original molarity/%	Final molarity/%	Volume per liter of buffer
NaCl	5 M	1.5 M	300 mL
Ethanol	100%	20%	200 mL
TRIS pH 7.2	1 M	10 mM	10 mL
Pure water (MilliQ or distilled)	NA	NA	490 mL

Add 490 mL water to sterile bottle

Add 300 mL of 5 Molarity (M) NaCl

Add 200 mL of 100 % volume Ethanol

Add 10 mL of 1 Molarity (M) pH 7.2 TRIS

Agitate to fully mix buffer solution

1.2 4S-WB2 composition:

Reagent	Original molarity/%	Final molarity/%	Volume per liter of buffer
NaCl	5 M	100 mM	20mL
Ethanol	100%	80%	800mL
TRIS pH 7.2	1 M	10 mM	10mL
Pure water (MilliQ or distilled)	NA	NA	170mL

Add 170 mL water to sterile bottle

Add 20 mL of 5 Molarity (M) NaCl


Add 800 mL of 100 % volume Ethanol

Add 10 mL of 1 Molarity (M) pH 7.2 TRIS

Agitate to fully mix buffer solution

- 1.3 Prepare a "Milk of Silica" silica suspension by resuspending 5 grams of silicon dioxide powder in  5 mL of pure water. Scale "Milk of Silica" suspension volume by number of wastewater samples (5mL/sample).

 Silicon dioxide ~99% 0.5-10 μm (approx. 80% between 1-5 μm) **Merck MilliporeSigma (Sigma-Aldrich) Catalog #SIGMA S5631**



"Milk of Silica" suspension (1g silicon dioxide/mL water)

Sample preparation, RNA preservation and particle lysis

- 2 Obtain a  40 mL wastewater sample in a sterile sample collection tube. Maintain at  4 °C during transport to the lab.

Note

Sodium chloride and TE buffer (Go to step 4) can be added to sample immediately after collection. Our unpublished analysis demonstrates that Sodium chloride & TE buffer preserve RNA present in wastewater.

- 3 Spike a known volume and titer of bovine coronavirus (bCoV) into the wastewater sample as a recovery efficiency control. Agitate sample to fully mix bCoV with the wastewater sample. Agitate sample to fully mix bCoV or other spiked-in controls with the wastewater sample.

 Bovilis Coronavirus Calf Vaccine **Merck Animal Health Catalog #16445**

Note

Other recovery controls can be used instead of bCoV. Some candidates include Phi6 bacteriophage and coronavirus OC43. In addition, purified RNAs can be used to quantify the extraction efficiency of "free RNA".

- 4 Add  9.5 g of sodium chloride to  40 mL wastewater sample.
 Make  7.2 TE buffer ( 1 Molarity (M) TRIS,  100 millimolar (mM) EDTA).
 Add  400 µL of TE buffer to  40 mL wastewater sample.

Note

Here, NaCl lyses lipid-protein envelopes, denatures proteins and disrupts RNA-protein interactions. EDTA inhibits the enzymatic degradation of RNA by RNases present in wastewater and TRIS provides optimal buffering conditions for nucleic acids.

- 4.1 Agitate sample until all NaCl dissolves in the wastewater. Vortex or shake sample for  00:00:30 to promote lysis.



Raw wastewater containing NaCl, TRIS & EDTA.

- 5 (OPTIONAL) Heat inactivate sample at $70\text{ }^{\circ}\text{C}$ for 00:30:00 . Our unpublished analyses have shown that this step will not affect SARS-CoV-2 RNA enrichment and detection.
- 6 Filter the sample through a 5-um PVDF filter via syringe filtration or funnel top vacuum.





Syringe filter setup: Wastewater is filtered through a 47-mm reusable filter membrane holder.

⊗ Durapore® Membrane Filter 5.0 μm Merck MilliporeSigma (Sigma-Aldrich) Catalog #SVLP04700

⊗ Swinnex Filter Holder Merck MilliporeSigma (Sigma-Aldrich) Catalog #SX0004700

⊗ Magnetic Funnel 300mL 47mm Pall Catalog #4242



Wastewater filtering through a 5-um PVDF filter in a Pall filter holder.

Direct RNA extraction via addition of silica slurry (RNA Binding, Washing, Eluting)

- 7 Aliquot 40 mL filtrate into two 20 mL aliquots. Add 20 mL of 70 % volume ethanol to each 20 mL sample filtrate aliquot.



Filtered sample before ethanol addition. Filtrate should be semi-clear.

7.1 Agitate sample to mix ethanol and wastewater lysate.

8 Resuspend "Milk of Silica" suspension by inverting the slurry 10 times. Add  2.5 mL of the 1g/mL "Milk of Silica" slurry to each aliquot containing  40 mL of wastewater lysate with ethanol.

8.1 Invert tube with lysate & silica 10 times to mix. Incubate mixture at room temperature for  00:10:00 .

Note

In this step, the silica particles bind RNA present in the processed wastewater sample.

8.2 Centrifuge tubes containing silica & bound RNA at  4000 x g, 4°C, 00:05:00 . The silica will form a firm pellet at the bottom of the tube. Remove the tubes from the centrifuge and decant and discard the supernatant.

Note

Here, the silica & bound RNA is precipitated to the bottom of the tube, separating it from the wastewater matrix.

9 Add  20 mL of 4S Wash buffer #1 (4S-WB1) to each silica pellet. Agitate or vortex tubes until silica is resuspended and appears milky.

9.1 Merge the two aliquot containing  20 mL 4S-WB1 and silica suspension by pouring the silica suspension from one tube into the other.

9.2 Centrifuge tubes containing silica, bound RNA and 4S-WB1 at  4000 x g, 4°C, 00:05:00 . The silica will form a firm pellet at the bottom of the tube.

Remove the tubes from the centrifuge and decant and discard the supernatant.

10 Add  40 mL of 4S Wash buffer #2 (4S-WB2) to the silica pellet. Agitate or vortex tubes until silica is resuspended and appears milky.

10.1 Centrifuge tubes containing silica, bound RNA and 4S-WB2  4000 x g, 4°C, 00:05:00 . The silica will form a firm pellet at the bottom of the tube. Remove the tubes from the centrifuge and decant and discard the supernatant.

10.2 Add  40 mL of 4S Wash buffer #2 (4S-WB2) to the silica pellet. Agitate or vortex tubes until silica is resuspended and appears milky.

10.3 Centrifuge tubes containing silica, bound RNA and 4S-WB2  4000 x g, 4°C, 00:05:00 . The silica will form a firm pellet at the bottom of the tube. Remove the tubes from the centrifuge and decant and discard the supernatant.

10.4 Vacuum aspirate any excess 4S-WB2 or allow tubes to incubate at room temperature for  00:10:00 to evaporate excess 4S-WB2.

11 Resuspend silica & RNA pellet in  20 mL of pure water (DNase and RNase-free) pre-warmed to  37 °C . Vortex, agitate or pipette silica until fully resuspended. Allow silica & water suspension to incubate for  00:10:00 .

Note

Here, water elutes RNA from the silica particulate. The sample RNA is now present in the aqueous phase.

11.1 Centrifuge tubes containing silica & eluted RNA  4000 x g, 37°C, 00:05:00 . The silica will form a firm pellet at the bottom of the tube and the RNA will be present in the aqueous phase. Pipette or decant the aqueous supernatant into a sterile conical bottom centrifugation-compatible (4000xg) tube for further concentration.

Note

This step separates the free, eluted RNA from the silica binding matrix, allowing downstream RNA concentration.

Concentration of eluted RNA (Isopropanol precipitation)

12 Add  20 mL of [M] 100 % volume Isopropanol and  4 mL of [M] 3 Molarity (M)  5.2 sodium acetate to the eluted RNA. Invert tube 10 times to mix solution and incubate mixture at room temperature for  00:10:00 .

 Isopropanol **Merck Millipore (EMD Millipore) Catalog #109634**

 Sodium acetate **Merck Millipore (EMD Millipore) Catalog #1.06268.1000**

Note


Isopropanol and sodium acetate alongisde centrifugation precipitate the eluted RNA from the 20mL aqueous matrix.

12.1 Centrifuge sample at  4000 x g, 4°C, 01:00:00 . A semi-translucent nucleic acid pellet will form at the bottom of the conical tube.


Note

Depending on sample type and source, the pellet may be brown or grey, as shown in the image in step 12.2

12.2 Carefully decant and discard the excess isopropanol & water from the nucleic acid pellet.



Side view of pellet after removal of isopropanol, water and sodium acetate mixture



Top view of pellet after removal of isopropanol, water and sodium acetate mixture

- 13 Wash pellet with ethanol by adding 40 mL [M] 75 \% volume Ethanol to the nucleic acid pellet containing tube. Invert, vortex or agitate until the pellet loosens from the bottom of the tube and fully contacts the ethanol.

Note

Depending on sample type and origin, the pellet may fracture or remain intact during ethanol washing.

- 13.1 Re-precipitate nucleic acid pellet by centrifuging the sample at 4000 x g , $\text{4}^\circ\text{C}$, 00:30:00 . After centrifugation, the nucleic acid pellet becomes

visible at the bottom of the conical tube.

13.2 Carefully decant and discard as much supernatant [M] 75 % volume Ethanol as possible from the nucleic acid pellet. Add  1 mL of [M] 70 % volume Ethanol to the nucleic acid pellet.

13.3 Using a pipette, resuspend the pellet in the  1 mL of [M] 75 % volume Ethanol. Transfer the pellet and ethanol mixture to a 1.5mL microcentrifuge tube.

Note

To facilitate pellet transfer, use sterile scissors to cut the opening of 1 mL pipette tips, allowing easier aspiration and transfer of the nucleic acid pellet.

14 After pellet transfer, centrifuge the microcentrifuge tube at  5000 rpm, 4°C, 00:05:00 . The nucleic acid pellet will form at the bottom and side of the microcentrifuge tube.

14.1 Carefully pipette-aspirate the supernatant [M] 70 % volume Ethanol from the nucleic acid pellet.

Note

Use pipette tips with a small opening to remove excess ethanol without aspirating the pellet.

14.2 Open the lid of the microcentrifuge tube and incubate the tube at  37 °C for  00:10:00 .

Note

This allows excess ethanol to evaporate, yielding ethanol-free RNA.

14.3 Resuspend the nucleic acid pellet in  200 µL of pure water or TE buffer. Vortex or pipette-mix the resuspended RNA to facilitate resuspension.



Note

It is possible for residual silica particles to remain in the final eluted RNA. In this case, briefly centrifuge the resuspended RNA and transfer the silica-free supernatant to a new sterile 1.5mL microfuge tube.

Storage

- 15 The eluted RNA is now ready for downstream analysis. Store RNA at $4\text{ }^{\circ}\text{C}$ for same-day use or freeze at $-80\text{ }^{\circ}\text{C}$ for later use and storage.