

Oct 08, 2020

 fastGRO

 In 1 collection

DOI

dx.doi.org/10.17504/protocols.io.bbmngik3w



Elisa Barbieri¹, Connor Hill^{1,2}, Alessandro Gardini¹

¹The Wistar Institute; ²The University of Pennsylvania



Elisa Barbieri

University of Edinburgh

Create & collaborate more with a free account

Edit and publish protocols, collaborate in communities, share insights through comments, and track progress with run records.

Create free account

OPEN  ACCESS



DOI: <https://dx.doi.org/10.17504/protocols.io.bbmngik3w>

Protocol Citation: Elisa Barbieri, Connor Hill, Alessandro Gardini 2020. fastGRO. protocols.io
<https://dx.doi.org/10.17504/protocols.io.bbmngik3w>

License: This is an open access protocol distributed under the terms of the **Creative Commons Attribution License**, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited



Protocol status: Working

We use this protocol and it's working

Created: January 22, 2020

Last Modified: October 12, 2020

Protocol Integer ID: 32136

Keywords: fastgro



Materials

MATERIALS

✕ 1.5 mL Eppendorf tubes

✕ Chloroform

✕ Isopropanol

✕ PBS

✕ NEBNext Ultra II Directional RNA Library Prep Kit for Illumina - 24 rxns **New England Biolabs Catalog #E7760S**

✕ 0.5M EDTA **Catalog #AM92606**

✕ 2 mL Eppendorf

✕ Glycerol

✕ RNA Clean & Concentrator-5 Kit **Zymo Research Catalog #R1015**

✕ Corning® 15 ml Centrifuge Tubes **Corning**

✕ M280 streptavidin beads **Invitrogen - Thermo Fisher**

✕ 5M NaCl **Ambion Catalog #AM9760G**

✕ Capillary electrophoresis instrument (e.g. Agilent Tapestation 4200)

✕ 1M MgCl₂ solution **Thermo Fisher Scientific Catalog #AM9530G**

✕ 50ml Falcon tubes **Corning Catalog #352070**

✕ Qubit RNA HS Assay Kit **Thermo Fisher Scientific Catalog #Q32852**

✕ 1M Tris-HCl (pH 8.0) **Thermo Fisher Scientific Catalog #15568025**

✕ Tween-20

✕ Ethanol

✕ KCl 2M **Catalog #AM9640G**

✕ Sarkosyl **Merck MilliporeSigma (Sigma-Aldrich) Catalog #L7414**

✕ 4-thiouridine (4sU) **Merck MilliporeSigma (Sigma-Aldrich) Catalog #T4509**

✕ TRIzol®; LS Reagent **Thermo Fisher Catalog #10296028**

✕ ATP **Thermo Fisher Catalog #18330019**

✕ CTP **Thermo Fisher Catalog #18331017**

✕ GTP **Thermo Fisher Catalog #18332015**

✕ EZ-Link®; HPDP-Biotin, No-Weigh®; Format **Thermo Fisher Catalog #A35390**

✕ SUPERase®; In®; RNase Inhibitor (20 U/μL) **Thermo Fisher Catalog #AM2696**



✕ Qubit[®] 3 Fluorometer **Thermo Fisher Catalog #Q33216**

✕ IGEPAL[®] CA-630 **Merck MilliporeSigma (Sigma-Aldrich) Catalog #I8896**

✕ Glycogen **Merck MilliporeSigma (Sigma-Aldrich) Catalog #10901393001**

✕ 1M DTT **Merck MilliporeSigma (Sigma-Aldrich) Catalog #43816-10ML**

✕ 1M Tris-HCl pH 7.5 **Thermo Fisher Scientific Catalog #15567027**

✕ 1M CaCl₂ **Merck MilliporeSigma (Sigma-Aldrich) Catalog #21115**

✕ NN-Dimethylformamide **Merck MilliporeSigma (Sigma-Aldrich) Catalog #227056-100ML**

✕ 4-Thiouridine-5-Triphosphate (4-thio-UTP) **Catalog #N-1025-1**

✕ RNA ScreenTape and Reagents **Agilent Technologies**

✕ Bioruptor USD-200 **Diagenode**

Troubleshooting

Before start

Prepare spike-in RNA or Nuclei

Prepare 50 mM of 4-thiouridine (4sU) in DEPC-treated water. Aliquot and store in the dark at -20 °C.

Incubate drosophila cells for 5 minutes with 50mM of 4sU in their growing medium. Wash cells with 1X PBS, lyse in Trizol reagent. Extract RNA, aliquot, snap-freeze in liquid nitrogen and store at -80 °C.

Can also prepare drosophila nuclei to control for the Nuclear run-on. Can be done using same nuclei extraction protocol (steps 1-9) and drosophila nuclei can be added to your sample at steps 8 or 12 to 5-10% of amount of nuclei from your sample.

Prepare buffers and solutions.

Swelling Buffer (SB) - Add 2 U/ml Superare-In before use.

- 10 mM Tris-HCL pH 7.5
- 2 mM MgCl₂
- 3 mM CaCl₂

Store at 4 °C.

Swelling Buffer + 10% Glycerol (GSB) - Add 2 U/ml Superare-In before use. Store at 4 °C.

Lysis Buffer (LyB) - Add 2 U/ml Superare-In before use.

- 10 mM Tris-HCL pH 7.5
- 2 mM MgCl₂
- 3 mM CaCl₂
- 10% Glycerol
- 1% Igopal

Store at 4 °C.

Freezing Buffer (FB) - Add 2 U/ml Superare-In before use.

- 40% glycerol
- 5 mM MgCl₂
- 0.1 mM EDTA
- 50 mM Tris-HCL pH8

Store at 4 °C.

1 mg/mL EZ-link HPDP Biotin

Resuspend 1 mg in 1 ml of DMF in polypropylene tubes, vortex and incubate at 36 °C for 30 min.

Store at -20 °C.

10x Biotinylation Buffer

100 mM Tris pH 7.5

10 mM EDTA pH 8.0

Store at 4 °C.




Nuclei isolation

1 Harvest cells and wash in cold 1X PBS

2 Resuspend cells in  10 mL of ice-cold SB.


Incubate for  00:05:00 .


Spin  400 x g, 00:10:00 .


3 Remove supernatant and resuspend in  10 mL GSB


Note

Volume of GSB should be at least 5 times the volume of cell pellet


4 Vortex lightly while adding  10 mL of LyB

5 Incubate on ice for  00:05:00


Add  25 mL of LyB and centrifuge  600 x g, 00:05:00 .


6 Flick to loosen pellet and resuspend in  25 mL of LyB.

Centrifuge  600 x g, 00:05:00

7 Remove supernatant and resuspend in  10 mL of FB.


Take  10 μ L for cell count.

8 Centrifuge  900 x g, 00:06:00 and resuspend using wide-end pipette tips in FB to a concentration of 2×10^7 nuclei per 10 μ L of FB.

9 Nuclei can be stored at  -80 °C for months.

Nuclear Run On

10

Prepare fresh 2x Nuclear run-on buffer (NRO). ( 100 μ L /sample)

- 10 mM Tris-HCl pH8
- 5 mM MgCl_2
- 300 mM KCl
- 1 mM DTT
- 500 μ M ATP
- 500 μ M GTP
- 500 μ M 4-thio-UTP
- 2 μ M CTP
- 200 μ /ml Suprase-in
- 1% Sarkosyl (N-Laurylsarcosine sodium salt solution)

Note

Per library, use $1.5\text{--}2 \times 10^7$ nuclei

11

Warm the NRO buffer at  30 $^{\circ}\text{C}$.



12

Thaw nuclei  On ice .



Note

5-10% drosophila nuclei can be added to your sample as spike-in if not using 4S-U labelled drosophila RNA in step 26.

13


Mix  100 μ L of thawed nuclei solution with  100 μ L of 2xNRO buffer.
Pipette up and down 15 times using end-cut pipette tip.

14



Incubate  00:07:00 at  30 $^{\circ}\text{C}$.



15

Add  600 μ L Trizol LS.

Vortex.

Incubate  00:05:00 at  Room temperature .

Note

STOP POINT: Freeze with liquid nitrogen, and store at -80 °C

Total RNA precipitation

16

Add  160 μ L of chloroform, shake vigorously by hand for  00:00:15

17

Incubate  00:02:00 at  Room temperature .




18

Centrifuge at  12000 rpm, 4°C, 00:15:00 .

19

Transfer upper, aqueous phase into new 1.5 mL centrifuge tube.


20

Add  400 μ L of isopropanol to precipitate RNA and incubate at  Room temperature for  00:10:00 .

Note

Can add 1-2 μ L of 2 μ g/ μ L glycogen to allow for visualization of pellet with lower RNA concentrations.

21


Centrifuge at  12000 rpm, 4°C, 00:10:00 .

22

Wash RNA pellet using  1 mL of cold 75 % ethanol





Centrifuge at  12000 rpm, 4°C, 00:10:00 .

23 Completely remove ethanol and air-dry pellet.
Dissolve in  100 µL of nuclease-free water.

24 Determine concentration by Nanodrop or Qubit.

RNA fragmentation

25 Transfer  150 µg of RNA to a 1.5 ml tube and add water up to  500 µL .

Note


Save 5 µl of unfragmented RNA to be run on TapeStation as a control for fragmented RNA and to check quality of RNA.

26 Add 5-10% of labelled spike-in RNA if using instead of drosophila nuclei.

27 Fragment RNA using Bioruptor with the following settings using: 1 cycle: 30 sec / 30 sec ON / OFF at high settings.

28
Transfer fragmented RNA to 2 ml tube.

29 Analyze fragmentation efficiency of fragmented versus unfragmented RNA on Agilent 2200 TapeStation.

30 Sonicated RNA can be snap-frozen in liquid nitrogen and stored at  -80 °C

EZ-link HPDP-Biotinylation

31
Transfer  150 µg of fragmented RNA in one 2 ml Eppendorf tube.

**Note**

Use only polypropylene tubes during biotinylation.


- 32 Incubate RNA at 65 °C for 00:10:00 , then On ice for 00:05:00 .
- 33 Prepare Biotin-RNA mix in 2 ml tube. Follow the order:
- up to 150 µg of fragmented RNA in 500 µL
 - 100 µL Biotinylation Buffer
 - 200 µL DMF
 - 200 µL EZ-link HPDP Biotin
- 34 Incubate in the dark at 24 °C and 800 rpm for 02:00:00 .


Precipitation of biotinylated RNA

- 35 Add appr. 800 µL of chloroform to the RNA-biotin in the 2 mL phase-lock tube and mix by manually shaking the tube.
- 36 Centrifuge at 4 °C and 16000 x g 00:05:00
- 37 Transfer upper phase into new tube (appr 1 mL).
- 38 Add 1/10 volume (100 µl) of 5 M NaCl and mix.

**Note**

If needed at 1-2 μL of 2 $\mu\text{g}/\mu\text{L}$ Glycogen to allow for visualization of pellet with lower RNA concentrations.

39 Add 1 volume (1 ml) of isopropanol and mix for  00:00:15 manually.


40 Centrifuge  16000 x g, 4°C, 00:05:00 .

41 Remove supernatant.

42 Wash pellet with  1 mL of ice-cold 75% ethanol.

Centrifuge  10006 x g, 4°C, 00:30:00 .

43 Remove supernatant.


44 Spin quickly at  4 °C and remove remaining supernatant with 200 μL and 10 μL pipettes.

Note

Biotinylated RNA should NOT dry.

45 Resuspend RNA in  100 μL of nuclease-free water.

Note

Biotinylated RNA can be stored at  -80 °C .



Enrichment of biotinylated RNA

46 Prepare Wash Buffer (WB):

- 100 mM Tris pH 7.5
- 10 mM EDTA pH 8.0
- 1M NaCl
- 0.1% (vol/vol) Tween-20

47 Leave half volume of WB at Room temperature and heat the other half at 65 °C .

48 Prepare the M280 Streptavidin Dynabeads:

48.1 Take 100 µL of beads per sample.

48.2 Wash the beads twice with 2 volumes (200 µL per sample) of wash buffer.

48.3 Resuspend in 1 Volume (100 µL per sample) of wash buffer.











49 Increase the volume of the solution of RNA-biotin to 200 µL with nuclease-free water.

Note



Can also scale down to 100 µL if you have less than 150 µg and use 50uL of beads.



















50 Incubate at 65 °C for 00:10:00 .
Place on ice for 00:05:00 .



- 51 Add  100 μL of prepared Invitrogen streptavidin beads to  200 μL of RNA-biotin.
- 52 Incubate at  4 $^{\circ}\text{C}$ for  00:15:00 in rotation.
- 53 Transfer tubes to a magnetic rack.
Remove supernatant.
Do not disturb beads.
- 54 Wash at least 3 times with  900 μL of warm ( 65 $^{\circ}\text{C}$) WB.
- 55 Wash at least 3 times with  900 μL of room temperature WB.
- 56 Resuspend beads in in  100 μL of 100 mM DTT and incubate  00:05:00 .
- 57 Transfer tubes to the magnetic rack.
Collect the 4-thio-labeled RNA in a new tube.
- 58 Repeat steps 57-58 and collect the eluted RNA in the same tube ( 200 μL total volume).

Purification of labelled RNA with RNA Clean and

- 59 Use buffers provided with the RNA Clean and Purification kit-5 (Zymo Research). Add ethanol to wash and pre-wash buffers and resuspend DNase in water.
- 60 Add  400 μL of RNA Binding Buffer to each sample and mix.
- 61 Add  600 μL of ethanol (95-100%) and mix.

- 62 Transfer the sample to the Zymo-Spin IC Column in a Collection Tube and centrifuge for  00:00:30 . Discard the flow-through.
- 63 Add  400 μL of RNA Wash Buffer to the column and centrifuge for  16000 x g, 00:00:30 . Discard the flow-through.
- 64 For each sample to be treated, prepare DNase I reaction mix in an RNase-free tube. Mix well by gentle inversion:
-  5 μL DNase I
 -  35 μL DNA Digestion Buffer
- 65 Add  40 μL reaction mix directly to the column matrix. Incubate at  Room temperature for  00:15:00 .
- 66 Add  400 μL RNA Prep Buffer to the column and centrifuge for  00:00:30 . Discard the flow-through.
- 67 Add  700 μL RNA Wash Buffer to the column and centrifuge for  00:00:30 . Discard the flow-through.
- 68 Add  400 μL RNA Wash Buffer to the column and centrifuge for  00:02:00 . Discard the flow-through.
- 69 Centrifuge for  00:01:00 at full speed to ensure complete removal of the wash buffer. Transfer the column carefully into an RNase-free tube.
- 70 Add  6 μL DNase/RNase-Free Water directly to the column matrix, incubate for  00:01:00 and centrifuge for  00:00:30
- 71 Measure concentration of labelled RNA by Qubit fluorometer.



- 72 Libraries can be prepared with NEBNext Ultra II Directional RNA Library Prep or other library prep kits.