


Jun 25, 2017

## Propagating T5-phages for Fluorescent Staining

DOI

[dx.doi.org/10.17504/protocols.io.igzcbx6](https://dx.doi.org/10.17504/protocols.io.igzcbx6)



Dr. Steven Wilhelm

The Aquatic Microbial E...



Steven W Wilhelm

The University of Tennessee, Knoxville

OPEN  ACCESS



DOI: [dx.doi.org/10.17504/protocols.io.igzcbx6](https://dx.doi.org/10.17504/protocols.io.igzcbx6)

**Protocol Citation:** Dr. Steven Wilhelm 2017. Propagating T5-phages for Fluorescent Staining. **protocols.io**  
<https://dx.doi.org/10.17504/protocols.io.igzcbx6>

**License:** This is an open access protocol distributed under the terms of the **Creative Commons Attribution License**, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

**Protocol status:** Working

**Created:** June 15, 2017

**Last Modified:** February 06, 2018


**Protocol Integer ID:** 6393


### Abstract

Please contact Dr. Steven Wilhelm ([wilhelm@utk.edu](mailto:wilhelm@utk.edu)) for additional information regarding this protocol.


## Materials


### STEP MATERIALS


 Magnesium sulfate heptahydrate

 Magnesium sulfate heptahydrate






### Protocol materials

 Magnesium sulfate heptahydrate





 Magnesium sulfate heptahydrate

 Magnesium sulfate heptahydrate

## Propagating T5-phages

- 1 Grow a culture of E.coli ATCC11303 in LB media overnight
- 2 The next morning, prewarm LB-agar plates to 37°C
- 3 Pellet 1 mL of the cells in an Eppendorf tube at 10,000 xg, 2 min  
 00:02:00
- 4 Discard the medium
- 5 Resuspend the pellet into 1 mL 10 mM MgSO<sub>4</sub>  
 1 mL  
 Magnesium sulfate heptahydrate
- 6 Melt 0.6% top agar in the microwave
- 7 Prepare sterile 5 mL tubes and pipet 3 mL of melted top agar into them  
 3 mL
- 8 Keep tubes in 45°C heat block or water bath so that the agar stays in a liquid state, but not too hot to kill the cells.
- 9 Add 10 µL T5 from the stock (except the control) to 100 µL of resuspended cells
- 10 Incubate 5 min at room temperature  
 00:05:00
- 11 Add the infected cells to the molten top agar
- 12 Vortex briefly



- 13 Pour onto prewarmed LB agar plate and tilt the plate to spread
- 14 Let top agar solidify ~30-60 min  
 01:00:00
- 15 Evert plates and return to 37°C incubator
- 16 Let grow ~6-8 hrs  
 08:00:00
- 17 When confluent plaques are seen on the plate, add 5 mL of sterile phage buffer (10 mM MgSO<sub>4</sub>; 1 mM CaCl<sub>2</sub>; 10 mM Tris-HCl, pH 7.5; 1% gelatin)
- 18 Let the plates sit overnight at 4°C with the buffer on top to gather the phages
- 19 The next day, transfer the liquid from the plates to a sterile tube and add 100 µL chloroform and 5 mL phage buffer
- 20 Shake for 1 min to let chloroform settle out  
 00:01:00
- 21 Transfer 4 mL of the supernatant to a fresh tube  
 4 mL
- 22 Filter the solution with 0.22 µm pore size syringe filter to get rid of all the cellular debris
- 23 Store phage at 4°C. They will stay infective for >1 yr.



## Protocol



NAME

## Fluorescent Staining of T5-phages

CREATED BY

Steven W Wilhelm

**PREVIEW**

- 23.1 Pellet phage in an ultracentrifuge at 28,000 rpm, 90 min, 10°C in 35 mL polycarbonate tubes, filled to the rim, balanced with phage buffer so that the difference is <0.01 g.

01:30:00

## Note

Use the SW-28 rotor, or equivalent, cooled down in the fridge prior to using.

- 23.2 Discard the supernatant

- 23.3 Resuspend the pellet with phage buffer

800 µL

- 23.4 If the pellet still seems to have some cellular debris in it, filter the resuspension using a 1 mL syringe and a small 0.2 µm pore size syringe filter.

- 23.5 Re-pellet the viruses in a Beckmann TL-100 ultracentrifuge at 35,000 rpm, 2 hr, 6°C using the TL-55 rotor cooled down before use using 1.4 mL polycarbonate tubes, filled and balanced as the bigger tubes in step 1.

- 23.6 Resuspend the pellet with phage buffer and transfer into 1.5 mL screw cap tubes

100 µL

- 23.7 Store at 4°C

- 23.8 Add YO-PRO stain to each tube containing 100 µL resuspension

0.5 µL

**Note**

Make sure to work in the dark, because the stain is photosensitive.

23.9 Cover the tubes with aluminum foil and let sit at 4°C for 48 hrs

23.10 After incubation, increase the volume to 1.4 mL

23.11 Centrifuge in the Beckmann TL-100 as in step 5

23.12 Discard the supernatant

23.13 Suspend the viruses in Milli-Q water

 100 µL