

Mar 12, 2024

# ssUMI: high-throughput long-read sequencing workflow for highly-accurate near full-length 16S rRNA genes on the ONT platform

DOI

[dx.doi.org/10.17504/protocols.io.6qpvr3qkpvmk/v1](https://dx.doi.org/10.17504/protocols.io.6qpvr3qkpvmk/v1)

Xuan Lin<sup>1</sup>, Katherine Waring<sup>2</sup>, John Tyson<sup>3,4</sup>, Ryan Ziels<sup>2</sup>

<sup>1</sup>University of British Columbia; <sup>2</sup>Civil Engineering, The University of British Columbia, Vancouver, BC, Canada;

<sup>3</sup>Environmental Microbiology, British Columbia Center for Disease Control Public Health Laboratory, Vancouver, BC, Canada;

<sup>4</sup>Pathology and Laboratory Medicine, The University of British Columbia, Vancouver, BC, Canada



Xuan Lin

University of British Columbia

## Create & collaborate more with a free account

Edit and publish protocols, collaborate in communities, share insights through comments, and track progress with run records.

Create free account

OPEN  ACCESS



DOI: <https://dx.doi.org/10.17504/protocols.io.6qpvr3qkpvmk/v1>

**Protocol Citation:** Xuan Lin, Katherine Waring, John Tyson, Ryan Ziels 2024. ssUMI: high-throughput long-read sequencing workflow for highly-accurate near full-length 16S rRNA genes on the ONT platform. **protocols.io**

<https://dx.doi.org/10.17504/protocols.io.6qpvr3qkpvmk/v1>



### Manuscript citation:

Lin, X., Waring, K., Tyson, J. & Ziels, R. M. High-accuracy meets high-throughput for microbiome profiling with near full-length 16S rRNA amplicon sequencing on the Nanopore platform. 2023.06.19.544637 Preprint at <https://doi.org/10.1101/2023.06.19.544637> (2023).

**License:** This is an open access protocol distributed under the terms of the **Creative Commons Attribution License**, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

**Protocol status:** Working

**We use this protocol and it's working**

**Created:** December 04, 2023

**Last Modified:** March 12, 2024

**Protocol Integer ID:** 91810

**Keywords:** length 16s rRNA amplicon, length 16s rRNA gene, rRNA amplicon, oxford nanopore native barcoding kit 96 v12, rRNA gene, sequencing library, oxford nanopore native barcoding kit, oxford nanopore community protocol, nanopore platform, sequencing, unique molecule identifier, amplicon, promethion platforms in super high accuracy mode, 1391r

## Abstract

This is the online protocol for near full-length 16S rRNA amplicon sequencing with unique molecule identifiers (ssUMI) on the Nanopore platform. Sequencing libraries are prepared with Oxford Nanopore Native Barcoding kit 96 V12 or V14 (SQK-NBD112.96 or SQK-NBD114.96) for sequencing on PromethION platforms in super high accuracy mode (260 bps).

The near full-length 16S rRNA amplicons are generated with primers 8F: AGRGTTYGATYMTGGCTCAG and 1391R: GACGGGCGGTGWGTRCA; the UMI design was adapted from **(Karst and Ziels, 2021)** and the Oxford Nanopore community protocol.

For more details, please check our preprint: <https://www.biorxiv.org/content/10.1101/2023.06.19.544637v1>



## Materials

### Primers and probe (order from IDT)

#### 1. ddPCR

ddPCR-8F: AGRGTTYGATYMTGGCTCAG

ddPCR-1391R: GACGGGCGGTGWGTRCA

ddPCR-515F-FAM: (FAM)-TGYCAGCMG-(ZEN)-CCGCGGTAA-(IBFQ)

#### 2. ssUMI-PCR

ssUMI-8F-UMI: GTATCGTGTAGAGACTGCGTAGG NNNYRNNNNYRNNNNYRNNNA GRGTTYGATYMTGGCTCAG (PAGE purified)

ssUMI-1391R-UMI: AGTGATCGAGTCAGTGCGAGTG NNNYRNNNNYRNNNNYRNNN GACGGGCGGTGWGTRCA (PAGE purified)

ssUMI-Universal-F: GGTGCTGAAGAAAGTTGTCTGGTGTCTTTGTGTTAACCGTATCGTGTAGAGACTGCGTAGG

ssUMI-Universal-R: GGTGCTGAAGAAAGTTGTCTGGTGTCTTTGTGTTAACCGTATCGAGTCAGTGCGAGTG

## Protocol materials

✕ PCR Plate Heat Seal foil piercable **Bio-Rad Laboratories Catalog #1814040**

✕ Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01**

✕ Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01**

✕ Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01**

✕ Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01**

✕ NEB Blunt/TA Ligase Master Mix **Catalog #M0367**

✕ NEBNext Ultra II End Repair/dA-Tailing Module - 96 rxns **New England Biolabs Catalog #E7546L**

✕ NEBNext Quick Ligation Reaction Buffer (5X) - 2.0 ml **New England Biolabs Catalog #B6058S**

✕ Quick T4 DNA Ligase **New England Biolabs Catalog #E7180S**

✕ Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01**

✕ Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01**

✕ Ultrapure Water **ThermoFisher Catalog #10977023**

✕ ddPCR 96-well plates **Bio-Rad Laboratories Catalog #12001925**

## Troubleshooting



## Before start

This protocol was developed with 96 samples, and we highly recommend using multi-channel pipettes and/or an automatic liquid handler.

Time can be saved by preparing master mixes first, before PCR steps. The master mix for PCR steps should be prepared in a Master Mix (PCR) Hood. To avoid cross-contamination make sure that your original stock reagents have no contact with any amplified DNA material.

A Negative Control (nuclease-free H<sub>2</sub>O) should be included.

Keep the enzymes on ice and thaw the other reagents at room temperature, mix, then spin down before placing on ice.

All steps after ssUMI-EarlyPCR2 should be performed in post-PCR area.

## Sample pre-dilution and ddPCR quantification of starting material

12h

- 1 Estimate the full-length 16S rRNA concentration in the DNA extract (e.g., sample), and dilute the sample to [M] 20000 copies/ $\mu$ L with

2h

⊗ Ultrapure Water **Thermofisher Catalog #10977023** .

### Note



The concentration of full-length 16S rRNA copy numbers can be estimated based on previous experiments, literature, or qPCR. It's important to pre-dilute the DNA sample to ensure the 16S rRNA copy number is within the dynamic range of ddPCR instrument (1-125,000 copies/ $\mu$ L).

- 2 Run ddPCR quantification with  $\text{🧪}$  2.5  $\mu$ L diluted DNA sample.


- 2.1 Prepare the ddPCR mastermix in a PCR hood, vortex to mix and dispense  $\text{🧪}$  19.5  $\mu$ L into each well of the   
 $\otimes$  ddPCR 96-well plates **Bio-Rad Laboratories Catalog #12001925** . Each component is thawed at  $\text{🌡}$  Room temperature , vortexed to mix, then spun down. A 10% pipetting loss should be included when preparing mastermix for multiple samples.

10m

	A	B	C
	Component	Volume (per rxn)	Volume (96 rxn)
	ddPCR-8F (10 $\mu$ M)	1.98 $\mu$ L	217.8 $\mu$ L
	ddPCR-1391R (10 $\mu$ M)	1.98 $\mu$ L	217.8 $\mu$ L
	ddPCR-515F-FAM (10 $\mu$ M)	0.55 $\mu$ L	60.5 $\mu$ L
	Nuclease-free water	3.99 $\mu$ L	438.9 $\mu$ L
	ddPCR Supermix for Probes (No dUTP)	11 $\mu$ L	1210 $\mu$ L
	<b>Total volume</b>	<b>19.5 <math>\mu</math>L</b>	<b>2145 <math>\mu</math>L</b>

2.2 Add  2.5 µL diluted DNA sample to each well, seal the plate with  PCR Plate Heat Seal foil piercable **Bio-Rad Laboratories Catalog #1814040** , vortex to mix, and spin down. 10m

2.3 Load the plates on the QX200 AutoDG Droplet Digital PCR System, and run droplet generation. 40m

2.4 Run PCR in a deep-well thermalcycler using the following program (set total volume as  40 µL ) : 6h

	A	B	C	D	E
	<b>Step</b>	<b>Temperature</b>	<b>Ramp rate</b>	<b>Time</b>	<b>Cycles</b>
	Enzyme Activation	95°C	2°C/sec	10 min	1
	Denaturation Annealing Extension	94°C 60°C 72 °C	2°C/sec	30 sec 1 min 4 min	50
	Enzyme Deactivation	98 °C	2°C/sec	10 min	1
	Hold	4°C	2°C/sec	∞	-

#### Note

ddPCR requires using a doubled reaction volume to prevent droplet burst during the PCR reaction

2.5 Count droplets in QX200 AutoDG Droplet Digital PCR System using manufacturer's protocols. 2h

## ssUMI-PCR1: UMI tagging and cleanup 2h 10m

3 In this step, the near full-length 16S rRNA gene primers containing UMIs are annealed to both ends of the DNA template using 2 rounds of PCR. Only one copy of a dual-end UMI-tagged amplicon will be generated for each input molecule. 1h 10m

3.1 Adjust the input DNA concentration to **1M 5000 copies/μL** with nuclease-free water (100,000 16S rRNA gene copies in 20 μL) based on the ddPCR measured near full-length 16S rRNA gene copy numbers (see Step 2.5).

30m

3.2 Prepare ssUMI-PCR1 mastermix in a PCR hood, flick the tube to mix and dispense **30 μL** into each well of a 96-well PCR plate. Each component is thawed **On ice**, mixed by flicking the tube, then spun down. A 10% pipetting loss should be included when preparing mastermix for multiple samples.

10m

A	B	C
Component	Volume (per rxn)	Volume (96 rxn)
2X Platinum™ SuperFi™ II Green PCR Master Mix	25 μL	2750 μL
100 μM UMI_8F (500 nM final)	0.25 μL	27.5 μL
100 μM UMI_1391R (500 nM final)	0.25 μL	27.5 μL
Nuclease-free water	4.5 μL	495 μL
<b>Total volume</b>	<b>30 μL</b>	<b>3300 μL</b>

3.3 Add **20 μL DNA samples from step 3.1** (100,000 full-length 16S rRNA gene copies) into each well of a 96-well PCR plate,


5m

3.4 Run PCR in a thermocycler using the following program (total volume: **50 μL**) :


22m



A	B	C	D	E
Step	Temperature	Ramp rate	Time	Cycles
Initial denaturation	98°C	max	3 min	1
Denaturation	98°C	max	30 sec	2
Annealing	Touchdown from 66°C to 60°C	0.2°C/sec	90 sec	
Extension	72°C	max	3 min	
Final extension	72 °C	max	5 min	1
Hold	4 °C	max	∞	-



4 ssUMI-PCR1 cleanup using  Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01** with a bead-to-sample ratio of 0.6.

1h

4.1 Homogenize  Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01** solution by vortexing.


4.2 Add  30 µL bead solution to the  50 µL ssUMI-PCR1 product (ratio 0.6) and mix by pipetting or brief vortexing.

4.3 Spin down, and then incubate at  Room temperature for  00:10:00 .

10m

4.4 Place the plate on a magnetic rack to pellet the beads, and wait until the solution is clear on the side of each well (~5 min).

4.5 Keep the plate on the magnetic rack, carefully discard the supernatant.

4.6 Wash beads by adding  200 µL fresh 80% ethanol along the opposite side of the beads.

4.7 Wait 30 seconds and discard the ethanol.

4.8 Repeat the washing steps (Steps 4.5-4.7).





4.9 Spin down and place the plate back on the magnetic rack, then remove residual ethanol with a smaller pipette.



#### Note


Not removing residual ethanol could cause primer and UMI carryover and high chimera rates.




- 4.10 Let the beads air dry for a maximum of 2 min (but do not overdry the beads to the point of cracking).
- 4.11 Remove the plate from the magnetic rack and elute the purified DNA by adding  20 µL nuclease-free water and mix by pipetting.
- 4.12 Incubate at  Room temperature for  00:05:00 . 5m
- 4.13 Place the plate on the magnetic rack to pellet the beads and wait until the eluate is clear and colourless.
- 4.14 Pipette off the  18 µL supernatant to a new 96-well PCR plate.

## ssUMI-EarlyPCR2: amplification of UMI-tagged amplicons


2h 20m

- 5 In this step, the dual-UMI-tagged near full-length 16S rRNA gene amplicons are further amplified with PCR. 1h 20m
- 5.1 Prepare ssUMI-PCR2 mastermix in PCR hood, flick the tube to mix. Each component is thawed  On ice , mixed by flicking the tube, then spun down. A 10% pipetting loss should be included when preparing mastermix for multiple samples. 10m

	A	B	C
	Component	Volume (per rxn)	Volume (96 rxn)
	2X Platinum™ SuperFi™ II Green PCR Master Mix	25 µL	2750 µL
	100 µM UMI_8F (500 nM final)	0.5 µL	55 µL
	100 µM UMI_1391R (500 nM final)	0.5 µL	55 µL
	25 mM MgCl (1mM final)	2 µL	220 µL
	Nuclease-free water	4 µL	440 µL
	<b>Total volume</b>	<b>32 µL</b>	<b>3520 µL</b>

5.2 Dispense  32 µL into each well of the 96-well PCR plate containing 18 µL cleaned ssUMI-PCR1 product.

5m


5.3 Spin down and run PCR in a thermocycler using the following program (total volume:  50 µL ) :

1h 5m

	A	B	C	D	E
	Step	Temperature	Ramp rate	Time	Cycles
	Initial denaturation	98°C	max	3 min	1
	Denaturation	98°C	max	20 sec	5
	Annealing	Touchdown from 70°C to 63°C	0.2°C/sec	45 sec	
	Extension	72°C	max	3 min 30s	
	Denaturation	98°C	max	20 sec	5
	Extension	72°C	max	4 min	
	Final extension	72 °C	max	5 min	1
	Hold	4 °C	max	∞	-


6 ssUMI-EarlyPCR2 cleanup using

1h










 Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01** with a bead-to-sample ratio of 0.6.

#### Note

This step should be conducted in a post-PCR area to prevent amplicon contamination.


6.1 Homogenize  Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01** solution by vortexing.




- 6.2 Add  30  $\mu$ L bead solution to the  50  $\mu$ L ssUMI-PCR1 product (ratio 0.6) and mix by pipetting or brief vortexing.
- 6.3 Spin down, and then incubate at  Room temperature for  00:10:00 . 10m
- 6.4 Place the plate on a magnetic rack to pellet the beads, and wait until the solution is clear on the side of each well (~5 min).
- 6.5 Keep the plate on the magnetic rack, carefully discard the supernatant.
- 6.6 Wash beads by adding  200  $\mu$ L fresh 70% ethanol along the opposite side of the beads.
- 6.7 Wait 30 seconds and discard the ethanol.
- 6.8 Repeat the washing steps (Steps 6.5–6.7).
- 6.9 Spin down and place the plate back on the magnetic rack, then remove residual ethanol with a smaller pipette.
- 6.10 Let the beads air dry for a maximum of 2 min (but do not overdry the beads to the point of cracking).
- 6.11 Remove the plate from the magnetic rack and elute the purified DNA by adding  20  $\mu$ L nuclease-free water and mix by pipetting.
- 6.12 Incubate at  Room temperature for  00:05:00 . 5m
- 6.13 Place the plate on the magnetic rack to pellet the beads and wait until the eluate is clear and colourless.
- 6.14 Pipette off the  18  $\mu$ L supernatant to a new 96-well PCR plate.

### Note

This is a safe stopping point.


For short-term storage, samples can be stored at  4 °C overnight;

For long-term storage, samples should be stored at  -20 °C .

## ssUMI-LatePCR2: amplification of UMI-tagged amplicons


2h 40m

- 7 Similar to ssUMI-EarlyPCR2, the dual-UMI-tagged near full-length 16S rRNA gene amplicons are further amplified with 15 cycles of PCR.

- 7.1 Prepare the same mastermix as in Step 5.1 (ssUMI-PCR2 mastermix) in PCR hood, flick the tube to mix. Each component is thawed  On ice , mixed by flicking the tube, then spun down. A 10% pipetting loss should be included when preparing mastermix for multiple samples.

10m


A	B	C
Component	Volume (per rxn)	Volume (96 rxn)
2X Platinum™ SuperFi™ II Green PCR Master Mix	25 µL	2750 µL
100 µM UMI_8F (500 nM final)	0.5 µL	55 µL
100 µM UMI_1391R (500 nM final)	0.5 µL	55 µL
25 mM MgCl (1mM final)	2 µL	220 µL
Nuclease-free water	4 µL	440 µL
<b>Total volume</b>	<b>32 µL</b>	<b>3520 µL</b>

- 7.2 Dispense  32 µL into each well of the 96-well PCR plate containing 18 µL cleaned ssUMI-EarlyPCR2 product.

5m

### Note

This step should be conducted in a post-PCR area to prevent amplicon contamination.


- 7.3 Spin down and run PCR in a thermocycler using the following program (total volume:  50  $\mu$ L ) :

1h 25m

	A	B	C	D	E
	Step	Temperature	Ramp rate	Time	Cycles
	Initial denaturation	98°C	max	3 min	1
	Denaturation	98°C	max	20 sec	15
	Extension	72°C	max	4 min	
	Final extension	72 °C	max	5 min	1
	Hold	4 °C	max	$\infty$	-


- 8 ssUMI-LatePCR2 cleanup using



1h

 Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01** with a bead-to-sample ratio of 0.6.

#### Note

This step should be conducted in a post-PCR area to prevent amplicon contamination.

- 8.1 Homogenize  Mag-Bind® TotalPure NGS beads **Omega Biotek Catalog #M1378-01** solution by vortexing.

- 8.2 Add  30  $\mu$ L bead solution to the  50  $\mu$ L ssUMI-PCR1 product (ratio 0.6) and mix by pipetting or brief vortexing.








- 8.3 Spin down , and then incubate at  Room temperature for  00:10:00 .

10m

- 8.4 Place the plate on a magnetic rack to pellet the beads, and wait until the solution is clear on the side of each well (~5 min).

- 8.5 Keep the plate on the magnetic rack, carefully discard the supernatant.



- 8.6 Wash beads by adding  200  $\mu\text{L}$  fresh 70% ethanol along the opposite side of the beads.
- 8.7 Wait 30 seconds and discard the ethanol.
- 8.8 Repeat the washing steps (Steps 8.5-8.7).
- 8.9 Spin down and place the plate back on the magnetic rack, then remove residual ethanol with a smaller pipette.
- 8.10 Let the beads air dry for a maximum of 2 min (but do not overdry the beads to the point of cracking).
- 8.11 Remove the plate from the magnetic rack and elute the purified DNA by adding  20  $\mu\text{L}$  nuclease-free water and mix by pipetting.
- 8.12 Incubate at  Room temperature for  00:05:00 .
- 8.13 Place the plate on the magnetic rack to pellet the beads and wait until the eluate is clear and colourless.
- 8.14 Pipette off the  18  $\mu\text{L}$  supernatant to a new 96-well PCR plate.
- 9 Quantify  1  $\mu\text{L}$  of the cleaned ssUMI-LatePCR2 product using a Qubit fluorometer with Qubit dsDNA HS Assay Kit. Amplicons should have concentration higher than  4 ng/ $\mu\text{L}$

5m

**Note**

This is a safe stopping point.

For short-term storage, samples can be stored at 4 °C overnight;

For long-term storage, samples should be stored at -20 °C .

**Nanopore sequencing library preparation using Native Barcoding Kit 12/14**

4h

**10 DNA End-prep with**

1h 30m



NEBNext Ultra II End Repair/dA-Tailing Module - 96 rxns **New England**  
Biolabs Catalog #E7546L

**Reagent preparation before starting this step**


1. Thaw the NEBNext Ultra II End Prep Reaction Buffer On ice , check for any visible precipitate; vortexing for at least 30 seconds may be required to solubilise all precipitate.
2. Place the Ultra II End Prep Enzyme Mix On ice





**Note**

Do NOT vortex the Ultra II End Prep Enzyme Mix.

- 10.1 In a clean 96-well plate, aliquot 50 fmol ( 46.4 ng ) of amplicon per sample (based on quantification in Step 9).
- 10.2 Make up each sample to 12.5 µL using nuclease-free water. Mix gently by pipetting and spin down.
- 10.3 Prepare End-prep mastermix, mix by pipetting 10-20 times. A 10-15% pipetting loss should be included when preparing mastermix for multiple samples.

A	B	C
Reagent	Volume (per rxn)	Volume (96 rxn)
Ultra II End-prep Reaction Buffer	1.75 µl	210 µl
Ultra II End-prep Enzyme Mix	0.75 µl	90 µl
<b>Total</b>	<b>2.5 µl</b>	<b>300 µl</b>


10.4 Add  2.5 µL End-prep mastermix to each well containing DNA amplicons, pipetting 10-20 times to mix and spin down briefly.

10.5 Using a thermocycler, incubate at  20 °C for  00:05:00 and  65 °C for  00:05:00 .

10m

#### Note




Take forward the end-prepped DNA into the native barcode ligation step.



If users want to pause the library preparation here, we recommend cleaning up your sample with 1X AMPure XP Beads (AXP) and eluting in nuclease-free water before storing at  4 °C .



11 Native barcode ligation with Native Barcoding Kit 12 or Kit 14.

1h



#### Reagent preparation before starting this step

1. Thaw  NEB Blunt/TA Ligase Master Mix **Catalog #M0367** at  Room temperature , spin down and mix by performing 10 full volume pipette mixes, then place  On ice .

2. Thaw the AMPure XP Beads (AXP) at  Room temperature and mix by vortexing. Keep the beads at  Room temperature .

3. Thaw the EDTA (provided with the sequencing kit) at  Room temperature and mix by vortexing. Then spin down and place  On ice .





4. Thaw the Native Barcodes NB01-96 at  Room temperature . Individually mix the barcodes by pipetting, spin down, and place them  On ice .

11.1 In a new 96-well plate, add the reagents in the following order per well (select unique barcode for each sample on the plate). Between each addition, pipette mix 10 times.

A	B
Reagent	Volume
End-prepped DNA	3.75 µL
Native Barcode (NB01-96)	1.25 µL
Blunt/TA Ligase Master Mix	5 µL
<b>Total</b>	<b>10 µL</b>

11.2 Thoroughly mix the reaction by gently pipetting 10 times and then briefly spin down.

11.3 Incubate for  00:20:00 at  Room temperature .

20m



11.4 Add  1 µL EDTA to each well and mix thoroughly by pipetting and spin down briefly.

11.5 Pool all barcoded samples in a 1.5 ml Eppendorf DNA LoBind tube.

12 Native Barcoding reaction cleanup with 0.4x AMPure XP Beads.


30m



**Before start of this step:**

1. Prepare  2 mL fresh 80% ethanol in nuclease-free water.
2. Pre-heat an incubator to  37 °C .


12.1 Resuspend the AMPure XP Beads (AXP) by vortexing.




12.2 Add  422  $\mu\text{L}$  (for 96 samples) AMPure XP Beads (AXP) to the pooled reaction, and mix by pipetting for a 0.4x clean.

12.3 Incubate on a Hula mixer (rotator mixer) for  00:10:00 at  Room temperature .

10m

12.4 Spin down the sample and pellet on a magnet for  00:05:00 . Keep the plate on the magnetic rack until the eluate is clear and colourless, and pipette off the supernatant.

5m


12.5 Keep the tube on the magnetic rack and wash the beads with  700  $\mu\text{L}$  freshly prepared 80% ethanol without disturbing the pellet. Remove the ethanol using a pipette and discard.



#### Note

If the pellet was disturbed, wait for beads to pellet again before removing the ethanol.

12.6 Repeat the previous step (step 12.5).


12.7 Spin down and place the tube back on the magnetic rack. Pipette off any residual ethanol. Allow the pellet to dry for ~30 seconds, but do not overdry the pellet to the point of cracking.


12.8 Remove the tube from the magnetic rack and resuspend the pellet in  35  $\mu\text{L}$  nuclease-free water 35  $\mu\text{L}$  nuclease-free water by gently flicking or pipetting.

12.9 Incubate for  00:10:00 at  37  $^{\circ}\text{C}$  . Every 2 minutes, agitate the sample by gently flicking for 10 seconds to encourage DNA elution.

10m


12.10 Pellet the beads on a magnetic rack until the eluate is clear and colourless.

12.11 Remove and retain  35  $\mu\text{L}$  of eluate into a clean 1.5 ml Eppendorf DNA LoBind tube.

- 13 Quantify  1  $\mu\text{L}$  of the eluted sample using a Qubit fluorometer with Qubit dsDNA HS Assay Kit.

Note

**This is a safe stopping point.**

Samples can be stored at  4  $^{\circ}\text{C}$  overnight

- 14 Nanopore sequencing adapter ligation


30m

**Reagent preparation before starting this step**

1. Thaw the



NEBNext Quick Ligation Reaction Buffer (5X) - 2.0 ml **New England Biolabs Catalog #B6058S**

at  Room temperature , spin down and mixed by performing 10 full volume pipette mixes.

2. Spin down the Adapter Mix II (AMII H, Kit 12) or Native Adapter (NA, Kit 14) and




Quick T4 DNA Ligase **New England Biolabs Catalog #E7180S** , pipette mix and

place on ice.

3. Thaw the Elution Buffer (EB) and Short Fragment Buffer (SFB) at



Room temperature and mix by vortexing. Then spin down and place  On ice .

Note

Do NOT vortex the Quick T4 DNA Ligase.

- 14.1 In a 1.5 ml Eppendorf LoBind tube, mix in the following order. Between each addition, pipette mix 10 times.

A	B
Reagent	Volume



A	B
Pooled barcoded sample	30 µL
Native Adapter (NA)	5 µL
NEBNext Quick Ligation Reaction Buffer (5x)	10 µL
Quick T4 DNA Ligase	5 µL
<b>Total</b>	<b>50 µL</b>

14.2 Thoroughly mix the reaction by gently pipetting and briefly spinning down.

14.3 Incubate the reaction for 00:20:00 at Room temperature .

20m

15 Adapter Ligation reaction cleanup with 0.4x AMPure XP Beads.

30m

**Before start of this step:**

Pre-heat an incubator to 37 °C .

15.1 Resuspend the AMPure XP Beads (AXP) by vortexing.

15.2 Add 20 µL of resuspended AMPure XP Beads (AXP) to the reaction and mix by pipetting.

15.3 Incubate on a Hula mixer (rotator mixer) for 00:10:00 at Room temperature .






10m

15.4 Spin down the sample and pellet on the magnetic rack. Keep the tube on the magnet and pipette off the supernatant.

15.5 Wash the beads by adding 125 µL Short Fragment Buffer (SFB). Flick the beads to resuspend, spin down, then return the tube to the magnetic rack and allow the beads to pellet. Remove the supernatant using a pipette and discard.


15.6 Repeat the previous step (Step 15.5).




- 15.7 Spin down and place the tube back on the magnet. Pipette off any residual supernatant.
- 15.8 Remove the tube from the magnetic rack and resuspend pellet in  25  $\mu\text{L}$  Elution Buffer (EB).
- 15.9 Spin down and incubate for  00:10:00 at  37 °C . Every 2 minutes, agitate the sample by gently flicking for 10 seconds to encourage DNA elution. 10m
- 15.10 Pellet the beads on a magnet until the eluate is clear and colourless, for at least 1 minute.
- 15.11 Remove and retain  25  $\mu\text{L}$  of eluate containing the DNA library into a clean 1.5 ml Eppendorf DNA LoBind tube.
- 16 Quantify  1  $\mu\text{L}$  of the eluted sample using a Qubit fluorometer with Qubit dsDNA HS Assay Kit. Then make up the library to 32  $\mu\text{L}$  at 10-20 fmol (18.4 ng).

#### Note

##### **This is a safe stop point.**

For short-term storage, sequencing libraries can be stored in Eppendorf DNA LoBind tubes at  4 °C

For single use and long-term storage of more than 3 months, we recommend storing libraries at  -80 °C in Eppendorf DNA LoBind tubes.