Dec 05, 2019

Tissue Preparation for CLARITY

DOI
dx.doi.org/10.17504/protocols.io.8jihuke

Seth Currlin[1], Marda Jorgensen[1], Jerelyn Nick[1]

[1]University of Florida

Optical Clearing of Tissue | Human BioMolecular Atl...

Jerelyn Nick
University of Florida

OPEN ACCESS

DOI: dx.doi.org/10.17504/protocols.io.8jihuke

External link: http://wiki.claritytechniques.org/index.php/Solutions

Protocol Citation: Seth Currlin, Marda Jorgensen, Jerelyn Nick 2019. Tissue Preparation for CLARITY. **protocols.io https://dx.doi.org/10.17504/protocols.io.8jihuke**

Protocol status: Working
We use this protocol and it's working

Created: October 21, 2019

Last Modified: December 05, 2019

Protocol Integer ID: 29002

Keywords: CLARITY, Hydrogel Solution, Clearing Solution, tissue fixation, paraformaldehyde, PFA, acrylamide, lipid clearing

Abstract

Tissue preparation for CLARITY includes fixation in 4% PFA, infusion with monomers in Hydrogel Solution, and clearing of lipids in Electrophoretic Tissue Clearing Solution.

Guidelines

The hydrogel solution components should be kept on ice during preparation to prevent polymerization. The thermal initiator is stable at low temperatures, but initiates polymerization at higher temperatures. To prevent polymerization, the hydrogel solution aliquots should be stored at -20°C until ready for use. However, the solution should be stable at 4°C for a few days and at room temperature for a couple hours.

Materials

Hydrogel Solution
(http://wiki.claritytechniques.org/index.php/Solutions)

	Ingredient	Amount	Final Concentration	Purpose
	40% Acrylamide	40 mL	4%	Hydrogel network monomer
	2% Bis-acrylamide	10 mL	0.05%	Small chemical crosslinker
	VA-044 Initiator	1 g	0.25%	Polymerization thermal initiator
	16% Paraformaldehyde	100 mL	4%	Biomacromolecule crosslinker
	10X PBS	40 mL	1X	Salt buffer
	Deionized water	210 mL	-	Aqueous solvent

Hydrogel Solution

Clearing Solution
Electrophoretic Tissue Clearing Solution C13001; logosbio.com,
(https://logosbio.com/tissue-clearing_3d-imaging/tissue-clearing/x-clarity)

Equipment:
Platform rocker at room temperature (PFA Incubation)
Rocking Stage at 4˚C (hydrogel solution incubation)
Incubator Shaker/ at 37˚C (hydrogel polymerization)
Incubator/Shaker at 45˚C (tissue clearing)

Safety warnings

Paraformaldehyde and acrylamide are both toxic; therefore, preparation and use of the hydrogel solution should be done in a fume hood.

1 1. PFA Incubation: Trimmed tissues are placed fixed in 4% PFA for 20-24 hours at room temperature on a slow platform rocker.

2 2. Hydrogel Incubation: Tissues are transferred to Hydrogel Solution in for approximately 5 days at 4˚C. Tubes are kept on a 2-axis rocker for the duration.

3 3. Hydrogel Polymerization: On day 5 the tissue is placed in pre-warmed 37˚C PBS and a layer of mineral oil to deter oxygen exchange from air within tube. The hydrogel within the tissue is polymerized at 37°C for 4 hours with gentle rocking.

4 4. Passive Clearing: Following polymerization the tissue is placed in Clearing Solution and kept at 45˚C with gentle rocking until optically clear.