May 16, 2019

Yale - Alanine Aminotransferase

DOI

dx.doi.org/10.17504/protocols.io.yz4fx8w

Gary Cline¹, John Stack¹

¹Yale University

Mouse Metabolic Phenotyping Centers Tech. support email: info@mmpc.org

෯ Lili Liang





DOI: <u>dx.doi.org/10.17504/protocols.io.yz4fx8w</u>

External link: <u>https://mmpc.org/shared/document.aspx?id=206&docType=Protocol</u>

Protocol Citation: Gary Cline, John Stack 2019. Yale - Alanine Aminotransferase. protocols.io <u>https://dx.doi.org/10.17504/protocols.io.yz4fx8w</u>

License: This is an open access protocol distributed under the terms of the <u>Creative Commons Attribution License</u>, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's working

Created: March 11, 2019

Last Modified: May 16, 2019

Protocol Integer ID: 21276

Keywords: Alanine Amino activity,



Abstract

Summary:

Procedure used to measure the Alanine Amino activity in blood, plasma, and serum. Alanine Amino (ALT) activity is measured by the enzymatically coupled reactions of ALT (to form pyruvate from alanine and α -ketoglutarate) and Lactate dehydrogenase (conversion of pyruvate to lactate with oxdiation of NADH to NAD). The rate of NAD formation is monitored by the change in absorbance at 340 nm.

Materials

MATERIALS

Assayed Control Serum 1 Prolabs(cliniqa) Catalog #R83082
Assayed Control Serum 2 Prolabs(cliniqa) Catalog #R83083
Alanine Transaminase Reagent Prolabs(cliniqa) Catalog #R85122

Reagent Preparation:

Alkaline Transaminase Reagent: Add the appropriate amount of water (6.5mL) to the reagent bottle. Invert to mix, allowing 15 minutes for the reagent to settle.

Assayed Control Serum 1: Add the appropriate amount of water (6.5mL) to the chemical control bottle. Invert to mix, allowing 15 minutes for the reagent to settle.

Assayed Control Serum 2: Add the appropriate amount of water (6.5mL) to the chemical control bottle. Invert to mix, allowing 15 minutes for the reagent to settle.

Before start

Analysis by automated system Cobas Mira Plus.

- 1 Calibrate Cobas for Alanine Transaminase Activity analysis by running two assayed control serum.
- 2 Sample handling as performed by the Cobas Mira Plus.
 - a) Pipette 16 μL of sample into a cuvette slot.
 - b) Add 145 μL of Alanine Transaminase Reagent.
 - c) Mixture is incubated at 37°C and spun for 10 minutes.
 - d) Absorbance is measured at 340 nm.