


Dec 26, 2018

yeast single cell RNA-seq (yscRNA-seq)

DOI

dx.doi.org/10.17504/protocols.io.t29eqh6



Mariona Nadal-Ribelles¹, Saiful Islam², Wu Wei², Pablo Latorre³, Michelle Nguyen², Eulàlia de Nadal³, Francesc Posas³, Lars M. Steinmetz⁴

¹IRB Barcelona; ²Stanford University, Stanford Genome Technology Center;

³IRB Barcelona, Universitat Pompeu Fabra; ⁴Stanford University, Stanford Genome Technology Center, EMBL

Yeast Protocols, Tools, a...



Mariona Nadal-Ribelles

IRB Barcelona

OPEN  ACCESS



DOI: dx.doi.org/10.17504/protocols.io.t29eqh6

Protocol Citation: Mariona Nadal-Ribelles, Saiful Islam, Wu Wei, Pablo Latorre, Michelle Nguyen, Eulàlia de Nadal, Francesc Posas, Lars M. Steinmetz 2018. yeast single cell RNA-seq (yscRNA-seq). **protocols.io**

<https://dx.doi.org/10.17504/protocols.io.t29eqh6>

License: This is an open access protocol distributed under the terms of the **Creative Commons Attribution License**, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working

We use this protocol and it's working

Created: September 27, 2018

Last Modified: December 26, 2018

Protocol Integer ID: 16193

Keywords: yeast single cell RNA-seq (yscRNA-seq), transcriptomics, single cell rna, yscrna, rna, single cell, seq

Guidelines

****Please follow all precautions that usually you need to follow RNA and single-cell work. Clean the area prior to starting the protocol. Use dedicated reagents only to single cell work (and label them appropriately). Use pipettes and filter tips throughout the entire protocol****

Cell growth

- 1 Grow the desired pre-inoculum of your desired yeast strain in their corresponding media O/N.
To profile exponentially growing cells, we recommend the initial culture not to grow over OD₆₆₀=1
- 2 Next morning. Dilute your cells to OD₆₆₀= 0.05 in the corresponding media and allow for at least 2 cell divisions prior to sorting.

Single cell isolation by FACS sorting

- 3 Prepare 96/384 well plates* containing  5 µL Absolute Ethanol ** in each to fix cells immediately from sorting

* During protocol optimization we recommend using break-away plates

(**EK-75118**). Check with your facility the compatibility of the plates.

** this is the minimum volume required for our sorting facility/plates. Check with your facility

Note: We have obtained the same results sorting cells directly into 5 ul of cell capturing solution and lysis (see below). If doing so, prepare plates right before sorting and keep them on  4 °C ice

- 4 Dilute cells prior to sorting to OD=0.05 in  3 mL of media and vortex vigorously to separate cell clumps.
* At this step propidium iodide (PI) can be added to check for cell viability
- 5 At the FACS facility, filter cells with Cell Strainer Tubes (check with your facility which tubes they prefer) and put cells in the appropriate sorting tube for live single cell sorting.
- 6 Check the alignment of the plate with the sorter. For example, this can be done by sorting a drop into a covered plate and look for the droplet would fall inside each well.



- 7 Sort live single yeast into the each well of the plates and leave one well (we ususally do H12 as empty/not sorted) as negative control.
* Should you want to do a positive control, sort 100 cells into one well (we usually do A1).

- 8 Cover plates with aluminim seal if plates will not be processed right away or with temporary plastic lid.

- 9 Quickly spin plates to collect cells at the bottom

- 10 Let EtOH avaporate in a sterile environment (stril hood) for  00:45:00 maximum

- 11 Once EtOH is completely evaporated, add  5 μ L yeast cell lysis solutuinn of cell capturing solution and lysis. Spin down and freeze immediately.

Regardless if cells are sorted into EtOH or cell capturing and lysis solution, frozen plates can be stored at -80°C for at least 6 months.

Cell lysis solution:

Reagents	Reference	Volum e (1 rxn)
1% Triton X-100	X100-1L	0.05
UMI_Oligo dT_T31(100 μ M)	IDT	0.2
dNTP 25 mM	R0181	0.68
100 mM DTT	18064014	0.5
Zymolyase 100T (100 mg/ml)	37340-57-1	0.6
RNase Inhibitor (40 U/ml)	2313A	0.12
RNase-Nuclease free H ₂ O	10977035	2.769
ERCC (1:1000,0000) (5000 molecules)	4456740	0.081
Total		5



Lysis reaction

- 12 Do the following lysis cycle from fresh sorted or frozen plates and **quickly** proceed to add RT reaction for 1st strand cDNA synthesis

Incubate at 30°C for at least 10 minutes *

 00:10:00

3 minutes at 72°C

 00:03:00

1 minutes at 4°C

* We have changed the length of cell lysis up to 30 minutes

1st strand cDNA synthesis

- 13 5 Add  5 µL Reverse transcription mix (RT mix)

Reagents	Volume (1 rxn)	Reference
5X SuperScript Stand Buffer	2	18064014
MgCl ₂ (1M)	0.06	AM9530G
Betaine (5M)	1.6	61962
UMI_TSO 100uM	0.2	IDT
200 U/ul SuperScript II	0.25	18064014
RNase inhibitor (40U/ml)	0.125	2313A
RNase-Nuclease free H ₂ O	0.765	10977035
Total	5	

- 14 Spin down the plate and perform the following cycles

42°C for 90 mins



70°C for 15 mins

4°C forever

 01:45:00

Library amplification

15 Add  15 µL PCR mix for library amplification

Reagents	Volume (1 rxn)
10X Advantage 2 PCR buffer	2.5
dNTPs (25mm)	0.4
UMI_PCR (10uM)	1.2
50X Advantage 2 polymerase mix	0.5
H2O	10.4
Total	15

16 Spin down the plate and do the following cycles



Temperature (°C)	Time	Cycles
95	1 min	1
95	20 sec	
58	4 min	5
68	6 min	
95	20 sec	
64	30 sec	9
68	6 min	
95	30 sec	
64	30 sec	7
68	7 min	
72	10 min	1

hold at 4°C overnight (if necessary). This is usually a safe stopping point

qPCR validation

- 17 Perform a 1:20 dilution of the amplified library to check the percentage of positive libraries.

Use your favorite protocol, and use as a target primers to a housekeeping gene or ERCCs.

This step is specially useful during the protocol set up as it allows to inspect the efficiency of the protocol before moving forward.

Reagent	Volume (µl)
Sybergreen 2X	2.5
Primer mix*	0.125
H2O	1.375
DNA	1

* Primer mix is a mmix of Fw and Rv primer (10µM each)

1 cycle: 95°C 10 min

40 cycles: 95°C 30 sec, 58°C 30 sec and 72°C 30 sec

1 cycle: 95°C 15 sec, 60°C 15 sec and 95°C 15 sec (melting curve)

Primer sequence for qPCR:

SOMN17 Fw_TDH3_probe TCGTCAAGTTGGTCTCCTGG

SOMN18 Rv_TDH3_probe GGCAACGTGTTCAACCAAGT SOMN21 Fw_ADH1_probe

TGGTGCCAAGTGTGTTCTG

SOMN22 Rv_ADH1_probe GGCGAAGAAGTCCAAAGCTT

SOMN310 Fw_5_ERCC_00130 CGGAAAAGTACTGACCAGCG

SOMN311 Rv_5_ERCC_00130 TGCCAATGACTTCAGCTGAC

A good plate will have around 70% positive wells, as far as it's around 50% it should be OK. Rearrange positive cells into a new plate to proceed to tagmentation.

dscDNA library clean up

- 18 Before commencing the purification steps, equilibrate Ampure XP beads at room temperature for 15 min, and then vortex well for several seconds.
Add  15 µL Ampure XP beads (1:0.6 ratio) to each sample (each tube might have slightly different volumes due to evaporation).
*Do not increase the volume of beads in the purification step above the 1:1 ratio. A less-than-standard amount of beads ensures that primer dimer carryover is kept to a minimum.
- 19 Mix by pipetting up and down ten times or until the solution appears homogeneous. Transfer solutions to a 96-well plate with compatible magnet stand
- 20 Incubate the mixture for 10 min at room temperature to let the DNA bind to the beads.
 00:10:00
- 21 Place the 96-well plate on the magnetic stand for 5 min or until the solution is clear and the beads have been collected
 00:05:00
- 22 While samples are on the magnet, carefully remove the liquid without disturbing the beads.
- 23 Wash the beads with 200 µL of 80% (vol/vol) ethanol solution. Incubate the samples for 30 sec and then remove the ethanol.

*It is important that the ethanol solution is freshly prepared every time, as ethanol absorbs moisture from the environment, thus changing the final concentration. Repeat ethanol washing.

24 Repeat ethanol washing one more time.

25 Remove any trace of ethanol and let the beads dry completely, leaving the plate at room temperature for 5 min or until a small crack appears on the surface of the beads.

*Avoid over drying the beads because this will make their resuspension in the designated buffer more difficult.

** As a precaution, cover the plate during this step or protect it from any possible source of contamination or air flows that might disperse the beads around the well, thus leading to cross-contamination between adjacent wells especially.

26 When beads are dried, elute dscDNA libraries with

 16.5 µL elution buffer (EB buffer Qiagen) **(19086)**

27 Remove plate from the magnet and mix vigourously by pipetting up and down x3 times to resuspend beads out of the magnet

28 Place the plate on the magnetic stand and leave it for 2 min or until the solution appears clear and beads have accumulated in a corner of the well.

 00:02:00


29 Recover 15 ml of SPN from each well and transfer to a new plate. Label correctly as this plate will be stored.

SAFE STOPPING POINT: cDNA libraries can be stored at -20°C before proceeding to tagmentation.

dscDNA library/concentration size validation

30 Run  1 µL of several purified dscDNA libraries to check the size distribution and estimate of concentrations using a High Sensitivity DNA ChIP (2100 Bioanalyzer). qPCR validation using a housekeeping gene is valuable to guide well selection. Always run your negative control.

Expected result



Adaptor annealing for tagmentation

31 In order to load Tn5 with cell-specific adaptors, these need to be annealed as dsDNA cell-specific adaptors.

To anneal the adapters mix in a 96 well plate:

Mix UMI-TN5-U (100 μ M) and UMI-TN5_1 (μ M) to 96 in TE 1X to final concentration 50 μ M (each), a 1:1 dilution.

Primer annealing thermocycler: 95°C for 3 minutes and gradually cool down to room temperature (0,5 °C/sec).

This plate can be stored at -20°C for several months and used to lead several rounds of Tn5.

Tn5 loading with cell-specific adaptors



32 Prepare the following mix and aliquot ,

Prepare the following mix and aliquot  8.75 μL of the mix (except for adapters) into a new 96 well plate. Then add  1.25 μL of each adaptor to each well.

Reagent	Volume	Observations
50 μM adapter (96 different)	1.25 μL	add this later individually to each well
80% Glycerol	6.25 μL	
50 μM Tn5 transposase	1.25 μL	Hennig, Bianca P., et al. "Large-Scale Low-Cost NGS Library Preparation Using a Robust Tn5 Purification and Tagmentation Protocol." G3: Genes, Genomes, Genetics (2017): g3-300257.
Nuclease-free water	1.25 μL	
Total volume	10 μL	

33 Incubate 37°C for one hour and freeze -20 °C if not going to be used right away.

 01:00:00

* Note, this Tn5-loaded plate can be safely stored for a 1-2 weeks at  -20 °C .

However leaving the loaded plate on ice  4 °C will significantly reduce Tn5 activity and will result in inefficient tagmentation.

Tagmentation

34 Prepare the following mix

Reagent	Volume (per well)
Harvested DNA	6 μ L
Nuclease-free water	8 μ L
2x TAPS buffer	2 μ L
100% DMF	2 μ L
10x Transposome	2.0 μ L
Total volume	20 μL

35 Incubate for 55°C for 5 min → 3 min 85°C to inactivate Tn5 and then cool to  4 °C

 00:05:00

* The tagmentation time can vary depending on the Tn5 purification batch.

5' capture through Streptavidin beads

36 Do a 1:20 dilution of MyOne Streptavidin for the total number of samples (

 1 μ L of beads/sample) .

(Example:  20 μ L beads for 20 samples)

2XBWT Buffer:

10 mM Tris-HCl pH7.5

1mM EDTA

2M NaCl

0.02% Tween-20

37 Wash MyOne beads x2 with 2XBWT buffer and resuspend with 20X more volume than the original volume of beads with 2XBWT



(Example:  20 μL beads for 20 samples, will be finally resuspended with

 400 μL 2XBWT

38 Add 20 μL beads to each well and incubate at RT for 5 min at room temprature

 00:05:00

39 Pool all samples into a single collecting tube (1.5 or 2 ml)

40 Place collecting tube in magnetic rack and allow time enough for the solution to be completely clear

41 Wash beads once with TNT buffer  100 μL

TNT Buffer:

20 mM Tris pH 7.5

50 mM NaCl,

0.02% Tween

42 Wash the beads once in Qiaquick PB  100 μL discard SPN

43 Wash beads 3x with TNT buffer  100 μL again, discard SPN

Removing 3' end fragments

44 Resuspend the beads in the following mix:

Reagent	Volume
CutSmart buffer	10 μL
PvuI-HF enzyme (20 U/ μL)	2 μL
Nuclease-free water	88 μL



Total volume	100 μ L
--------------	-------------

- 45 Incubate at 37°C for one hour with interval mix during the incubation (to avoid beads precipitation); 2 min without mix, 30 sec 1000 rpm mix.

01:00:00

- 46 Wash the beads three times in TNT. 100 μ L

Eluting single stranded cDNA library

- 47 Resuspend in 30 μ L Nuclease-free water.

30 μ L

- 48 Incubate 10 min at 70°C, 850 rpm mix.

00:10:00

- 49 Bind the beads to the magnet immediately and collect the supernatant.

sscDNA cleanup

- 50 Add 54 μ l of room temperature Ampure XP beads to 30 μ sscDNA library

54 μ L Ampure XP beads

- 51 Incubate 10 min at RT. 00:10:00

- 52 Bind the beads to the magnet for 1min and discard supernatant or until solution is completely clear.

00:01:00

- 53 Wash once with 200 μ L fresh 80% ethanol for 20-30 sec. Let the beads be bound to the magnet the entire time.

54 Dry the beads for up to 2 min.

 00:02:00

55 Resuspend in 30 μ L Qiagen EB buffer and incubate 5 min at RT.

 00:05:00

 30 μ L EB

56 Bind the beads 1 min and transfer SPN to a new tube.

Library Concentration

57 To quantify library concentration, set up a KAPA quantification reaction with a 1:100 and 1:1000 dilutions of the eluted cDNA library.

Reagent	Volume (1 rxn)
KAPA SYBR® FAST qPCR Master Mix containing Primer Premix	12 μ l
PCR-grade water	4 μ
Diluted library DNA or DNA Standard	4 μ l
TOTAL	20 μ l

This kit can be substituted by your favorite quantification method or by a qPCR using P5-P7 primer pairs with known standards (PhiX is strongly recommended) sybergreen 2X mastermix.

58 qPCR cycling conditions for KAPA and homemade Sybergreen

Temperature	Time	
95°C	5 min	
95°C	30 sec	repeat this for 30 cycles for qPCR quantification
60°C	45 sec	
4°C	hold	

- 59 Use the qPCR to calculate library quantification using the template provided by **KAPA biosystems** or the instructions provided from your manufacturer.
We have used KAPA, NEB and homemade systems with similar results.

Library Size

60


Sett up a separate PCR to run a bioanalyzer to determine the final size distribution.
Prepare the following mix:

KAPA SYBR Q-PCR Mastermix ABI Prism	10 μ L
Primers mix (10 X)	2 μ l
Water	6 μ L
DNA without dilution	2 μ l
Total volume	20 μl

- 61 Run the same PCR as in step 58 but for 11 cycles

- 62 Run 1 μ L into a High sensitivity DNA CHIP to obtain an average library size based on the Bioanalyzer profile.

Expected result



These two are final library for sequencing. It is pooled from ~80 cells, single stranded. We loaded 10 pM for sequencing and the sequencing reads looks good.

Sequencing

- 63 Sequence the library on the HiSeq 2000 High output using C1-P1-PCR-2 as the *Read 1* primer and UMI-TN5-U as the *Index read* primer.
- 64 To run the libraries on the HiSeq rapid run, us LNA primers. Spike in at primer at 0.5 uM.
Index 1 primer into HP8 (position 17) in the HiSeq
Read 1 primer into HP9 (position 16) in the Hiseq
(double check this information with your sequencing kit/instrument)
- UMI_PCR_read1: +GAATGA+TACGGCG+ACCA +CCGA+T - custom 250 nmole. DNA oligo,
HPLC Purification
Index1: CTGT+CT+CTT+ATA+CA +CA+TCTGA+CG+C - custom 250 nmole DNA oligo,
HPLC Purification
- *Note for High Output run custom primers are needed as well but without LNA
- 65 Load around 8-14 pmol of each library per lane. Libraries are single stranded DNA, so no denaturing is required.